DIRECTIONAL AIR VALVE

AIR PILOT OPERATED

HOW TO ORDER

This model number is a coded number which describes all available options.

NVSA 4 2 1 4 - 00

'ype of Actuation

Single Pilot, Spring return

Double Pilot, detented

Double Pilot, spring centered
(all ports blocked in neutral)

Double Pilot, spring centered
(cyl. ports open to exhaust in neutral)

Double Pilot, spring offset

J = Indicates valve unit only — no base (Includes sub-plate gasket & hold down bolts)

se For Valve Type

V&O A&B

- 41 *51 = Mounted on individual subplate—\%" NPT side ports (5) — dual exhaust
- 42 *52 = Mounted on individual subplate — ¼" NPT side ports (5) — Dual exhaust
- 43 *53 = Mounted on individual subplate — %" NPT side & bottom ports (10) — dual exhaust
- 44 *54 = Mounted on Individual subplate — %" NPT bottom ports (5) — dual exhaust
- 45 *55 = Mounted on individual subplate — %" NPT side ports (5) — dual exhaust
- *12 = Mounted on stacking manifold block ¼" NPT side ports (2)
- 3 *14 = Mounted on stacking manifold block ¼" NPT side & bottom ports (4)
- 15 *16 = Mounted on stacking mounted block ¼" NPT side (2) & bottom (5) ports

*These manifolds & sub-plates incorporate %"
NPT "pilot pressure" ports for supplying
"internal" pilot pressure to the valves.

*Type A and B valves only

_ Optional

M = Interface Speed Control
 V1 = Red Pilot Indicator
 V2 = Green Pilot Indicator

Optional Features

- A = Recessed non-locking operator, -pilot pressure, access through base of valve.
- B = No operator Pilot pressure access through base of valve.
- N = Recessed non-locking operator, "External" pilot connection.
- O = No operator "External" pilot connection.

To Specify "Factory Built" Valve/Manifold Assembly:

- 1. Establish the number of stations required.
- 2. Select the type of valve required on each station.
- 3. Choose Manifold Block desired. e.g. #12, #14 or #16.
- To specify a valve mounted on a manifold block Insert manifold number into valve number i.e. NVSA 4114-11N is a NVSA 4114-00N valve mounted on a #11 block.

To Order "Factory Built" Valve/Manifold Assembly:

EXAMPLE 1 Pce. Four Station Manifold Ass'y comprising:

Station 1. NVSA 4114-12A Station 2 NVSA 4114-14A

Station 3. NVSA 4214-12A

(3) Blocking Discs in P, EA & EB galleries.

Station 4. #16 Manifold Block & Blank Station Kit

1. ME 401LR-4 Assembly Kit

SUBPLATES AND MANIFOLDS

order valves mounted on subplates or manifolds, insert "XX" into Valve No.)

Example: NVSA 4114-"XX"A

IBPLATES (N & O Type Valve)

EAILO	(iv a o Type valve)			
PART NO.	PORTING	(No. of Ports)	"XX"	
3P 0111	1/4" NPTF Side	(5)	41	
3P 0112	1/4" NPTF Side	(5)	42	1
SP 0113	1/4" NPTF Side (5), 1/4" NPTF Botton	n (5)	43	7
3P 0114	¼" NPTF Bottom	(5)	44	8
3P 0115	%" NPTF Side	(5)	45	1

BPLATES (A & B Type Valve %" NPTF Pilot Ports)

ART NO.	PORTING	No. of Ports)	"XX"
PA 0111	%" NPTF Side	(5)	51
PA 0112	¼" NPTF Side	(5)	52
PA 0113	%" NPTF Side (5), %" NPTF Bottor		53
PA 0114	¼" NPTF Bottom	(5)	54
PA 0115	%" NPTF Side	(5)	55

MANIFOLDS

PART NO.	PORTING	(No. of Ports)	"XX"
MBA 4010-02	¼" Side	(2)	12
MBA 4011-02	¼" Side, ¼" Bottom A & B	(4)	14
MBA 4210-02	1/4" Side (2), 1/4" Bottom	(5)	16

ACCESSORIES

PART NUMBER	DESCRIPTION	PCS. REQ.
ME 401 LR	01 LR Left & Right End Plates Includes (3) O-Rings ARP 565-015 (1) Plug AXT 336-9	
ME 401 SLR	Left & Right End Plates - Short w/o Conduit NPT Threads. Includes (3) O-Rings ARP 568-015	
AXT 336-5-*	Tierods - Includes (2) M6X25 Screws Per Rod	2 Reg.
AXT 336-4-*	* Conduit Cover - Includes (4) 8.32 x %" screws. Note: Not required if using ME401SLR End Plates.	
AXT 336-6	Gallery Blocking Disc.	1000
AXT 336-7A	Blank Station Kit	
AXT 337-4	337-4 Right - Pilot Air Gasket	
AXT 337-5	Left - Pilot Air Gasket	
ARP 568-015	(3) Manifold O-Ring	

*ADD No. of Stations