

# 5 Port Solenoid Valve

Metal Seal / Rubber Seal

The EX510 series is to be discontinued. When designing new equipment and facilities, consider using another series (EX260/EX600) instead.



The connection cable and various units for PLC connection in PC wiring systems have been discontinued by the manufacturer. Therefore, while they can no longer be provided, the valve manifold (manifold with built-in valves) can still be ordered. For details, refer to the [Web Catalogue](#).

RoHS  
compliant

## Power saving

Standard: **0.4 w**  
(Reduced by **60%** compared to existing model)

High-pressure (1 MPa, Metal seal): **0.95 w**



Series **VQ1000/2000**



CAT.EUS11-100A-UK

# 5 Port Solenoid Valve Series VQ

## Space-saving profile


All pilot valves are compactly mounted on one side. The space-saving design of mounting all fittings on one side permits mounting in three directions.

## The non-bias, one-clamp structure permits easy valve replacement.

## Built-in one-touch fittings for easy piping

## Slide locking type manual override provided

Manual override cannot be pushed by sliding the switch, to prevent malfunction.




## Thin compact design with high flow capacity

Model	Manifold pitch (mm)	Flow-rate characteristics		Applicable cylinder bore size
		Metal seal	Rubber seal	
		C [dm³/(s·bar)]	C [dm³/(s·bar)]	
VQ1000	10.5	0.72	1.0	Up to ø50
VQ2000	16	2.6	3.2	Up to ø80

Note) Flow-rate characteristics: 4/2 → 5/3 (A/B → R1/R2)

## A wide variety of optional parts (The photo does not show an actual use example.)



## Valve Specifications

			Sonic conductance C [dm <sup>3</sup> /(s·bar)]		Type of actuation					Voltage		Electrical entry			Manual override			
			4/2 → 5/3 (A/B → R1/R2)		Single	Double	Closed centre	Exhaust centre	Pressure centre	12 VDC 24 VDC	Plug-in	Grommet	L-type plug connector	M-type plug connector	Non-locking push type (Tool required)	Locking type (Tool required)	Locking type (Manual)	Slide locking type (Manual)
			Double	Single														
Base Mounted	Plug-in	Series VQ1000	Metal seal	VQ1□00	0.72	0.72	●	●	●	●	●	●			●	●	●	●
					1.0	0.65												
		P. 7	Rubber seal	VQ1□01														
	P. 11	Series VQ2000	Metal seal	VQ2□00	2.6	2.0	●	●	●	●	●	●			●	●	●	●
					3.2	2.2												
		P. 11	Rubber seal	VQ2□01														











Series VQ1000



Series VQ2000

## A variety of common wiring methods are standardized.


<b>F</b> kit (D-sub connector) Number of pins: 15/25   Top entry  Side entry	<b>P</b> kit (Flat ribbon cable) Number of pins: 10/16/20/26   Top entry  Side entry		
<b>T</b> kit (Terminal block box)  	<b>L</b> kit (Lead wire)  	<b>S</b> kit (Serial transmission)  	<b>M</b> kit (Circular connector)   (VQ2000 only)

### Dual 3-port valves, 4 positions

Rubber seal only

- Two 3-port valves built into one body.
- The 3-port valves on the A and B sides can operate independently.
- When used as 3 port valves, only half the number of stations is required.
- Can also be used as a 4-position, 5-port type valve.

Exhaust centre : **VQ1A01**  
                      : **VQ2A01**  
Pressure centre: **VQ1B01**  
                      : **VQ2B01**



R1 A P B R2

Model	A side	B side	JIS symbol
<b>VQ1A01</b> <b>VQ2A01</b>	N.C. valve	N.C. valve	
<b>VQ1B01</b> <b>VQ2B01</b>	N.O. valve	N.O. valve	
<b>VQ1C01</b> <b>VQ2C01</b>	N.C. valve	N.O. valve	

### Semi-standard









### Options

External pilot	D-sub connector 15P	Flat ribbon cable 10P/16P/20P	Negative COM specifications	Inch-size one-touch fittings	Special wiring specifications	Blanking plate	Individual SUP/EXH spacer	SUP/EXH block plate	Name plate	Back pressure check valve	DIN rail mounting	Built-in silencer	Silencer for EXH port	Elbow fitting for cylinder port	Dual flow fitting	Plug for cylinder port	Regulator unit	Ejector unit	Double check block (Separated)
●	●	●	Except S kit	●	Except L kit	●	●	●	●	●	●	●	●	●	●	●	●	●	●
P. 55					P. 65														
●	●	●	Except S kit	●	Except L kit	●	●	●	●	●	●	●	●	●	●	●	●	●	●
P. 55					P. 69														











# Series VQ/Base Mounted: Variations

## Manifold Variations

		Plug-in	
		Series VQ1000	Series VQ2000
<div> <div>F</div> <div>kit</div> </div>	<b>D-sub connector</b> Conforming to with MIL D-sub connector	 P. 17	 P. 17
	<b>P</b> kit <b>Flat ribbon cable (26/20/16/10 pins)</b> Conforming to MIL flat ribbon cable connector	 P. 21	 P. 21
	<b>T</b> kit <b>Terminal block box (Terminal block)</b> Terminal block is compactly arranged on one side.	 P. 33	 IP65 enclosure compatible P. 33
	<b>L</b> kit <b>Lead wire</b> Direct electrical entry type	 P. 37	 IP65 enclosure compatible P. 37




## Manifold Variations

		Plug-in	
		Series VQ1000	Series VQ2000
<div>Gateway-type serial transmission system</div> <div>Serial unit: EX510</div>	<div></div> <div>IP20 enclosure compliant</div> <div>P. 41</div>	<div></div> <div>IP20 enclosure compliant</div> <div>P. 41</div>	
	<div>Integrated-type serial transmission system (for Output)</div> <div>Serial unit: EX120 /124</div>	<div></div> <div>P. 45</div>	<div></div> <div>IP20 enclosure compliant</div> <div>P. 45</div>
		<div></div> <div>Dust-protected (-XP)</div> <div>P. 45</div>	<div></div> <div>Dust-tight, Water-jet-proof (-W) IP65 enclosure compliant</div> <div>P. 45</div>
<div>Circular connector</div> <div>IP65 (Dust-tight, Water-jet-proof)</div>	<div></div>	<div></div> <div>Dust-tight, Water-jet-proof (-W) IP65 enclosure compliant</div> <div>P. 51</div>	

# Cylinder Speed Chart

This chart is provided as guidelines only.  
For performance under various conditions, use SMC's Model Selection Program before making a judgment.



Note 1) It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open.


Note 2) The average velocity of the cylinder is what the stroke is divided by the total stroke time.

Note 3) Load factor:  $((\text{Load mass} \times 9.8) / \text{Theoretical force}) \times 100\%$ .

## Conditions

Series	Conditions	Series CJ2	Series CM2	Series MB, CA2
<b>VQ1101</b>	Tube bore x Length	T0604 (O.D. ø6/I.D. ø4) x 1 m		
	Speed controller	AS3001F-06		
	Silencer	AN200-KM8		
<b>VQ2101</b>	Tube bore x Length	T0806 (O.D. ø8/I.D. ø6) x 1 m		
	Speed controller	AS3001F-08		
	Silencer	AN200-KM10		

# INDEX



Features .....	P. 1
Variations .....	P. 3
Cylinder Speed Chart .....	P. 5
<b>VQ1000</b> How to Order, Manifold Options .....	P. 7
<b>VQ2000</b> How to Order, Manifold Options .....	P. 11
<b>VQ1000/2000</b> Model, Standard/Manifold Specifications .....	P. 15
<b>VQ1000/2000</b>	
<b>F</b> kit (D-sub connector) .....	P. 17
<b>VQ1000/2000</b>	
<b>P</b> kit (Flat ribbon cable) .....	P. 21
<b>VQ1000/2000</b>	
<b>T</b> kit (Terminal block box) .....	P. 33
<b>VQ1000/2000</b>	
<b>L</b> kit (Lead wire) .....	P. 37
<b>VQ1000/2000</b>	
<b>S</b> kit (Serial transmission) EX510 .....	P. 41
<b>VQ1000/2000</b>	
<b>S</b> kit (Serial transmission) EX120/124 .....	P. 45
<b>VQ2000</b>	
<b>M</b> kit (Circular connector) .....	P. 51
<b>VQ2000</b> Sub-plate Single Unit .....	P. 54
<b>VQ1000/2000</b> Semi-standard .....	P. 55
<b>VQ1000/2000</b> Construction .....	P. 59
<b>VQ1000/2000</b> Exploded View of Manifold .....	P. 61
<b>VQ1000/2000</b> Manifold Optional Parts .....	P. 65
<b>VQ1000/2000</b> Specific Product Precautions .....	Back page




# Plug-in Unit Base Mounted

# Series VQ1000

[Option]

## How to Order Manifold



Symbol	Option
—	None
B Note 2)	With back pressure check valve
D	DIN rail mounting
D0	With DIN rail bracket (Without DIN rail)
D□ Note 6)	DIN rail length specified
G1 Note 3) Note 8)	1 set of regulator unit
G2 Note 3) Note 7)	2 sets of regulator unit
G3 Note 3) Note 7)	3 sets of regulator unit
K Note 4)	Special wiring spec. (Except double wiring)
N Note 8)	With name plate
R Note 5)	External pilot
S	Direct EXH outlet with built-in silencer

- Note 1) When multiple symbols are specified, indicate them by letter in the order that they appear in the table, starting from the top. Example: -BFS
- Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.
- Note 3) Specify the mounting position by means of the manifold specification sheet.
- Note 4) Specify the wiring specifications by means of the manifold specification sheet. (Except L kit)
- Note 5) Indicate "R" for the valve with external pilot.
- Note 6) □: Station. Example: D08: The number of stations that may be displayed is longer than the manifold number of stations.
- Note 7) G1, G2, or G3 cannot be combined with N.
- Note 8) When mounting the blanking plate with connector and the slide locking manual type valve by ordering only the manifold, order the name plate separately.

### Cylinder port

Symbol	Port size	Symbol	Port size
C3	With ø3.2 one-touch fitting	L5	Top ported elbow M5 thread
C4	With ø4 one-touch fitting	B3	Bottom ported elbow with ø3.2 one-touch fitting
C6	With ø6 one-touch fitting	B4	Bottom ported elbow with ø4 one-touch fitting
M5	M5 thread	B6	Bottom ported elbow with ø6 one-touch fitting
CM Note 1)	Mixed sizes and with port plug	B5	Bottom ported elbow M5 thread
L3	Top ported elbow with ø3.2 one-touch fitting	LM Note 1)	Elbow port, mixed sizes
L4	Top ported elbow with ø4 one-touch fitting	MM Note 2)	Mixed size for different types of piping, option installed
L6	Top ported elbow with ø6 one-touch fitting		

- Note 1) Indicate "Mixed sizes and with port plug" by means of the manifold specification sheet.
- Note 2) When selecting the mixed size for different types of piping or dual flow fitting assembly, enter "MM" and give instructions in the manifold specification sheet.
- Note 3) Inch-size one-touch fittings are also available. Refer to page 57 for details.
- Note 4) M5 fittings for M5 thread are attached without being incorporated.

### Kit type/Electrical entry/Cable length

F kit (D-sub connector)				P kit (Flat ribbon cable)			
Top entry		Side entry		Top entry		Side entry	
Note 1) 25P		Note 1) 26P		Note 1) 26P		Note 1) 26P	
Connector entry direction		P. 17		Connector entry direction		P. 21	
Top entry	Side entry	Top entry	Side entry	Top entry	Side entry	Top entry	Side entry
FU0	FS0	Without cable	Note 2) 2 to 24 stations	PU0	PS0	Without cable	Note 2) 2 to 24 stations
FU1	FS1	With cable (1.5 m)		PU1	PS1	With cable (1.5 m)	
FU2	FS2	With cable (3 m)		PU2	PS2	With cable (3 m)	
FU3	FS3	With cable (5 m)		PU3	PS3	With cable (5 m)	

- Note 1) Besides the above, F/P kit with different number of pins are available. Refer to page 55 for details.
- Note 2) Refer to page 56 for details.



## How to Order Valves

## How to Order Manifold Assembly

**VQ 1 1 0 0 - 5 1 - Q**

**Series**  
1 VQ1000

**CE/UKCA compliant**  
Note) DC specification only

### Type of actuation

1	2-position single	(A)(B) (R1)(P)(R2)
2	Metal 2-position double (A)(B) (R1)(P)(R2)	
	Rubber 2-position double (A)(B) (R1)(P)(R2)	
3	3-position closed centre (A)(B) (R1)(P)(R2)	
4	3-position exhaust centre (A)(B) (R1)(P)(R2)	
5	3-position pressure centre (A)(B) (R1)(P)(R2)	
A Note)	4-position dual 3-port valve (A) N.C. 1 N.C.	
B Note)	4-position dual 3-port valve (B) N.O. 1 N.O.	
C Note)	4-position dual 3-port valve (C) N.C. 1 N.O.	

### Seal

0	Metal seal
1	Rubber seal

### Function

Symbol	Specifications
—	Standard
B	High-speed response type
K Note 1)	High-pressure type (1.0 MPa)
N Note 2)	Negative common
R Note 2)	External pilot

Note 1) Metal seal only.  
Note 2) For external pilot and negative common specifications, refer to "Semi-standard" on pages 56 to 57.

Note 3) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not

Note 4) Rubber seal only

### Manual override

—: Non-locking push type (Tool required)	B: Locking type (Tool required)
C: Locking type (Manual)	D: Slide locking type (Manual)

### Light/surge voltage suppressor


—	Yes
E Note)	None

Note) Not applicable to the S kit.

### Coil voltage

5	24 VDC
6	12 VDC

### Example



VV5Q11-09C6FU2-Q · 1 set (F kit 9-station manifold base part no.)  
\*VQ1100-51 ······ 4 sets (Single solenoid part no.)  
\*VQ1200-51 ······ 4 sets (Double solenoid part no.)  
\*VVQ1000-10A-1 ······ 1 set (Blanking plate part no.)


The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

Specify the part numbers for valves and options together beneath the manifold base part number. Besides, when the arrangement will be complicated, specify them by means of the manifold specification sheet.

## Caution


Use the standard specification when continuously energizing for long periods of time.

## T kit (Terminal block box)




P. 33

## L kit (Lead wire)



P. 37

## S kit (Serial transmission)



The valve is equipped with an indicator light and surge voltage suppressor, and the voltage is 24 VDC.

P. 45


T0	Terminal block box	2 to 24 stations Note 2)	L0	With cable (0.6 m)	L1	With cable (1.5 m)	L2	With cable (3 m)	1 to 8 stations	S0	Without SI unit	S1	DeviceNet®	S2	CC-LINK	S3	CompoNet® (Positive common)	S4	CompoNet® (Negative common)	Max. 16 stations

# Series VQ1000


## VQ1000: Manifold Options

P. 65 to 68


**Blanking plate assembly**  
VVQ1000-10A-1




**Individual SUP spacer**  
VVQ1000-P-1-C<sub>6</sub>  
N<sub>7</sub>




**Individual EXH spacer**  
VVQ1000-R-1-C<sub>6</sub>  
N<sub>7</sub>




**SUP block plate**  
VVQ1000-16A




**Blanking plate with connector**  
VVQ1000-1C□-□




**EXH block base assembly**  
VVQ1000-19A-  
F□ C3, C4  
P□ C6, M5  
L□ N1, N3  
N7




**Back pressure check valve assembly [-B]**  
VVQ1000-18A




**Name plate [-N]**  
VVQ1000-N<sub>NC</sub>-Station  
(1 to Max. stations)




**Blanking plug**  
KQ2P-□




**Port plug**  
VVQ0000-58A




**Elbow fitting assembly**  
VVQ1000-F-L□




**DIN rail mounting bracket**  
[-D/-D0/-D□]  
VVQ1000-57A




**Direct EXH outlet with built-in silencer**  
[-S]



**Dual flow fitting assembly**  
VVQ1000-52A-C<sub>8</sub>  
N<sub>9</sub>




**Silencer (For EXH port)**  
AN200-KM8/AN203-KM8




- Refer to back page 4 for cylinder port fittings part number.
- Refer to page 62 for replacement parts.

**Regulator unit**  
VVQ1000-AR-1



**Double check block**  
VVQ1000-FPG-□□-□







# Plug-in Unit Base Mounted

# Series VQ2000

[Option]

## How to Order Manifold

**VV5Q 2 1 - 08 C6 FU1 - - Q**

**Series**  
2 VQ2000

**Manifold**  
1 Plug-in unit

**CEUKCA compliant**  
Note) DC specification only

**Option**

Symbol	Option
—	None
B Note 2)	With back pressure check valve
D	DIN rail mounting
D0	With DIN rail bracket (Without DIN rail)
D□ Note 5)	DIN rail length specified
K Note 3)	Special wiring spec. (Except double wiring)
N Note 6)	With name plate
R Note 4)	External pilot
S	Direct EXH outlet with built-in silencer
W Note 7)	Enclosure: Dust-tight, Water-jet-proof (IP65) (T/L/S/M kit only)

**Stations**

Symbol	Port size
01	1 station
⋮	⋮

The maximum and minimum number of stations are varied depending on kit. (Refer to the below table.)

**Cylinder port**

Symbol	Port size
C4	With ø4 one-touch fitting
C6	With ø6 one-touch fitting
C8	With ø8 one-touch fitting
CM Note 1)	Mixed sizes and with port plug
L4	Top ported elbow with ø4 one-touch fitting
L6	Top ported elbow with ø6 one-touch fitting

Symbol	Port size
L8	Top ported elbow with ø8 one-touch fitting
B4	Bottom ported elbow with ø4 one-touch fitting
B6	Bottom ported elbow with ø6 one-touch fitting
B8	Bottom ported elbow with ø8 one-touch fitting
LM Note 1)	Elbow port, mixed sizes
MM Note 2)	Mixed size for different types of piping, option installed

Note 1) Indicate "Mixed size and with port plug" by means of the manifold specification sheet.  
Note 2) When selecting the mixed size for different types of piping, dual flow fitting assembly, or double check block (direct mounting), enter "MM" and give instructions in the manifold specification sheet.  
Note 3) Inch-size one-touch fittings are also available. Refer to page 57 for details.

Note 1) When two or more symbols are specified, indicate them alphabetically.  
Example: -DNR

Note 2) Models with a suffix "B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.

Note 3) Specify the wiring specifications by means of the manifold specification sheet. (Except L kit)

Note 4) Indicate "R" for the valve with external pilot.

Note 5) □: Station. Example: D08: The number of stations that may be displayed is longer than the manifold number of stations.

Note 6) When mounting the slide locking manual type valve by ordering only the manifold, order the name plate separately.

Note 7) When used in combination with the direct EXH outlet with built-in silencer type, keep the exhaust port from coming into direct contact with water or other liquids.

## Kit type/Electrical entry/Cable length

**F kit (D-sub connector)**

Note 1) 25P

Connector entry direction		Without cable	With cable (1.5 m)	With cable (3 m)	With cable (5 m)
Top entry	Side entry				
FU0	FS0				
FU1	FS1				
FU2	FS2				
FU3	FS3				

Note 2) 2 to 24 stations

**P kit (Flat ribbon cable)**

Note 1) 26P

Connector entry direction		Without cable	With cable (1.5 m)	With cable (3 m)	With cable (5 m)
Top entry	Side entry				
PU0	PS0				
PU1	PS1				
PU2	PS2				
PU3	PS3				

Note 2) 2 to 24 stations

**T kit (Terminal block box)**

Dust-tight/Water-jet-proof (IP65) compatible Note 3)

**L kit (Lead wire)**

Dust-tight/Water-jet-proof (IP65) compatible Note 3)

	Without SI unit	DeviceNet®	CC-LINK	CompoNet® (Positive common)	CompoNet® (Negative common)
S0					
SQ					
SV					
SZB					
SZBN					

Note 2) Max. 16 stations

**S kit (Serial transmission)**

The valve is equipped with an indicator light and surge voltage suppressor, and the voltage is 24 VDC. Dust-tight, Water-jet-proof (IP65) is available. Note 3)

**M kit (Circular-connector)**

Dust-tight/Water-jet-proof (IP65) compatible Note 3)

	Without cable	With cable (1.5 m)	With cable (3 m)	With cable (5 m)
M0				
M1				
M2				
M3				

Note 2) 2 to 24 stations

Note 1) Besides the above, F/P kit with different number of pins are available. Refer to page 55 for details.  
Note 2) Refer to page 56 for details.

Note 3) Refer to the pages on respective kits for IP65 type. (T/L/S kit)

## How to Order Valves

## How to Order Manifold Assembly

**VQ 2 1 0 0 - 5 - 1 - Q**

**Series**  
2 VQ2000

**Seal**  
0 Metal seal  
1 Rubber seal

**Type of actuation**

1	2-position single (A)(B) (R1)(P)(R2)	A Note)	4-position dual 3-port valve (A) N.C. 1 N.C.
2	Metal 2-position double (A)(B) (R1)(P)(R2)	B Note)	4-position dual 3-port valve (B) N.O. 1 N.O.
	Rubber 2-position double (A)(B) (R1)(P)(R2)	C Note)	4-position dual 3-port valve (C) N.C. 1 N.O.
3	3-position closed centre (A)(B) (R1)(P)(R2)	Note) Rubber seal only	
4	3-position exhaust centre (A)(B) (R1)(P)(R2)		
5	3-position pressure centre (A)(B) (R1)(P)(R2)		

Note) For sub-plate single unit type, refer to page 54.

### Function

Symbol	Specifications
—	Standard
B	High-speed response type
K Note 1)	High-pressure type (1.0 MPa)
N Note 2)	Negative common
R Note 2)	External pilot

Note 1) Metal seal only  
Note 2) For external pilot and negative common specifications, refer to "Semi-standard" on pages 56 to 57.  
Note 3) When two or more symbols are specified, indicate them alphabetically.  
Combination of [B] and [K] is not

### Caution

Use the standard specification when continuously energizing for long periods of time.

• CE/UKCA compliant  
Note) DC specification only

• Light/surge voltage suppressor

—	Yes
E Note)	None


Note) Not applicable to the S kit.

### Coil voltage


5	24 VDC
6	12 VDC

### Manual override


—: Non-locking push type  
(Tool required)




B: Push-locking slotted type  
(Tool required)




C: Locking type (Manual)



D: Slide locking type (Manual)



### Example



VV5Q21-08C8FU2 1 set (F kit 8-station manifold base part no.)  
\*VQ2100-51 ..... 3 sets (Single solenoid part no.)  
\*VQ2200-51 ..... 4 sets (Double solenoid part no.)  
\*VVQ2000-10A-1 ..... 1 set (Blanking plate part no.)

The asterisk denotes the symbol for assembly.  
Prefix it to the part nos. of the solenoid valve, etc.

Specify the part numbers for valves and options together beneath the manifold base part number. Besides, when the arrangement will be complicated, specify them by means of the manifold specification sheet.




# Series VQ2000


## VQ2000: Manifold Options

P. 69 to 73


**Blanking plate assembly**  
VVQ2000-10A-1




**Individual SUP spacer**  
VVQ2000-P-1-C<sub>8</sub>  
N<sub>9</sub>




**Individual EXH spacer**  
VVQ2000-R-1-C<sub>8</sub>  
N<sub>9</sub>




**SUP block plate**  
VVQ2000-16A




**EXH block plate**  
VVQ2000-19A




**SUP stop valve spacer**  
VVQ2000-24A-1




**Back pressure check valve assembly [-B]**  
VVQ2000-18A




**Name plate [-N]**  
VVQ2000-N-Station  
(1 to Max. stations)




**Blanking plug**  
KQ2P-□




**Port plug**  
VVQ1000-58A




**DIN rail mounting bracket**  
[-D/-D0/-D□]  
VVQ2000-57A




**Direct EXH outlet with built-in silencer**  
[-S]




**Silencer (For EXH port)**  
AN200-KM10



**Elbow fitting assembly**  
VVQ2000-F-L□




**Dual flow fitting assembly**  
VVQ2000-52A-C<sub>10</sub>  
N<sub>11</sub>




- Refer to back page 4 for cylinder port fittings part number.
- Refer to page 64 for replacement parts.

**Double check block (Separated)**  
VQ2000-FPG-□□-□



**Double check block (Direct mounting)**  
VVQ2000-23A-□



Color: red



# Plug-in Unit

## Base Mounted

# Series VQ1000/2000



### Model

Series	Type of actuation		Model		Flow-rate characteristics <sup>Note 1)</sup>								Response time (ms) <sup>Note 2)</sup>		Weight (g)	
					1 → 2/4 (P → A/B)				2/4 → 3/5 (A/B → R1/R2)				Standard: 0.4 W	High-speed response: 0.95 W		
					C [dm³/(s·bar)]	b	Cv	Q <sup>Note 3)</sup> [ℓ/min] (ANR)	C [dm³/(s·bar)]	b	Cv	Q <sup>Note 3)</sup> [ℓ/min] (ANR)				
VQ1000	2-position	Single	Metal seal	VQ1100	0.70	0.15	0.16	163	0.72	0.25	0.18	178	15 or less	12 or less	67	
			Rubber seal	VQ1101	0.85	0.20	0.21	204	1.0	0.30	0.25	254	20 or less	15 or less		
		Double	Metal seal	VQ1200	0.70	0.15	0.16	163	0.72	0.25	0.18	178	13 or less	10 or less		77
			Rubber seal	VQ1201	0.85	0.20	0.21	204	1.0	0.30	0.25	254	20 or less	15 or less		
	3-position	Closed centre	Metal seal	VQ1300	0.68	0.15	0.16	158	0.72	0.25	0.18	178	26 or less	20 or less		
			Rubber seal	VQ1301	0.70	0.20	0.16	168	0.65	0.42	0.18	179	33 or less	25 or less		
		Exhaust centre	Metal seal	VQ1400	0.68	0.15	0.16	158	0.72	0.25	0.18	178	26 or less	20 or less		
			Rubber seal	VQ1401	0.70	0.20	0.16	168	1.0	0.30	0.25	254	33 or less	25 or less		
		Pressure centre	Metal seal	VQ1500	0.70	0.15	0.16	163	0.72	0.25	0.18	178	26 or less	20 or less		
			Rubber seal	VQ1501	0.85	0.20	0.21	204	0.65	0.42	0.18	179	33 or less	25 or less		
	4-position	Dual 3-port valve	Rubber seal	VQ1 <sup>A</sup> <sub>C</sub> 01	0.70	0.20	0.16	168	0.70	0.20	0.16	168	33 or less	25 or less		
VQ2000	2-position	Single	Metal seal	VQ2100	2.0	0.15	0.46	466	2.6	0.15	0.60	606	29 or less	22 or less	95	
			Rubber seal	VQ2101	2.2	0.28	0.55	552	3.2	0.30	0.80	814	31 or less	24 or less		
		Double	Metal seal	VQ2200	2.0	0.15	0.46	466	2.6	0.15	0.60	606	20 or less	15 or less		105
			Rubber seal	VQ2201	2.2	0.28	0.55	552	3.2	0.30	0.80	814	26 or less	20 or less		
	3-position	Closed centre	Metal seal	VQ2300	2.0	0.15	0.46	466	2.0	0.18	0.46	474	38 or less	29 or less		
			Rubber seal	VQ2301	2.0	0.28	0.49	502	2.2	0.31	0.60	563	44 or less	34 or less		
		Exhaust centre	Metal seal	VQ2400	2.0	0.15	0.46	466	2.6	0.15	0.60	606	38 or less	29 or less		
			Rubber seal	VQ2401	2.0	0.28	0.49	502	3.2	0.30	0.80	814	44 or less	34 or less		
		Pressure centre	Metal seal	VQ2500	2.4	0.17	0.57	565	2.0	0.18	0.46	474	38 or less	29 or less		
			Rubber seal	VQ2501	3.2	0.28	0.80	804	2.2	0.31	0.60	563	44 or less	34 or less		
	4-position	Dual 3-port valve	Rubber seal	VQ2 <sup>A</sup> <sub>B</sub> 01	1.8	0.28	0.46	452	1.8	0.28	0.46	452	44 or less	34 or less		



Note 1) The values are given for port size C6: (VQ1000), C8: (VQ2000) without back pressure check valve.


Note 2) As per JIS B 8375-1981 (Supply pressure 0.5 MPa; with indicator light/surge voltage suppressor; clean air. The response time is subject to the pressure and quality of the air.) The values at the time of ON are given for double types.

Note 3) These values have been calculated according to ISO6358 and indicate the flow rate under standard conditions with an inlet pressure of 0.6 MPa (relative pressure) and a pressure drop of 0.1 MPa.



## Standard Specifications

### JIS symbol



Note) Rubber seal only

Valve specifications	Valve type	Metal seal		Rubber seal
	Fluid	Air, Inert gas		Air, Inert gas
	Maximum operating pressure	0.7 MPa (High-pressure type: 1.0 MPa)		0.7 MPa
	Minimum operating pressure	Single	0.1 MPa	0.15 MPa
		Double	0.1 MPa	0.1 MPa
		3-position	0.1 MPa	0.2 MPa
		4-position	—	0.15 MPa
	Ambient and fluid temperature	-10 to 50°C (Note 1)		
	Lubrication	Not required		
	Manual override	Push type, Locking type (Tool required, Manual) semi-standard		
Electrical specifications	Impact/Vibration resistance (Note 2)	150/30 m/s <sup>2</sup>		
	Enclosure	Dust-protected; Dust-tight, Water-jet-proof (IP65) (Note 4)		
	Coil rated voltage	12, 24 VDC		
	Allowable voltage fluctuation	10% of rated voltage		
	Coil insulation type	Equivalent to Class B		

Note 1) Use dry air to prevent condensation when operating at low temperatures.

Note 2) Impact resistance ..... No malfunction occurred when it is tested in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance ... No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Note 3) Value for high-speed response, high-voltage type (0.95 W)


Note 4) Dust-tight, Water-jet-proof (IP65) is available on T/L/S/M kit of the VQ2000.

## Manifold Specifications


Series	Base model	Connection type	Piping specifications			Applicable stations	Applicable solenoid valve	5-station weight (g)
			Piping direction	Port size <sup>Note 1)</sup>				
				1(P), 3(R)	4(A), 2(B)			
VQ1000	VV5Q11-□□□-Q	F kit—D-sub connector P kit—Flat ribbon cable T kit—Terminal block box L kit—Lead wire S kit—Serial transmission	Side	C8 (ø8) <div>Option: Direct EXH outlet with built-in silencer</div>	C3 (ø3.2)  C4(ø4)  C6 (ø6)  M5 (M5 thread)	<div>( F/P/T kit ) 2 to 24 stations /</div> <div>( S kit ) 2 to 16 stations /</div> <div>( L kit ) 1 to 8 stations )</div>	VQ1□00  VQ1□01	643 (Single) 754 (Double, 3-position)
VQ2000	VV5Q21-□□□-Q	F kit—D-sub connector P kit—Flat ribbon cable T kit—Terminal block box L kit—Lead wire S kit—Serial transmission M kit—Circular connector	Side	C10 (ø10) <div>Option: Direct EXH outlet with built-in silencer</div>	C4 (ø4)  C6 (ø6)  C8 (ø8)	<div>( F/P kit ) 2 to 24 stations /</div> <div>( S kit ) 2 to 16 stations /</div> <div>( L kit ) 1 to 8 stations )</div> <div>( T kit ) 2 to 20 stations /</div>	VQ2□00  VQ2□01	1076 (Single) 1119 (Double, 3-position)

Note 1) Inch-size one-touch fittings are also available. Refer to page 57 for details.

Note 2) Refer to page 56 for details.




VV5Q11



VV5Q21

# F Series VQ1000/2000 Kit (D-sub connector)



- D-sub connector reduces installation labour for electrical connections.
- Using the D-sub connector (25P), (15P as semi-standard) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 24.

## Manifold Specifications


Series	Piping specifications		Applicable stations
	Piping direction	Port size	
VQ1000	Side	1(P), 3(R) C8	C3, C4, C6, M5 Max. 24 stations
VQ2000	Side	C10	C4, C6, C8 Max. 24 stations

## D-sub Connector (25 Pins)

## Cable Assembly ●

AXT100-DS25-015  
030  
050

(The D-sub connector cable assembly can be ordered individually or included in a specific manifold model no. Refer to "How to Order Manifold.")



### D-sub connector cable assembly

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-DS25-015	Cable 0.3 mm <sup>2</sup> x 25 cores
3 m	AXT100-DS25-030	
5 m	AXT100-DS25-050	

Note 1) For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308.

Note 2) Cannot be used for transfer wiring.

### Connector manufacturers' example

- Fujitsu Limited
- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.
- Hirose Electric Co., Ltd.

### Electrical characteristics

Item	Property
Conductor resistance /km, 20C	65 or less
Voltage limit V, 1 min, AC	1000
Insulation resistance M/km, 20C	5 or more

Note) The min. bending radius of the D-sub connector cable assembly is 20 mm.


### Wire colour by terminal no. of D-sub connector cable assembly

Terminal no.	Lead wire colour	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Grey	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Grey	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Grey	Red
24	Black	White
25	White	None

Note 1) Types with 15 pins are also available. Refer to page 55 for details.

Note 2) Lengths other than the above are also available. Please contact SMC for details.

## How to Order Manifold



Symbol	Port size	VQ1000	VQ2000
C3	With ø3.2 one-touch fitting	●	—
C4	With ø4 one-touch fitting	●	●
C6	With ø6 one-touch fitting	●	●
C8	With ø8 one-touch fitting	—	●
M5	M5 thread	●	—
CM Note 3)	Mixed sizes and with port plug	●	●
MM Note 4)	Mixed size for different types of piping, option installed	●	●

### Option

Symbol	Option	VQ1000	VQ2000
—	None	●	●
B Note 2)	With back pressure check valve	●	●
D	DIN rail mounting	●	●
D0	With DIN rail bracket (Without DIN rail)	●	●
D□ Note 3)	DIN rail length specified (□: Stations 02 to 24)	●	●
G1 Note 4) Note 7)	1 set of regulator unit	●	—
G2 Note 4) Note 7)	2 sets of regulator unit	●	—
G3 Note 4) Note 7)	3 sets of regulator unit	●	—
K Note 5)	Special wiring specifications (Except double wiring)	●	●
N	With name plate	●	●
R Note 6)	External pilot	●	●
S	Direct EXH outlet with built-in silencer	●	●

Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BRS

Note 2) Models with a suffix "B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.

Note 3) The number of stations that may be displayed is longer than the manifold number of stations.

Note 4) Specify the mounting position by means of the manifold specification sheet.

Note 5) Specify the wiring specifications by means of the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

Note 7) G1, G2, or G3 cannot be combined with N.


Note 1) Insert "L" (Top ported) or "B" (Bottom ported) for elbow type. Example) B6 (Bottom ported elbow with ø6 one-touch fitting)

Note 2) Indicate "LM" for models with elbow fittings and mixed cylinder port sizes.

Note 3) Indicate "Mixed sizes and with port plug" by means of the manifold specification sheet.

Note 4) When selecting the mixed size for different types of piping, dual flow fitting assembly, or double check block (direct mounting), enter "MM" and give instructions in the manifold specification sheet.

Note 5) Inch-size one-touch fittings are available. Refer to "Semi-standard" on page 57 for details.



The total number of stations is tabulated starting from station one on the D-side.

## Electrical Wiring Specifications

**D-sub connector**

**D-sub connector assembly**  
015  
AXT100-DS25- 030 Wire colour  
050

Terminal no.	Polarity	Lead wire colour	Dot marking	
Station 1 SOLA 1	(-)	(+)	Black	None
Station 1 SOLB 14	(-)	(+)	Yellow	Black
Station 2 SOLA 2	(-)	(+)	Brown	None
Station 2 SOLB 15	(-)	(+)	Pink	Black
Station 3 SOLA 3	(-)	(+)	Red	None
Station 3 SOLB 16	(-)	(+)	Blue	White
Station 4 SOLA 4	(-)	(+)	Orange	None
Station 4 SOLB 17	(-)	(+)	Purple	None
Station 5 SOLA 5	(-)	(+)	Yellow	None
Station 5 SOLB 18	(-)	(+)	Grey	None
Station 6 SOLA 6	(-)	(+)	Pink	None
Station 6 SOLB 19	(-)	(+)	Orange	Black
Station 7 SOLA 7	(-)	(+)	Blue	None
Station 7 SOLB 20	(-)	(+)	Red	White
Station 8 SOLA 8	(-)	(+)	Purple	White
Station 8 SOLB 21	(-)	(+)	Brown	White
Station 9 SOLA 9	(-)	(+)	Grey	Black
Station 9 SOLB 22	(-)	(+)	Pink	Red
Station 10 SOLA 10	(-)	(+)	White	Black
Station 10 SOLB 23	(-)	(+)	Grey	Red
Station 11 SOLA 11	(-)	(+)	White	Red
Station 11 SOLB 24	(-)	(+)	Black	White
Station 12 SOLA 12	(-)	(+)	Yellow	Red
Station 12 SOLB 25	(-)	(+)	White	None
COM. 13	(+)	(-)	Orange	Red

As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 12 stations or less, regardless of valve and option types. Mixed single and double wiring is available as semi-standard. Refer to page 56 for details.

Note) When using the negative common specifications, use valves for negative common. (Refer to page 56.) Refer to "Semi-standard" on page 56 for details.

## How to Order Valves

**VQ 1 1 0 0 - 5 - 1 - Q**

**Series**

1	VQ1000
2	VQ2000

**Type of actuation**

1	2-position single
2	2-position double
3	3-position closed centre
4	3-position exhaust centre
5	3-position pressure centre
A	4-position dual port (N.C. +N.C.)
B	4-position dual port (N.O. +N.O.)
C	4-position dual port (N.C. +N.O.)

**Seal**

0	Metal seal
1	Rubber seal

**Function**

Symbol	Specifications
—	Standard
B	High-speed response type
K Note 1)	High-pressure type (1.0 MPa)
N Note 2)	Negative common
R Note 2)	External pilot

Note 1) Metal seal only  
Note 2) For external pilot and negative common specifications, refer to "Semi-standard" on pages 56 to 57.  
Note 3) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not possible.

**CE/UKCA compliant**  
Note) DC specification only

**Manual override**

—	Non-locking push type (Tool required)
B	Locking type (Tool required)
C	Locking type (Manual)
D	Slide locking type (Manual)

**Light/surge voltage suppressor**

—	Yes
E	None

**Coil voltage**

5	24 VDC
6	12 VDC

## How to Order Manifold Assembly

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

D-sub connector kit with cable (3 m)

VV5Q11-09C6FU2-Q · 1 set—Manifold base part no.

\*VQ1100-51-Q ······2 sets—Valve part no. (Stations 1 to 2)


\*VQ1200-51-Q ······4 sets—Valve part no. (Stations 3 to 6)

\*VQ1300-51-Q ······2 sets—Valve part no. (Stations 7 to 8)

\*VVQ1000-10A-1-Q ···1 set—Blanking plate part no. (Station 9)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D-side. When part nos. written collectively are complicated, specify them by means of the manifold specification sheet.




## Caution

Use the standard specification when continuously energizing for long periods of time.

# F Series VQ1000/2000 kit (D-sub connector)

## VV5Q11


The dashed lines indicate the DIN rail mounting [-D] and the side entry connection [-FS].



D side

Stations -- 1 -- 2 -- 3 -- 4 -- 5 -- 6 -- 7 -- 8 -- n

U side



### Dimensions


Formula L1 = 10.5n + 44.5, L2 = 10.5n + 62.5 n: Station (Maximum 24 stations)

L \ n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5	223	233.5	244	254.5	265	275.5	286	296.5
L2	83.5	94	104.5	115	125.5	136	146.5	157	167.5	178	188.5	199	209.5	220	230.5	241	251.5	262	272.5	283	293.5	304	314.5
(L3)	112.5	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5	275	287.5	300	312.5	325	325	337.5
(L4)	123	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5	323	335.5	335.5	348



With ejector unit: Formula L1 = 10.5n + 28.7 + (Number of ejector units x 26.7)  
L2 = 10.5n + 46.3 + (Number of ejector units x 26.7)  
L4 is L2 plus about 30.

# VV5Q21

The dashed lines indicate the DIN rail mounting [-D] and the side entry connection [-FS].



Applicable connector: D-sub connector (25P)  
(Complies with MIL-C-24308)



## Dimensions


Formula  $L1 = 16n + 53$ ,  $L2 = 16n + 73$  n: Station (Maximum 24 stations)

L \ n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341	357	373	389	405	421	437
L2	105	121	137	153	169	185	201	217	233	249	265	281	297	313	329	345	361	377	393	409	425	441	457
(L3)	137.5	150	162.5	187.5	200	212.5	225	250	262.5	275	300	312.5	325	337.5	350	375	387.5	400	412.5	437.5	450	462.5	487.5
(L4)	148	160.5	173	198	210.5	223	235.5	260.5	273	285.5	310.5	323	335.5	348	360.5	385.5	398	410.5	423	448	460.5	473	498



# P

# Series VQ1000/2000 kit (Flat ribbon cable)



VV5Q11

VV5Q21

- MIL flat ribbon cable connector reduces installation labour for electrical connection.
- Using the connector for flat ribbon cable (26P) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 24.

## Manifold Specifications


Series	Piping specifications			Applicable stations
	Piping direction	Port size		
		1(P), 3(R)	4(A), 2(B)	
VQ1000	Side	C8	C3, C4, C6, M5	Max. 24 stations
VQ2000	Side	C10	C4, C6, C8	Max. 24 stations

## Flat Ribbon Cable (26 Pins)

### Cable Assembly

AXT100-FC26-1  
to  
3

(Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to "How to Order Manifold.")



### Flat Ribbon Cable Connector Assembly

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC26-1	Cable 26 cores x 28AWG
3 m	AXT100-FC26-2	
5 m	AXT100-FC26-3	

Note 1) For other commercial connectors, use a 26 pins type with strain relief conforming to MIL-C-83503.


Note 2) Cannot be used for transfer wiring.

### Connector manufacturers' example

- Hirose Electric Co., Ltd.
- Fujitsu Limited
- J.S.T. Mfg. Co., Ltd.
- Sumitomo 3M Limited
- Japan Aviation Electronics Industry, Ltd.
- Oki Electric Cable Co., Ltd.

Note 1) Other than the above model, 10P, 16P, 20P are also available. Refer to page 55 for details.

Note 2) Lengths other than the above are also available. Please contact SMC for details.



VV5Q11

VV5Q21

The total number of stations is tabulated starting from one on the D-side.

## How to Order Manifold

**VV5Q 1 1 - 08 C6 P U 1 - - Q**

**Series**

1	VQ1000
2	VQ2000

**Manifold**

1	Plug-in unit
---	--------------

**Stations**

02	2 stations
...	...
24	24 stations

Note) Refer to page 56 for details.

**Connector entry direction**

U	Top entry
S	Side entry

**Cylinder port**

Symbol	Port size	VQ1000	VQ2000
C3	With ø3.2 one-touch fitting	●	—
C4	With ø4 one-touch fitting	●	●
C6	With ø6 one-touch fitting	●	●
C8	With ø8 one-touch fitting	—	●
M5	M5 thread	●	—
CM Note 3)	Mixed sizes and with port plug	●	●
MM Note 4)	Mixed size for different types of piping, option installed	●	●

**Cable (Length)**

0	Without cable
1	With cable (1.5 m)
2	With cable (3 m)
3	With cable (5 m)

**CE compliant**  
Note) DC specification only

### Option

Symbol	Option	VQ1000	VQ2000
—	None	●	●
B Note 2)	With back pressure check valve	●	●
D	DIN rail mounting	●	●
D0	With DIN rail bracket (Without DIN rail)	●	●
D□ Note 3)	DIN rail length specified (□: Stations 02 to 24)	●	●
G1 Note 4)	1 set of regulator unit	—	—
G2 Note 4)	2 sets of regulator unit	●	—
G3 Note 4)	3 sets of regulator unit	—	—
K Note 5)	Special wiring specifications (Except double wiring)	●	●
N	With name plate	●	●
R Note 6)	External pilot	●	●
S	Direct EXH outlet with built-in silencer	●	●

Note 1) Insert "L" (Top ported) or "B" (Bottom ported) for elbow type.

Example) B6 (Bottom ported elbow with ø6 one-touch fitting)

Note 2) Indicate "LM" for models with elbow fittings and mixed cylinder port sizes.

Note 3) Indicate "Mixed sizes and with port plug" by means of the manifold specification sheet.

Note 4) When selecting the mixed size for different types of piping, dual flow fitting assembly, or double check block (direct mounting), enter "MM" and give instructions in the manifold specification sheet.

Note 5) Inch-size one-touch fittings are available. Refer to "Semi-standard" on page 57 for details.

Note 1) When two or more symbols are specified, indicate them alphabetically.

Example) -BRS

Note 2) Models with a suffix "B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.

Note 3) The number of stations that may be displayed is longer than the manifold number of stations.

Note 4) Specify the mounting position by means of the manifold specification sheet.

Note 5) Specify the wiring specifications by means of the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

## ● Electrical Wiring Specifications

**Flat ribbon cable connector**

Connector terminal no.

Triangle mark indicator position

Electrical wiring specifications

Terminal no.	Polarity
1	(-) (+)
2	(-) (+)
3	(-) (+)
4	(-) (+)
5	(-) (+)
6	(-) (+)
7	(-) (+)
8	(-) (+)
9	(-) (+)
10	(-) (+)
11	(-) (+)
12	(-) (+)
13	(-) (+)
14	(-) (+)
15	(-) (+)
16	(-) (+)
17	(-) (+)
18	(-) (+)
19	(-) (+)
20	(-) (+)
21	(-) (+)
22	(-) (+)
23	(-) (+)
24	(-) (+)
25	(+) (-)
26	(+) (-)

Positive COM spec. Negative COM spec. (Note)

As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 12 stations or less, regardless of valve and option types. Mixed single and double wiring is available as semi-standard. Refer to page 56 for details.

Note) When using the negative common specifications, use valves for negative common. (Refer to page 56.) Refer to "Semi-standard" on page 56 for details.

## How to Order Valves

**VQ 1 1 0 0 - 5 1 - Q**

**Series**

1	VQ1000
2	VQ2000

**Type of actuation**

1	2-position single
2	2-position double
3	3-position closed centre
4	3-position exhaust centre
5	3-position pressure centre
A	4-position dual port (N.C. +N.C.)
B	4-position dual port (N.O. +N.O.)
C	4-position dual port (N.C. +N.O.)

**Seal**

0	Metal seal
1	Rubber seal

**Function**

Symbol	Specifications
—	Standard
B	High-speed response type
K Note 1)	High-pressure type (1.0 MPa)
N Note 2)	Negative common
R Note 2)	External pilot

**Manual override**

—	Non-locking push type (Tool required)
B	Locking type (Tool required)
C	Locking type (Manual)
D	Slide locking type (Manual)

**Light/surge voltage suppressor**

—	Yes
E	None

**Coil voltage**

5	24 VDC
6	12 VDC

Note 1) Metal seal only  
Note 2) Refer to "Semi-standard" on pages 56 to 57 for external pilot and negative common specifications.  
Note 3) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not possible.

## How to Order Manifold Assembly


Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

Flat ribbon cable kit with cable (3 m)  
**VV5Q11-09C6PU2-Q-1** set—Manifold base part no.  
 \*VQ1100-51-Q ..... 2 sets—Valve part no. (Stations 1 to 2)  
 \*VQ1200-51-Q ..... 4 sets—Valve part no. (Stations 3 to 6)  
 \*VQ1300-51-Q ..... 2 sets—Valve part no. (Stations 7 to 8)  
 \*VVQ1000-10A-1-Q ..... 1 set—Blanking plate part no. (Station 9)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D-side. When part nos. written collectively are complicated, specify them by means of the manifold specification sheet.




## ⚠ Caution

Use the standard specification when continuously energizing for long periods of time.

# **P** Series **VQ1000/2000** kit (Flat ribbon cable)


## **VV5Q11**

The dashed lines indicate the DIN rail mounting [-D] and the side entry connection [-PS].



D side Stations -- 1 -- 2 -- 3 -- 4 -- 5 -- 6 -- 7 -- 8 ----- n U side

Applicable connector: Flat ribbon cable connector (26P)  
(Complies with MIL-C-83503)



### **Dimensions**




Formula  $L1 = 10.5n + 44.5$ ,  $L2 = 10.5n + 57.5$  n: Station (Maximum 24 stations)

L \ n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5	223	233.5	244	254.5	265	275.5	286	296.5
L2	78.5	89	99.5	110	120.5	131	141.5	152	162.5	173	183.5	194	204.5	215	225.5	236	246.5	257	267.5	278	288.5	299	309.5
(L3)	112.5	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	225	237.5	250	262.5	275	287.5	287.5	300	312.5	325	337.5
(L4)	123	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	235.5	248	260.5	273	285.5	298	298	310.5	323	335.5	348

With ejector unit: Formula  $L1 = 10.5n + 28.7 + (\text{Number of ejector units} \times 26.7)$   
 $L2 = 10.5n + 41.3 + (\text{Number of ejector units} \times 26.7)$   
 L4 is L2 plus about 30.

# VV5Q21

The dashed lines indicate the DIN rail mounting [-D] and the side entry connection [-PS].



## Dimensions

Formula  $L1 = 16n + 53$ ,  $L2 = 16n + 68$  n: Station (Maximum 24 stations)

n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341	357	373	389	405	421	437
L2	100	116	132	148	164	180	196	212	228	244	260	276	292	308	324	340	356	372	388	404	420	436	452
(L3)	125	150	162.5	175	187.5	212.5	225	237.5	262.5	275	287.5	300	312.5	337.5	350	362.5	387.5	400	412.5	425	450	462.5	475
(L4)	135.5	160.5	173	185.5	198	223	235.5	248	273	285.5	298	310.5	323	348	360.5	373	398	410.5	423	435.5	460.5	473	485.5

# T

# Series VQ1000/2000 kit (Terminal block box)

IP65 compliant

- This kit has a small terminal block inside a junction box. The electrical entry port {VQ1000: G 1/2, VQ2000: G 3/4} permits connection of conduit fittings.
- Maximum stations: 24 (VQ1000), 20 (VQ2000)
- Enclosure: Dust-tight, Water-jet-proof (IP65) compatible (Series VQ2000)

## Manifold Specifications

Series	Piping direction	Piping specifications		Applicable stations
		Port size	Port size	
		1(P), 3(R)	4(A), 2(B)	
VQ1000	Side	C8	C3,C4,C6,M5	Max. 24 stations
VQ2000	Side	C10	C4,C6,C8	Max. 20 stations

## Terminal Block Connection (VQ1000)

Open the terminal block cover to connect the wires to the terminal block.

### Step 1. Removing the terminal block cover

Loosen the screws on the terminal block cover and open it in the direction shown by the arrow. The cover can then be removed from the terminal block.





### Step 2. Wiring

The diagram on the left shows the terminal block wiring schematic. All stations are provided with double solenoid wiring. Insert each lead wire into the terminal opening and tighten the screw directly above.


How to connect is inserting the lead wire into the terminal window, then tighten the screw on the top. (Tightening torque: 0.25 to 0.35 N·m)

### Step 3. Mounting the terminal block cover


Hook groove (a) on shaft (b) and close the cover. Then tighten the screws.



VV5Q11



VV5Q21



The total number of stations is tabulated starting from station one on the D-side.

## Electrical Wiring Specifications: VQ1000

Station	Terminal no.	Polarity
Station 1	SOL_A 1A	(+)
	SOL_B 1B	(-)
Station 2	SOL_A 2A	(+)
	SOL_B 2B	(-)
Station 3	SOL_A 3A	(+)
	SOL_B 3B	(-)
Station 4	SOL_A 4A	(+)
	SOL_B 4B	(-)
Station 5	SOL_A 5A	(+)
	SOL_B 5B	(-)
Station 6	SOL_A 6A	(+)
	SOL_B 6B	(-)
Station 7	SOL_A 7A	(+)
	SOL_B 7B	(-)
Station 8	SOL_A 8A	(+)
	SOL_B 8B	(-)
Station 9	SOL_A 9A	(+)
	SOL_B 9B	(-)
Station 10	SOL_A 10A	(+)
	SOL_B 10B	(-)
Station 11	SOL_A 11A	(+)
	SOL_B 11B	(-)
Station 12	SOL_A 12A	(+)
	SOL_B 12B	(-)
	COM.	(+)

1st row-2nd row-3rd row  
The quantity of terminal blocks used depends on the number of manifold stations:

Manifold	Terminal block
2 to 8 stations	2 rows
9 to 12 stations	3 rows

As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 12 stations or less, regardless of valve and option types. Mixed single and double wiring is available as semi-standard. Refer to page 56 for details.

Note) When using the negative common specifications, use valves for negative common. Refer to "Semi-standard" on page 56 for details.

## How to Order Manifold

VV5Q 1 1-08 C6 T 0 - Q

Series  
1 VQ1000  
2 VQ2000

Manifold  
1 Plug-in unit

Stations  
02 2 stations  
24 24 stations

Cylinder port  
Symbol Port size VQ1000 VQ2000  
C3 With ø3.2 one-touch fitting ● —  
C4 With ø4 one-touch fitting ● ●  
C6 With ø6 one-touch fitting ● ●  
C8 With ø8 one-touch fitting — ●  
M5 M5 thread ● —  
CM Mixed sizes and with port plug ● ●  
MM Mixed size for different types of piping, option installed ● ●

CE/UKCA compliant  
Note) DC specification only

Note 1) VQ2000: Max. 20 stations  
Note 2) Refer to page 56 for details.  
Note) For negative common specifications, refer to "Semi-standard" on page 56.

## Option

Symbol	Option	VQ1000	VQ2000
—	None	●	●
B Note 2)	With back pressure check valve	●	●
D	DIN rail mounting	●	●
D0	With DIN rail bracket (Without DIN rail)	●	●
D□ Note 6)	DIN rail length specified (□: Stations 02 to 24)	●	●
G1 Note 4)	1 set of regulator unit	●	—
G2 Note 4)	2 sets of regulator unit	●	—
G3 Note 4)	3 sets of regulator unit	●	—
K Note 5)	Special wiring spec. (Except double wiring)	●	●
N	With name plate	●	●
R Note 6)	External pilot	●	●
S	Direct EXH outlet with built-in silencer	●	●
W Note 8)	Enclosure: Dust-tight, Water-jet-proof (IP65)	—	●

Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BRS

Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.

Note 3) The number of stations that may be displayed is longer than the manifold number of stations.

Note 4) Specify the mounting position by means of the manifold specification sheet.

Note 5) Specify the wiring specifications by means of the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

Note 7) G1, G2, or G3 cannot be combined with N.

Note 8) When used in combination with the direct EXH outlet with built-in silencer type, keep the exhaust port from coming into direct contact with water or other liquids.



### • Terminal Block Wiring (VQ2000)

Open the terminal block cover to connect the wires to the terminal block.


#### Step 1. Removing the terminal block cover

Loosen mounting screws (4 pcs.) on the terminal block cover and remove the cover.

#### Step 2. Wiring

Loosen screws on the terminal block, connect wiring and complete it by tightening screws. (Tightening torque: 0.5 to 0.7 N·m)

The diagram on the right shows the terminal block wiring. All stations are provided with double wiring regardless of the valves which are mounted.




Applicable crimped terminal:  
1.25-3S, 1.25Y-3,  
1.25Y-3N, 1.25Y-3.5

#### Step 3. Mounting the terminal block cover

Securely tighten the screws after confirming that the gasket is installed correctly. (Tightening torque: 0.7 to 1.2 N·m)

### • Special Wiring Specifications: VQ2000



As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 10 stations or less, regardless of valve and option types. Mixed single and double wiring is available as semi-standard.

Note) When using the negative common specifications, use valves for negative common.

Refer to "Semi-standard" on page 56 for details.

	Terminal no.	Polarity
Station 1	SOL.A 1A	(-)
	SOL.B 1B	(+)
Station 2	SOL.A 2A	(-)
	SOL.B 2B	(+)
Station 3	SOL.A 3A	(-)
	SOL.B 3B	(+)
Station 4	SOL.A 4A	(-)
	SOL.B 4B	(+)
Station 5	SOL.A 5A	(-)
	SOL.B 5B	(+)
Station 6	SOL.A 6A	(-)
	SOL.B 6B	(+)
Station 7	SOL.A 7A	(-)
	SOL.B 7B	(+)
Station 8	SOL.A 8A	(-)
	SOL.B 8B	(+)
Station 9	SOL.A 9A	(-)
	SOL.B 9B	(+)
Station 10	SOL.A 10A	(-)
	SOL.B 10B	(+)
	COM.	(+)

Note)

Positive COM spec. Negative COM spec.

## How to Order Valves

**VQ 1 1 0 0 - 5 - 1 - Q**

**Series**

1	VQ1000
2	VQ2000

**Type of actuation**

1	2-position single
2	2-position double
3	3-position closed centre
4	3-position exhaust centre
5	3-position pressure centre
A	4-position dual port (N.C. +N.C.)
B	4-position dual port (N.O. +N.O.)
C	4-position dual port (N.C. +N.O.)

**Seal**

0	Metal seal
1	Rubber seal

**CE/UKCA compliant**  
Note) DC specification only

**Enclosure**

-	Dust-protected
W Note)	Dust-tight, Water-jet-proof (IP65)

Note) VQ2000 only

**Manual override**

-	Non-locking push type (Tool required)
B	Locking type (Tool required)
C	Locking type (Manual)
D	Slide locking type (Manual)

**Light/surge voltage suppressor**

-	Yes
E	None

**Coil voltage**

5	24 VDC
6	12 VDC

**Function**

Symbol	Specifications
-	Standard
B	High-speed response type
K Note 1)	High-pressure type (1.0 MPa)
N Note 2)	Negative common
R Note 2)	External pilot

**Caution**  
Use the standard specification when continuously energizing for long periods of time.

## How to Order Manifold Assembly

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

Terminal block box kit

VV5Q11-08C6T0-Q...1 set-Manifold base part no.

\*VQ1100-51-Q...2 sets-Valve part no. (Stations 1 to 2)


\*VQ1200-51-Q...4 sets-Valve part no. (Stations 3 to 6)

\*VQ1300-51-Q...1 set-Valve part no. (Station 7)

\*VVQ1000-10A-1...1 set-Blanking plate part no. (Station 8)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D-side. When part nos. written collectively are complicated, specify them by means of the manifold specification sheet.



Note 1) Metal seal only

Note 2) Refer to "Semi-standard" on pages 56 to 57 for external pilot and negative common specifications.

Note 3) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not possible.

# VV5Q11

**DIN rail clamp screw**

G 1/2

C8 [3(R) EXH port]  
C8: ø8 one-touch fitting


(12)  
7.7  
18.7  
(7.5)

P = 10.5  
31.5  
9.3  
25  
61.5  
40.7

C3, C4, C6, M5 [4(A), 2(B) port]

- C3: ø3.2 one-touch fitting
- C4: ø4 one-touch fitting
- C6: ø6 one-touch fitting
- M5: M5 thread

C8 [1(P) SUP port]  
C8: ø8 one-touch fitting




L \ n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
<b>L1</b>	66.5	77	87.5	98	108.5	119	129.5	140	150.5	161	171.5	182	192.5	203	213.5	224	234.5	245	255.5	266	276.5	287	297.5
<b>L2</b>	126	136.5	147	157.5	168	178.5	189	199.5	210	220.5	231	241.5	252	262.5	273	283.5	294	304.5	315	325.5	336	346.5	357
<b>(L3)</b>	150	162.5	175	187.5	198.5	200	212.5	225	237.5	250	262.5	275	287.5	300	312.5	324	335	345	357.5	370	382.5	395	407.5
<b>(L4)</b>	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423




# VV5Q21

The dashed lines indicate DIN rail mounting [-D] (with DIN rail mounting bracket).



D side Stations -- 1 -- 2 -- 3 -- 4 -- 5 -- 6 -- 7 -- 8 -- n U side



## Dimensions

Formula L1 = 16n + 118.5, L2 = 16n + 131 n: Station (Maximum 20 stations)

L	n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1		150.5	166.5	182.5	198.5	214.5	230.5	246.5	262.5	278.5	294.5	310.5	326.5	342.5	358.5	374.5	390.5	406.5	422.5	438.5
L2		163	179	195	211	227	243	259	275	291	307	323	339	355	371	387	403	419	435	451
(L3)		187.5	200	225	237.5	250	262.5	287.5	300	312.5	337.5	350	362.5	375	400	412.5	425	450	462.5	475
(L4)		198	210.5	235.5	248	260.5	273	298	310.5	323	348	360.5	373	385.5	410.5	423	435.5	460.5	473	485.5


# L Series VQ1000/2000 kit (Lead wire)

IP65 compliant

- Direct electrical entry. Models with one or more stations are available.
- (SUP) and (EXH) ports are provided on one side for further space savings.
- Maximum stations are 8.
- Enclosure: Dust-tight, Water-jet-proof (IP65) compatible (Series VQ2000)

## Wiring Specifications: Positive COM ●

Three lead wires are attached to each station regardless of the type of valve which is mounted.  
The red wire is for COM connection.




Use any of the below cable lead wire assembly to change the lead wire length:

### Lead wire assembly with connector


Lead wire length	Part no.
0.6 m	VVQ1000-84A-6-*
1.5 m	VVQ1000-84A-15-*
3 m	VVQ1000-84A-30-*

\* Station number 1 to 8




## Manifold Specifications

Series	Piping specifications			Applicable stations
	Piping direction	Port size		
		1(P), 3(R)	4(A), 2(B)	
VQ1000	Side	C8	C3, C4, C6, M5	Max. 8 stations
VQ2000	Side	C10	C6, C8	Max. 8 stations



The total number of stations is tabulated on the D-side.

## How to Order Manifold




Note) For negative common specifications, refer to "Semi-standard" on page 56.

- Note 1) Insert "L" (Top ported) or "B" (Bottom ported) for elbow type.  
Example) B6 (Bottom ported elbow with ø6 one-touch fitting)
- Note 2) Indicate "LM" for models with elbow fittings and mixed cylinder port sizes.
- Note 3) Indicate "Mixed sizes and with port plug" by means of the manifold specification sheet.
- Note 4) When selecting the mixed size for different types of piping, dual flow fitting assembly, or double check block (direct mounting), enter "MM" and give instructions in the manifold specification sheet.
- Note 5) Inch-size one-touch fittings are available. Refer to "Semi-standard" on page 57 for details.

### Option



Symbol	Option	VQ1000	VQ2000
—	None	●	●
B	With back pressure check valve	●	●
D	DIN rail mounting	●	●
D0	With DIN rail bracket (Without DIN rail)	●	●
D□	DIN rail length specified (□: Stations 02 to 24)	●	●
G1	1 set of regulator unit	●	—
G2	2 sets of regulator unit	●	—
G3	3 sets of regulator unit	●	—
N	With name plate	●	●
R	External pilot	●	●
S	Direct EXH outlet with built-in silencer	●	●
W	Enclosure: Dust-tight, Water-jet-proof (IP65)	—	●

- Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BRS
- Note 2) Models with a suffix "B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.
- Note 3) The number of stations that may be displayed is longer than the manifold number of stations.
- Note 4) Specify the mounting position by means of the manifold specification sheet.
- Note 5) Indicate "R" for the valve with external pilot.
- Note 6) G1, G2, or G3 cannot be combined with N.
- Note 7) When used in combination with the direct EXH outlet with built-in silencer type, keep the exhaust port from coming into direct contact with water or other liquids.



### • Wiring Specifications: Negative COM (Semi-standard)

Three lead wires are attached to each station regardless of the type of valve which is mounted.  
The black wire is for COM connection.



#### Lead wire assembly with connector

Lead wire length	Part no.
0.6 m	VVQ1000-84AN-6-*
1.5 m	VVQ1000-84AN-15-*
3 m	VVQ1000-84AN-30-*

\* Station number 1 to 8

Note) When using the negative common specifications, use valves for negative common. For negative common specifications, refer to "Semi-standard" on page 56.

## How to Order Valves

**VQ 1 1 0 0 - 5 - - - 1 - Q**

**Series**

1	VQ1000
2	VQ2000

**Seal**

0	Metal seal
1	Rubber seal

**Type of actuation**

1	2-position single
2	2-position double
3	3-position closed centre
4	3-position exhaust centre
5	3-position pressure centre
A	4-position dual port (N.C. +N.C.)
B	4-position dual port (N.O. +N.O.)
C	4-position dual port (N.C. +N.O.)

**Function**

Symbol	Specifications
—	Standard
B	High-speed response type
K <sup>Note 1)</sup>	High-pressure type (1.0 MPa)
N <sup>Note 2)</sup>	Negative common
R <sup>Note 2)</sup>	External pilot

**Enclosure**

—	Dust-protected
W <sup>Note)</sup>	Dust-tight, Water-jet-proof (IP65)

Note) VQ2000 only

**Manual override**

—	Non-locking push type (Tool required)
B	Locking type (Tool required)
C	Locking type (Manual)
D	Slide locking type (Manual)

**Light/surge voltage suppressor**

—	Yes
E	None

**Coil voltage**

5	24 VDC
6	12 VDC

**CE/UKCA compliant**  
Note) DC specification only

Note 1) Metal seal only

Note 2) For external pilot and negative common specifications, refer to "Semi-standard" on pages 56 to 57.

Note 3) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not possible.

## How to Order Manifold Assembly

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

Lead wire kit with cable (3 m)

VV5Q11-06C6L2-Q...1 set—Manifold base part no.

\*VQ1100-51-Q...2 sets—Valve part no. (Stations 1 to 2)


\*VQ1200-51-Q...2 sets—Valve part no. (Stations 3 to 4)

\*VQ1300-51-Q...1 set—Valve part no. (Station 5)

\*VVQ1000-10A-1...1 set—Blanking plate part no. (Station 6)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D-side. When part nos. written collectively are complicated, specify them by means of the manifold specification sheet.



## ⚠ Caution


Use the standard specification when continuously energizing for long periods of time.




# L Series VQ1000/2000kit (Lead wire)

## VV5Q11

The dashed lines indicate DIN rail mounting [-D] (with DIN rail mounting bracket).



D side      Stations -- 1 -- 2 -- 3 -- 4 -- 5 -- 6 -- 7 -- n      U side



### Dimensions


Formula  $L1 = 10.5n + 28.5$ ,  $L2 = 10.5n + 38$   
n: Station (Maximum 8 stations)

L	n	1	2	3	4	5	6	7	8
L1	39	49.5	60	70.5	81	91.5	102	112.5	122
L2	48.5	59	69.5	80	90.5	101	111.5	122	132
(L3)	75	87.5	100	112.5	125	137.5	150	162.5	175
(L4)	85.5	98	110.5	123	135.5	148	160.5	173	185.5



With ejector unit: Formula  $L1 = 10.5n + 28.5 + (\text{Number of ejector units} \times 26.7)$   
 $L2 = 10.5n + 38 + (\text{Number of ejector units} \times 26.7)$   
 L4 is L2 plus about 30.

# VV5Q21

The dashed lines indicate DIN rail mounting [-D] (with DIN rail mounting bracket).



D side Stations --- 1 --- 2 --- 3 --- 4 --- 5 --- 6 --- n U side



**Dust-tight, Water-jet-proof**

## Dimensions

Formula L1 = 16n + 35, L2 = 16n + 47  
n: Station (Maximum 8 stations)

L	n	1	2	3	4	5	6	7	8
L1	51	67	83	99	115	131	147	163	
L2	63	79	95	111	127	143	159	175	
(L3)	87.5	100	125	137.5	150	162.5	184.5	200	
(L4)	98	110.5	135.5	148	160.5	173	198	210.5	

S

# Series VQ1000/2000

kit (Serial transmission) Base mounted plug-in manifold: For EX510 Gateway-type serial transmission system

The EX510 series is to be discontinued. When designing new equipment and facilities, consider using another series (EX260/EX600) instead.

## How to Order Manifold

VV5Q 1 1 - SB 08 - - Q

Manifold series

1	VQ1000
2	VQ2000

SI unit specifications

—	NPN output (+COM.)
N	PNP output (−COM.)

Valve stations

Symbol	Stations
01	1 station
⋮	⋮
08	8 stations

Note) Max. 16 stations.  
(Special wiring specifications)

SI unit part no.

Symbol	SI unit specifications	SI unit part no.
—	NPN output (+COM.)	EX510-S002A
N	PNP output (−COM.)	EX510-S102A

Cylinder port

Symbol	Port size	VQ1000	VQ2000
<b>C3</b>	With ø3.2 one-touch fitting	○	—
<b>C4</b>	With ø4 one-touch fitting	○	○
<b>C6</b>	With ø6 one-touch fitting	○	○
<b>C8</b>	With ø8 one-touch fitting	—	○
<b>M5</b>	M5 thread	○	—
<b>CM</b> Note 1)	With mixed sizes and with port plug	○	○
<b>L3</b>	Top ported elbow with ø3.2 one-touch fitting	○	—
<b>L4</b>	Top ported elbow with ø4 one-touch fitting	○	○
<b>L6</b>	Top ported elbow with ø6 one-touch fitting	○	○
<b>L8</b>	Top ported elbow with ø8 one-touch fitting	—	○
<b>L5</b>	Top ported elbow M5 thread	○	—
<b>B3</b>	Bottom ported elbow with ø3.2 one-touch fitting	○	—
<b>B4</b>	Bottom ported elbow with ø4 one-touch fitting	○	○
<b>B6</b>	Bottom ported elbow with ø6 one-touch fitting	○	○
<b>B8</b>	Bottom ported elbow with ø8 one-touch fitting	—	○
<b>B5</b>	Bottom ported elbow M5 thread	○	—
<b>LM</b> Note 1)	Elbow port, mixed sizes	○	○
<b>N1</b>	ø1/8" with one-touch fitting	○	—
<b>N3</b>	ø5/32" with one-touch fitting	○	○
<b>N7</b>	ø1/4" with one-touch fitting	○	○
<b>N9</b>	ø5/16" with one-touch fitting	—	○
<b>M5T</b>	UNF10-32 thread	○	—
<b>NM</b> Note 1)	With mixed sizes and with port plug	○	○
<b>LN1</b>	Top ported elbow with ø1/8" one-touch fitting	○	—
<b>LN3</b>	Top ported elbow with ø5/32" one-touch fitting	○	○
<b>LN7</b>	Top ported elbow with ø1/4" one-touch fitting	○	○
<b>LN9</b>	Top ported elbow with ø5/16" one-touch fitting	—	○
<b>L5T</b>	Top ported elbow UNF10-32 thread	○	—
<b>BN1</b>	Bottom ported elbow with ø1/8" one-touch fitting	○	—
<b>BN3</b>	Bottom ported elbow with ø5/32" one-touch fitting	○	○
<b>BN7</b>	Bottom ported elbow with ø1/4" one-touch fitting	○	○
<b>BN9</b>	Bottom ported elbow with ø5/16" one-touch fitting	—	○
<b>B5T</b>	Bottom ported elbow UNF10-32 thread	○	—
<b>LM</b> Note 1)	Elbow port, mixed sizes	○	○
<b>MM</b> Note 2)	Mixed size for different types of piping, option installed	○	○

Note 1) Indicate "Mixed sizes and with port plug" in the manifold specification sheet.

Note 2) When selecting the mixed size for different types of piping, dual flow fitting assembly, or double check block (direct mounting), enter "MM" and give instructions in the manifold specification sheet.

Refer to Best Pneumatics No. ① for details on EX510 gateway-type serial transmission system.

Option

Symbol	Option
—	None
<b>B</b> Note 2)	With back pressure check valve
<b>D</b> Note 8)	DIN rail mounting
<b>D</b> □ Note 7)	DIN rail length specified (□: Stations 02 to 16)
<b>G1</b> Note 3) Note 6)	1 set of regulator unit
<b>G2</b> Note 3) Note 6)	2 sets of regulator unit
<b>G3</b> Note 3) Note 6)	3 sets of regulator unit
<b>K</b> Note 4)	Special wiring spec. (Except double wiring)
<b>N</b>	With name plate
<b>R</b> Note 5)	with external pilot
<b>S</b>	Direct EXH outlet with built-in silencer



Note 1) When two or more symbols are specified, indicate them alphabetically.  
Example) -BRS



Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.

Note 3) Specify the mounting position by means of the manifold specification sheet.

Note 4) Specify the wiring specifications by means of the manifold specification sheet.

Note 5) Indicate "R" for the valve with external pilot.


Note 6) VQ1000 only

Note 7) The number of stations that may be displayed is longer than the manifold number of stations.

Note 8) Need to be chosen with "D" or "D□".

## How to Order Manifold Assembly

### Example



VV5Q11-SB08C6-D-Q... 1 set (SB kit, 8-station manifold part no.)

\*VQ1100-51-Q..... 4 sets (Single type part no.)

\*VQ1200-51-Q..... 3 sets (Double type part no.)

\*VQ1300-51-Q..... 1 set (3 position type part no.)

→ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

→ Enter in order starting from the first station on the D-side.

Add the valve and option part numbers under the manifold base part number. In the case of complex arrangement, specify them by means of the manifold specification sheet.










## How to Order Valves

VQ 1 1 0 0   - 5   1 - Q

## Series

1	VQ1000
2	VQ2000

## Type of actuation


1	2-position single 
2	Metal 2-position double 
	Rubber 2-position double 
3	3-position closed centre 
4	3-position exhaust centre 
5	3-position pressure centre 
A Note)	4-position dual 3-port valve (A) 
B Note)	4-position dual 3-port valve (B) 
C Note)	4-position dual 3-port valve (C) 




Note) Rubber seal only

## Manual override


Nil: Non-locking push type (Tool required)




B: Locking type (Tool required)



C: Locking type (Manual)



D: Slide locking type (Manual)



## Rated voltage

5 24 VDC

## Function

Symbol	Specifications
—	Standard (0.4 W)
B	High-speed response type (0.95 W)
K Note 1)	High-pressure type (1.0 MPa) [0.95 W]
N Note 2)	Negative common
R Note 2)	External pilot

Note 1) Metal seal only


Note 2) For external pilot and negative common specifications, refer to "Semi-standard" on pages 56 to 57.

Note 3) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not possible.


## Seal

0	Metal seal
1	Rubber seal

## VV5Q11



Applicable connector:  
Flat ribbon cable connector (20P)  
(Complies with MIL-C-83503)



### Dimensions

Formula  $L1 = 10.5n + 44.5$ ,  $L2 = 10.5n + 91$  n: Station (Maximum 16 stations)

L \ n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	55	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5
L2	101.5	112	122.5	133	143.5	154	164.5	175	185.5	196	206.5	217	227.5	238	248.5	259
L3	125	137.5	150	162.5	175	175	187.5	200	212.5	225	237.5	237.5	250	262.5	275	287.5
L4	135.5	148	160.5	173	185.5	185.5	198	210.5	223	235.5	248	248	260.5	273	285.5	298






## IP65 compliant

- The serial transmission system reduces wiring work, while minimizing wiring and saving space.
- Enclosure: Dust-tight, Water-jet-proof (IP65) compatible (Series VQ2000)

## Manifold Specifications

Series	Piping specifications			Applicable stations
	Piping direction	Port size		
		1(P), 3(R)	4(A), 2(B)	
VQ1000	Side	C8	C3, C4, C6, M5	Max. 16 stations
VQ2000	Side	C10	C4, C6, C8	Max. 16 stations

## How to Order Manifold



## Cylinder port

Symbol	Port size	VQ1000	VQ2000
C3	With ø3.2 One-touch fitting	●	—
C4	With ø4 One-touch fitting	●	●
C6	With ø6 One-touch fitting	●	●
C8	With ø8 One-touch fitting	—	●
M5	M5 thread	●	—
CM	Mixed sizes and with port plug	●	●
MM	Mixed size for different types of piping, option installed	●	●

- Note 1) Insert "L" (Top ported) or "B" (Bottom ported) for elbow type.  
Example) B6 (Bottom ported elbow with ø6 One-touch fitting)
- Note 2) Indicate as "LM" (Including upward, downward piping and mixed) for models with elbow fittings and mixed cylinder port sizes.
- Note 3) Indicate "Mixed sizes and with port plug" by means of the manifold specification sheet.
- Note 4) When selecting the mixed size for different types of piping, dual flow fitting assembly, or double check block (direct mounting), enter "MM" and give instructions in the manifold specification sheet.
- Note 5) Inch-size One-touch fittings are available. Refer to "Semi-standard" on page 57 for details.

## SI Unit Part No. (Without option W)

Symbol	Protocol	SI unit part no.
Q	DeviceNet® (16 outputs)	Standard: EX120-SDN1 Dust-protected: No part no.
V	CC-LINK (16 outputs)	Standard: EX120-SMJ1
ZB	CompoNet® (16 outputs) (Positive common)	Standard: EX120-SCM1 Dust-protected: No part no.
ZBN	CompoNet® (16 outputs) (Negative common)	Standard: EX120-SCM3 Dust-protected: No part no.


## SI Unit Part No. (With option W)

Symbol	Protocol	SI unit part no.
Q	DeviceNet® System (16 outputs)	EX124D-SDN1
V	CC-LINK (16 outputs)	EX124D-SMJ1

Symbol	Option	VQ1000	VQ2000
—	None	●	●
B	With back pressure check valve	●	●
D	DIN rail mounting	●	●
D0	With DIN rail bracket (Without DIN rail)	●	●
D□	DIN rail mounting (□: Stations 02 to 24)	●	●
G1	1 set of regulator unit	●	—
G2	2 sets of regulator unit	●	—
G3	3 sets of regulator unit	●	—
K	Special wiring specifications (Except double wiring)	●	●
N	With name plate	●	●
R	With external pilot	●	●
S	Direct EXH outlet with built-in silencer	●	●
W	Enclosure: Dust-tight, Water-jet-proof (IP65)	—	●

- Note 1) When two or more symbols are specified, indicate them alphabetically.  
Example) -BRS.
- Note 2) Models with a suffix "B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.
- Note 3) The number of stations that may be displayed is longer than the manifold number of stations.
- Note 4) Specify the mounting position by means of the manifold specification sheet.
- Note 5) Specify the wiring specifications by means of the manifold specification sheet.
- Note 6) Indicate "R" for the valve with external pilot.
- Note 7) Refer to "Dimensions" on page 48 for SI unit and valve, in case of W (Dust-tight, Water-jet-proof).
- Note 8) G1, G2, or G3 cannot be combined with N.
- Note 9) When used in combination with the direct EXH outlet with built-in silencer type, keep the exhaust port from coming into direct contact with water or other liquids.

Refer to the **Web Catalogue** and the Operation Manual for the details of EX120/124 Integrated-type (for Output) Serial Transmission System. Please download the Operation Manual via our website, <https://www.smc.eu>



## How to Order Valves

**VQ 1 1 0 0 - 5 - 1 - Q**

**Series**

1	VQ1000
2	VQ2000

**Type of actuation**

1	2-position single
2	2-position double
3	3-position closed centre
4	3-position exhaust centre
5	3-position pressure centre
A	4-position dual port (N.C. +N.C.)
B	4-position dual port (N.O. +N.O.)
C	4-position dual port (N.C. +N.O.)

**Seal**

0	Metal seal
1	Rubber seal

**Enclosure**

—	Dust-protected
W (Note)	Dust-tight, Water-jet-proof (IP65)

Note) VQ2000 only

**Manual override**

—	Non-locking push type (Tool required)
B	Locking type (Tool required)
C	Locking type (Manual)
D	Slide locking type (Manual)

**Coil voltage**

5	24 VDC; With indicator light/ surge voltage suppressor
---	--

**Function**

Symbol	Specifications
—	Standard
B	High-speed response type
K (Note 1)	High-pressure type (1.0 MPa)
N (Note 2)	Negative common
R (Note 2)	External pilot

Note 1) Metal seal only  
Note 2) For external pilot and negative common specifications, refer to "Semi-standard" on pages 56 to 57.  
Note 4) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not possible.

## How to Order Manifold Assembly


Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

**VV5Q11-08C6SV-Q** : 1 set—Manifold base part no.  
 \*VQ1100-51-Q ..... 2 sets—Valve part no. (Stations 1 to 2)  
 \*VQ1200-51-Q ..... 4 sets—Valve part no. (Stations 3 to 6)  
 \*VQ1300-51-Q ..... 1 set—Valve part no. (Station 7)  
 \*VVQ1000-10A-1 ..... 1 set—Blanking plate part no. (Station 8)


Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D-side. When part nos. written collectively are complicated, specify them by means of the manifold specification sheet.



### VV5Q11

The dashed lines indicate DIN rail mounting [-D] (with DIN rail mounting bracket).



With ejector unit: Formula

L1 = 10.5n + 28.7 + (Number of ejector units x 26.7)

L2 = 10.5n + 56.3 + (Number of ejector units x 26.7)

L4 is L2 plus about 30.

Dust-protected SI unit: L5 = 10.5n + 97, L6 = L3 + 25, L7 = L4 + 25

Formula L1 = 10.5n + 44.5, L2 = 10.5n + 72.5 n: Station (Maximum 16 stations)


### Dimensions

L	n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
<b>L1</b>		65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5
<b>L2</b>		93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5	230	240.5
<b>(L3)</b>		125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5
<b>(L4)</b>		135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273





# M Series VQ2000 kit (Circular connector)



VQ2000 only

VV5Q21

- MIL flat cable connector reduces installation labour for electrical connection.
- Manifold and connectors, both compliant with the IP65 rating (Dust-tight, Water-jet-proof), provide a high-degree of protection for the electrical parts.
- Maximum stations are 24.

## Manifold Specifications


Series	Piping specifications		Applicable stations
	Piping direction	Port size	
		1(P), 3(R)	4(A), 2(B)
VQ2000	Side	C10	C4, C6, M8
			Max. 24 stations

## Circular Connector (26 Pins)

## Cable Assembly ●

015  
AXT100-MC26-030  
050

(Circular connector cable assembly included in a specific manifold model no.)  
(Refer to "How to Order Manifold.")



### Circular connector cable assembly

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-MC26-015	Cable 25-core x 24AWG
3 m	AXT100-MC26-030	
5 m	AXT100-MC26-050	

### Electrical characteristics

Item	Property
Conductor resistance /km, 20C	65 or less
Voltage limit V, 1 min, AC	1000
Insulation resistance M/km, 20C	5 or more

Note) The minimum bending radius of the circular connector cable is 20 mm.

### Circular connector cable assembly terminal no.

Terminal no.	Lead wire colour	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Grey	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Grey	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Grey	Red
24	Black	White
25	White	None
26	White	None

Note) Lengths other than the above are also available. Please contact SMC for details.

## How to Order Manifold

VV5Q 2 1 - 08 C6 M 1 - N - Q

Series 2 VQ2000

Manifold 1 Plug-in unit

Option ● CE/UKCA compliant  
Note) DC specification only

Stations 02 2 stations  
24 24 stations

Symbol	Port size
C4	With ø4 one-touch fitting
C6	With ø6 one-touch fitting
C8	With ø8 one-touch fitting
CM Note 3)	Mixed sizes and with port plug
MM Note 4)	Mixed size for different types of piping, option installed

Note) Refer to page 56 for details.

### Cylinder port

Symbol	Port size
C4	With ø4 one-touch fitting
C6	With ø6 one-touch fitting
C8	With ø8 one-touch fitting
CM Note 3)	Mixed sizes and with port plug
MM Note 4)	Mixed size for different types of piping, option installed

- Note 1) Insert "L" (Top ported) or "B" (Bottom ported) for elbow type.  
Example) B6 (Bottom ported elbow with ø6 one-touch fitting)
- Note 2) Indicate "LM" for models with elbow fittings and mixed cylinder port sizes.
- Note 3) Indicate "Mixed sizes and with port plug" by means of the manifold specification sheet.
- Note 4) When selecting the mixed size for different types of piping, dual flow fitting assembly, or double check block (direct mounting), enter "MM" and give instructions in the manifold specification sheet.
- Note 5) Inch-size one-touch fittings are available. Refer to "Semi-standard" on page 57 for details.


### Cable (Length)

Symbol	Option
0	Without cable
1	With cable (1.5 m)
2	With cable (3 m)
3	With cable (5 m)

### Option

Symbol	Option
—	None
B Note 2)	With back pressure check valve
D	DIN rail mounting
D0	With DIN rail bracket (Without DIN rail)
D□ Note 3)	DIN rail mounting (□: Stations 02 to 24)
K Note 4)	Special wiring spec. (Except double wiring)
N	With name plate
R Note 5)	External pilot
S	Direct EXH outlet with built-in silencer
W Note 6)	Enclosure: Dust-tight, Water-jet-proof (IP65)


- Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BKR
- Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. When a back pressure check valve is desired, and is to be installed only in certain manifold stations, specify the mounting position by means of the manifold specification sheet.
- Note 3) The number of stations that may be displayed is longer than the manifold number of stations.
- Note 4) Specify the wiring specifications by means of the manifold specification sheet.
- Note 5) Indicate "R" for the valve with external pilot.
- Note 6) When used in combination with the direct EXH outlet with built-in silencer type, keep the exhaust port from coming into direct contact with water or other liquids.



VV5Q21

The total number of stations is tabulated starting from station one on the D-side.

### Electrical Wiring Specifications



As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 12 stations or less, regardless of valve and option types. Mixed single and double wiring is available as semi-standard. Refer to page 56 for details.



Note) When using the negative common specifications, use valves for negative common. (Refer to page 56.) Refer to "Semi-standard" on page 56 for details.

### Circular connector cable assembly 015 AXT100-MC26-030 Wire colour 050

	Terminal no.	Polarity	Lead wire colour	Dot marking	
Station 1	SOLA 1	(-)	(+)	Black	None
	SOLB 2	(-)	(+)	Brown	None
Station 2	SOLA 3	(-)	(+)	Red	None
	SOLB 4	(-)	(+)	Orange	None
Station 3	SOLA 5	(-)	(+)	Yellow	None
	SOLB 6	(-)	(+)	Pink	None
Station 4	SOLA 7	(-)	(+)	Blue	None
	SOLB 8	(-)	(+)	Purple	White
Station 5	SOLA 9	(-)	(+)	Grey	Black
	SOLB 10	(-)	(+)	White	Black
Station 6	SOLA 11	(-)	(+)	White	Red
	SOLB 12	(-)	(+)	Yellow	Red
Station 7	SOLA 13	(-)	(+)	Orange	Red
	SOLB 14	(-)	(+)	Yellow	Black
Station 8	SOLA 15	(-)	(+)	Pink	Black
	SOLB 16	(-)	(+)	Blue	White
Station 9	SOLA 17	(-)	(+)	Purple	None
	SOLB 18	(-)	(+)	Grey	None
Station 10	SOLA 19	(-)	(+)	Orange	Black
	SOLB 20	(-)	(+)	Red	White
Station 11	SOLA 21	(-)	(+)	Brown	White
	SOLB 22	(-)	(+)	Pink	Red
Station 12	SOLA 23	(-)	(+)	Grey	Red
	SOLB 24	(-)	(+)	Black	White
(Max.)	COM. 25	(+)	Note) (-)	White	None
	COM. 26	(+)	(-)	White	None

Positive COM spec. Negative COM spec.

### How to Order Valves

**VQ 2 1 0 0 - 5 - W 1 - Q**

**Series**  
2 VQ2000

**Type of actuation**

1	2-position single
2	2-position double
3	3-position closed centre
4	3-position exhaust centre
5	3-position pressure centre
A	4-position dual port (N.C. +N.C.)
B	4-position dual port (N.O. +N.O.)
C	4-position dual port (N.C. +N.O.)

**Seal**

0	Metal seal
1	Rubber seal

**Function**

Symbol	Specifications
—	Standard
B	High-speed response type
K Note 1)	High-pressure type (1.0 MPa)
N Note 2)	Negative common
R Note 2)	External pilot

Note 1) Metal seal only  
Note 2) For external pilot and negative common specifications, refer to "Semi-standard" on pages 56 to 57.  
Note 3) When two or more symbols are specified, indicate them alphabetically. Combination of [B] and [K] is not possible.

**CE/UKCA compliant**  
Note) DC specification only

**Enclosure IP65 (Dust-tight, Water-jet-proof)**

**Manual override**

—	Non-locking push type (Tool required)
B	Locking type (Tool required)
C	Locking type (Manual)
D	Slide locking type (Manual)

**Light/surge voltage suppressor**

—	Yes
E	None

**Coil voltage**

5	24 VDC
6	12 VDC

### How to Order Manifold Assembly


Specify the part numbers for valves and options together beneath the manifold base part number.

#### <Example>

Circular connector kit with cable (3 m)  
VV5Q21-09C6M2-W-Q · 1 set—Manifold base part no.  
\*VQ2100-51-Q ····· 3 sets—Valve part no. (Stations 1 to 3)  
\*VQ2200-51-Q ····· 3 sets—Valve part no. (Stations 4 to 6)  
\*VQ2300-51-Q ····· 2 sets—Valve part no. (Stations 7 to 8)  
\*VVQ2000-10A-1 ··· 1 set—Blanking plate part no. (Station 9)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D-side. When part nos. written collectively are complicated, specify them by means of the manifold specification sheet.




### Caution


Use the standard specification when continuously energizing for long periods of time.

### VV5Q21

The dashed lines and dimensions in parentheses indicate DIN rail mounting [-D].



D side Stations -- 1 -- 2 -- 3 -- 4 -- 5 -- 6 -- 7 -- 8 -- n U side



Made by CONINVERS GmbH  
HC-26P1NRAWF00

#### Dimensions

Formula  $L1 = 16n + 77.5$ ,  $L2 = 16n + 100.5$  n: Station (Maximum 12 stations)

L \ n	2	3	4	5	6	7	8	9	10	11	12
L1	109.5	125.5	141.5	157.5	173.5	189.5	205.5	221.5	237.5	253.5	269.5
L2	132.5	148.5	164.5	180.5	196.5	212.5	228.5	244.5	260.5	276.5	292.5
(L3)	162.5	175	187.5	200	225	237.5	250	275	287.5	300	312.5
(L4)	173	185.5	198	210.5	235.5	248	260.5	285.5	298	310.5	323

# Sub-plate Single Unit


VQ2000 Only

# Series VQ2000

## How to Order

IP65 enclosure in  
standard specifications

Easy-to-use terminal block



In the case of **Valve** + **Sub-plate**

VQ2 **1** **0** **0** - **5** **W** **1** - **02** **Q**

Entry is the same as  
standard products.

Enclosure

—	Dust-protected
<b>W</b> Note 1)	IP65 (Dust-tight, Water-jet-proof)

Note 1) Valves are IP65 specifications.

• CE/UKCA compliant  
Note) DC specification  
only

• Thread type

—	Rc
<b>N</b>	NPT
<b>T</b>	NPTF
<b>F</b>	G


In the case of **Sub-plate** alone

• Port size

<b>02</b>	1/4
-----------	-----

VQ2000 - PW - 02

## Dimensions




Note) When using this valve for IP65, mount a seal connector to the electrical entry.

## Semi-standard

### Different Number of Connector Pins

F and P kits with the following number of pins are available besides the standard number (F = 25P; P = 26P). Select the desired number of pins and cable length from the cable assembly list. Place an order for the cable assembly separately.

#### F kit (D-sub connector) 15 pins



#### How to Order Manifold

VV5Q11-06 C6 F SA - Q

Stations

Cylinder port

Option


#### How to Order

D-sub connector, 15 pins  
Connector location-Side  
Without cable

#### Kit type/Electrical entry

Pins	Location	Top entry		Side entry	
15P (Max. 7 stations)		F kit	UA	F kit	SA

Note) In the same way as the 25-pin models (standard), the terminal no. 1 is for SOL.A at the 1st station, the terminal no. 9 for SOL.B at the 1st station, and the terminal no. 8 for COM.



#### Wire Colour Table by Terminal No. of D-sub Connector Cable Assembly


Terminal no.	Lead wire colour	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Grey	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black

#### D-sub Connector Cable Assembly

Cable length (L)	Pins	15P
1.5 m		AXT100-DS15-1
3 m		AXT100-DS15-2
5 m		AXT100-DS15-3

Note) For other commercial connectors, use a type conforming to MIL-C-24308.

#### P kit (Flat ribbon cable) 10/16/20 pins



#### How to Order Manifold

VV5Q11-06 C6 P SC - Q

Stations

Cylinder port

Option


#### How to Order

Flat ribbon cable, 20 pins  
Connector location-Side  
Without cable

#### Kit type/Electrical entry

Pins	Location	Top entry		Side entry	
10P (Max. 4 stations)		P kit	UA	P kit	SA
16P (Max. 7 stations)			UB		SB
20P (Max. 9 stations)			UC		SC

Note) In the same way as the 26-pin models (standard), the terminal no. 1 is for SOL.A at the 1st station, the terminal no. 2 for SOL.B at the 1st station, and two pins from the max. terminal numbers are for COM.



#### Flat Ribbon Cable Assembly

Cable length (L)	Pins	10P	16P	20P
1.5 m		AXT100-FC10-1	AXT100-FC16-1	AXT100-FC20-1
3 m		AXT100-FC10-2	AXT100-FC16-2	AXT100-FC20-2
5 m		AXT100-FC10-3	AXT100-FC16-3	AXT100-FC20-3
Connector width (W)		17.2	24.8	30

Note) For other commercial connectors, use a type with strain relief conforming to MIL-C-83503.



## Special Wiring Specifications

In the internal wiring of F/P/J/G/T/S kit, double wiring (connected to SOL. A and SOL. B) is adopted for each station regardless of the valve and option types. Mixed single and double wiring is available as an option.

### 1. How to Order


Indicate an option symbol “-K”, for the manifold no. and be sure to specify the mounting position and number of stations of the single and double wiring by means of the manifold specification sheet.

**Example) VV5Q11-08C6FU1-D K S-Q**

Others, option symbols:  
to be indicated alphabetically.

### 2. Wiring specifications

With the A side solenoid of the 1st station as no.1 (meaning, to be connected to no.1 terminal), without making any terminals vacant.



### 3. Max. number of stations

The maximum number of stations depends upon the number of solenoids. Assuming one for a single and two for a double, determine the number of stations so that the total number is not more than the max. number given in the following table.

Kit	F kit (D-sub connector)	P kit (Flat ribbon cable)	J kit (Flat ribbon cable)	G kit (Flat ribbon cable with terminal block)
Type	F <sub>S</sub> <sup>U</sup> □ 25P	F <sub>S</sub> <sup>U</sup> □ 15P	P <sub>S</sub> <sup>U</sup> □ 26P	P <sub>S</sub> <sup>U</sup> □ 20P
Max. points	24	14	24	18

Kit	T kit (Terminal block box)	S kit (Serial transmission)	M kit (Circular connector)
Type	2 rows of terminal blocks 16	3 rows of terminal blocks 24	S□
Max. points	20	16	24

## Negative Common Specifications

Specify the valve model no. as shown below for negative common specification.

The manifold no. shown below is for the T (VQ1000) and L (VQ1000/2000) kits. For other kits the standard manifold can be used. However, negative common is not compatible with S (except EX510 gateway-type and EX240 integrated-type) and G kits.

### How to Order Valves

**VQ1100 N-51-Q**

• Negative common specifications

### How to Order Manifold

T kit (VQ1000):

**VV5Q11-06 C6 T N - -Q**

• Stations  
• Cylinder port  
• Negative common specifications  
• Option

L kit (VQ1000/2000):

**VV5Q11-06 C6 L N 1 - -Q**

• Stations  
• Cylinder port  
• Negative common specifications  
• Electrical entry  
• Cable length  
• Option

Electrical entry Cable length	
0	With cable (0.6 m)
1	With cable (1.5 m)
2	With cable (3 m)

# Series VQ1000/2000

## Semi-standard

### External Pilot Specifications

When the supply air pressure is lower than the required minimum operating pressure (0.1 to 0.2 MPa) for the solenoid valve (or when the valve is used for vacuum), specify an external pilot model. Order a manifold or valve by suffixing the external pilot specification, "R". The X-port of the manifold base is equipped with one-touch fittings for external pilot.

VQ1000: C4 (ø4 one-touch fitting)

VQ2000: C6 (ø6 one-touch fitting)

### How to Order Manifold

**VV5Q11-08C6FU1-R S-Q**

External pilot specifications

Others, option symbols:  
to be indicated alphabetically.

### How to Order Valves

**VQ1100 R-51-Q**

External pilot specifications

Note 1) When two or more functions are specified, indicate them alphabetically.  
Note 2) Since the pilot EXH of this valve is released from the R1 passage, it is not possible to vacuum from a part other than EXH pressure and SUP ports.

### Inch-size One-touch Fittings

The valve with inch-size one-touch fittings is shown below.

**VV5Q11-06 N7 PS0- -Q**

Stations

Option

Kit type/Electrical entry

Cylinder port

Symbol	N1	N3	N7	N9	M5T	NM
Applicable tubing O.D. (Inch)	ø1/8"	ø5/32"	ø1/4"	ø5/16"	10-32UNF (M5 thread)	Mixed
4(A), 2(B) port	<b>VQ1000</b>	●	●	—	●	●
	<b>VQ2000</b>	—	●	●	—	●

Note) When inch-size fittings are selected for the cylinder port, inch-size fittings are selected on 1(P), 3(R) port, too.

1(P), 3(R) port size  
VQ1000 ..... ø5/16" (N9)  
VQ2000 ..... ø3/8" (N11)

### DIN Rail Mounting

Each manifold can be mounted on a DIN rail. Order it by indicating a DIN rail mounting option symbol, "-D". In this case, a DIN rail which is approx. 30 mm longer than the manifold with the specified number of stations is attached.

#### ● When DIN rail is unnecessary

(DIN rail mounting brackets only are attached.)

Indicate the option symbol, -D0, for the manifold part number.

#### Example)

**VV5Q11-08C6FU1-D0S-Q**

Others, option symbols:  
to be indicated alphabetically.

#### ● When using DIN rail longer than the manifold with specified number of stations

Clearly indicate the necessary number of stations next to the option symbol "-D" for the manifold part number.

#### Example)

**VV5Q11-08C6FU1-D09S-Q**

DIN rail for 9 stations

Others, option symbols:  
to be indicated alphabetically.

Note) The number of stations that may be displayed is longer than the manifold number of stations.

#### ● When changing to a DIN rail mounting.

Order brackets for mounting a DIN rail. (Refer to "Manifold Optional Parts" on pages 67 and 71.)

No. VVQ1000-57A (For VQ1000)


VVQ2000-57A (For VQ2000)

2 pcs. per one set.

#### ● When ordering DIN rail only

DIN rail no.: AXT100-DR-□

Note) As for □, specify the number from the DIN rail table. Refer to the dimensions of each kit for L dimension.



#### L Dimension

L = 12.5 x n + 10.5

No.	1	2	3	4	5	6	7	8	9	10
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5
No.	11	12	13	14	15	16	17	18	19	20
L dimension	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5
No.	31	32	33	34	35	36	37	38	39	40
L dimension	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5




# Series VQ1000/2000

## Construction

### VQ1000 Plug-in Unit: Main Parts/Replacement Parts

#### Metal seal




#### Component Parts

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	
4	Pilot valve assembly	—	

Note) Refer to page 62 for "How to Order Pilot Valve Assembly".

#### Rubber seal




#### Component Parts

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool valve	Aluminum, HNBR	
3	Piston	Resin	
4	Pilot valve assembly	—	

Note) Refer to page 62 for "How to Order Pilot Valve Assembly".

## VQ2000 Plug-in Unit: Main Parts/Replacement Parts

### Metal seal




### Component Parts

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	
4	Pilot valve assembly	—	

Note) Refer to page 62 for "How to Order Pilot Valve Assembly".

### Rubber seal



### Component Parts

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool valve	Aluminum, HNBR	
3	Piston	Resin	
4	Pilot valve assembly	—	


Note) Refer to page 62 for "How to Order Pilot Valve Assembly".



# Exploded View of Manifold

## VQ1000 Plug-in Unit: Exploded View

(F/P/L/S kit)



# Exploded View of Manifold

## <Housing Assembly and SI Unit>

Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
①	(SQ kit)	<b>EX120-SDN1</b>	DeviceNet®
	(SV kit)	<b>EX120-SMJ1</b>	CC-LINK
②	P <sub>S</sub> <sup>U</sup> kit	<b>AXT100-1-P<sub>S</sub><sup>U</sup></b> □ (Note)	Flat ribbon cable housing assembly □: Number of pins: 26/20/16/10
③	FU kit	<b>AXT100-1-FU15</b>	D-sub connector housing assembly (Top entry) Number of pins: 15
	FS kit	<b>AXT100-1-FS</b> □	D-sub connector housing assembly (Side entry) □: Number of pins: 25/15

Note) Top entry connector for PU while side entry connector for PS.

## <D-Side End Plate Assembly>

④⑤ D-side end plate assembly no.

**VVQ1000-3A-1-** □ - □

Electrical entry ● Option

<b>FU25</b>	For F kit top entry 25 pins	—	Common EXH
<b>F</b>	For F kit	<b>R</b> (Note 1)	External pilot
<b>P</b>	For P kit	<b>S</b> (Note 1)	Direct EXH outlet with built-in silencer
<b>L</b>	For L kit		
<b>S</b>	For S kit		

Note 1) When both options are specified, indicate as RS.

Note 2) The housing assembly and SI unit of F/P/S kit are not included. Separately place an order for ①, ②, ③.

## <Manifold Block Assembly>

⑧ Manifold block assembly no.

**VVQ1000-1A-** □ - □

Electrical entry ●

Tie-rod (2 pcs.) and lead wire assembly for extensions are attached.

● Port size

<b>F0</b>	Without lead wire	<b>C3</b>	With ø3.2 one-touch fitting
<b>F1</b>	F kit for 2 to 12 stations/Double wiring	<b>C4</b>	With ø4 one-touch fitting
<b>F2</b>	F kit for 13 to 24 stations/Double wiring	<b>C6</b>	With ø6 one-touch fitting
<b>F3</b>	F kit for 2 to 24 stations/Single wiring	<b>M5</b>	M5 thread
<b>P1</b>	P/S kit for 2 to 12 stations/Double wiring	<b>C0</b>	Without one-touch fitting (With clip)
<b>P2</b>	P/S kit for 13 to 24 stations/Double wiring		
<b>P3</b>	P/S kit for 2 to 24 stations/Single wiring		
<b>L0</b> □	L0 kit □: Stations (1 to 8)		
<b>L1</b> □	L1 kit □: Stations (1 to 8)		
<b>L2</b> □	L2 kit □: Stations (1 to 8)		

## <Replacement Parts for Manifold Block>

Replacement Parts

No.	Part no.	Description	Material	Quantity
⑨	<b>VVQ1000-80A-1</b>	Gasket	HNBR	12
⑩	<b>VVQ1000-80A-2</b>	Seal	HNBR	12
⑪	<b>VVQ1000-80A-3</b>	Clamp screw	Carbon steel	12
⑫	<b>VVQ1000-80A-4</b>	Clip	Stainless steel	12

Note) A set of parts containing 12 pcs. each is enclosed.

## <U-Side End Plate Assembly>

⑥ U-side end plate assembly no. (For F/P/S kit)

**VVQ1000-2A-1-** □

● Option

—	Common EXH
<b>R</b>	External pilot
<b>S</b>	Direct EXH outlet with built-in silencer

Note) The ⑭'s fitting assembly is included.

⑦ U-side end plate assembly no. (For L kit)

**VVQ1000-2A-1-L**

## <Fitting Assembly>

⑬ Fitting assembly part no. (For cylinder port)

**VVQ1000-50A-** □

● Port size

<b>C3</b>	Applicable tubing ø3.2
<b>C4</b>	Applicable tubing ø4
<b>C6</b>	Applicable tubing ø6
<b>M5</b>	M5 thread

Note) Purchasing order is available in units of 10 pieces.

⑭ Fitting assembly part no. (For 1(P), 3(R) port)

**VVQ1000-51A-C8**

● Applicable tubing ø8

Note) Purchasing order is available in units of 10 pieces.

⑮ Tie-rod assembly part no. (2 pcs./set)

**VVQ1000-TR-** □

Note 1) Please order when eliminating manifold stations.

When adding stations, tie-rods are attached to the manifold block assembly. Therefore, it is not necessary to order.

Note 2) □: Stations 02 to 24

Note 3) For S/P/F/L kit

## Pilot valve assembly

**V112** □ - □ □

● Function

Symbol	Specifications
—	Standard
<b>B</b>	High-speed response type
<b>K</b>	High-pressure type (1.0 MPa)

● Coil voltage

<b>5</b>	24 VDC
<b>6</b>	12 VDC

● Enclosure









<b>A</b>	Dust-tight, Water-jet-proof (IP65)
<b>B</b>	Dust-protected

Note) Common to single solenoid and double solenoid

# Exploded View of Manifold

## VQ2000 Plug-in Unit: Exploded View

(F/P/L/S kit)

	Housing assembly and SI unit	D-side end plate assembly	Manifold block assembly	U-side end plate assembly	
S kit					
P kit					
F kit					
L kit					

# Exploded View of Manifold

## <Housing Assembly and SI Unit>

### Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
①	(SQ kit)	EX120-SDN1 [EX124D-SDN1] <small>Note 1)</small>	DeviceNet®
	(SV kit)	EX120-SMJ1 [EX124D-SMJ1] <small>Note 1)</small>	CC-LINK
②	P <sub>S</sub> <sup>U</sup> kit	AXT100-1-P <sub>S</sub> <sup>U</sup> □ <small>Note 2)</small>	Flat ribbon cable housing assembly □: Number of pins: 26/20/16/10
③	F <sub>S</sub> <sup>U</sup> kit	AXT100-1-F <sub>S</sub> <sup>U</sup> □ <small>Note 2)</small>	D-sub connector housing assembly □: Number of pins: 25/15

Note 1) Dust-tight, Water-jet-proof (IP65)

Note 2) Top entry connector for FU, PU while side entry connector for FS, PS.

## <D-Side End Plate Assembly>

### ④⑤ D-side end plate assembly no.

VVQ2000-3A-1-□-□-□

#### Electrical entry

F	For F kit
P	For P kit
L	For L kit
S	For S/M kits

#### Enclosure

—	Dust-protected
W	Dust-tight, Water-jet-proof (IP65)

Note) F/P kit are only available with “—” option.  
M kit is available with [W] only. S/L/T kit are selectable depending on the manifold type.

#### Option

Nil	Common EXH
R <small>Note 1)</small>	External pilot
S <small>Note 1)</small>	Direct EXH outlet with built-in silencer

Note 1) When both options are specified, indicate as RS.

Note 2) The housing assembly and SI unit of F/P/S kit are not included.

Separately place an order for ①, ②, ③, ④.

Note 3) “S” (Built-in silencer) and “W” (IP65) cannot be combined.

## <U-Side End Plate Assembly>

### ⑥ U-side end plate assembly no. (For F/P/T/S/M kits)

VVQ2000-2A-1-□-□-□

#### Option

—	Common EXH
R	External pilot
S	Direct EXH outlet with built-in silencer

#### Enclosure

—	Dust-protected
W	Dust-tight, Water-jet-proof (IP65)

Note) F/P kit are only available with “—” option.  
M kit is available with [W] only. S/L/T kit are selectable depending on the manifold type.

Note 1) The ⑤'s fitting assembly is included.

Note 2) The housing assembly and SI unit of F/P/S kit are not included.

Separately place an order for ①, ②, ③, ④.

Note 3) “S” (Built-in silencer) and “W” (IP65) cannot be combined.

### ⑦ U-side end plate assembly no. (For L kit)

VVQ2000-2A-1-L-□-□-□

#### Enclosure

—	Dust-protected
W	Dust-tight, Water-jet-proof (IP65)

Note) Select it depending on the manifold type.

## <Manifold Block Assembly>

### ⑧ Manifold block assembly no.

VVQ2000-1A-□-□-□-□

Tie-rod (2 pcs.) and lead wire assembly for extensions are attached.

#### Electrical entry

F0	Without lead wire
F1	F kit for 2 to 12 stations/Double wiring
F2	F kit for 13 to 24 stations/Double wiring
F3	F kit for 2 to 24 stations/Single wiring
P1	P/S kit for 2 to 12 stations/Double wiring
P2	P/S kit for 13 to 24 stations/Double wiring
P3	P/S kit for 2 to 24 stations/Single wiring
L0□	L0 kit □: Stations (1 to 8)
L1□	L1 kit □: Stations (1 to 8)
L2□	L2 kit □: Stations (1 to 8)
T1	T kit for 2 to 20 stations/Double wiring
T3	T kit for 2 to 20 stations/Single wiring
M1	M kit for 2 to 12 stations/Double wiring
M2	M kit for 13 to 24 stations/Double wiring
M3	M kit for 2 to 24 stations/Single wiring

#### Port size

C4	With ø4 one-touch fitting
C6	With ø6 one-touch fitting
C8	With ø8 one-touch fitting
C0	Without one-touch fitting (With clip)

#### Enclosure

—	Dust-protected
W	Dust-tight, Water-jet-proof (IP65)

Note) F/P kit are available with “Nil” only.

M kit is available with [W] only.

S/L/T kit are selectable depending on the manifold type.

## <Fitting Assembly>

### ⑬ Fitting assembly part no. (For cylinder port)

VVQ1000-51A-□-□-□

#### Port size

C4	Applicable tubing ø4
C6	Applicable tubing ø6
C8	Applicable tubing ø8

Note) Purchasing order is available in units of 10 pieces.

### ⑭ Fitting assembly part no. (For 1(P), 3(R) port)

VVQ2000-51A-C10

#### Applicable tubing ø10

Note) Purchasing order is available in units of 10 pieces.

## <Replacement Parts for Manifold Block>

### Replacement Parts

No.	Part no.	Description	Material	Quantity
⑨	VVQ2000-80A-1	Gasket	HNBR	12
⑩	VVQ2000-80A-2	Seal	HNBR	12
⑪	VVQ2000-80A-3	Clamp screw	Carbon steel	12
⑫	VVQ2000-80A-4	Clip	Stainless steel	12

Note) A set of parts containing 12 pcs. each is enclosed.

### ⑮ Tie-rod assembly part no. (2 pcs./set)

VVQ2000-TR-□

Note 1) Please order when eliminating manifold stations.

When adding stations, tie-rods are attached to the manifold block assembly. Therefore, it is not necessary to order.

Note 2) □: Stations 02 to 24

Note 3) For S/P/J/F/L kit

# Series VQ1000



## VQ1000: Manifold Optional Parts

### Blanking plate assembly VVQ1000-10A-1

JIS symbol



It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.





### Individual SUP spacer VVQ1000-P-1-C6 N7

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.) Block both sides of the station, for which the supply pressure from the individual SUP spacer is used, with SUP block plates. (Refer to the application example.)

Note 1) Specify the spacer mounting position and SUP block plate position by means of the manifold specification sheet. The block plate is used in one or two places for one set. (Two SUP block plates for blocking SUP station are attached to the individual SUP spacer.)

Note 2) As a standard, electric wiring is connected to the position of the manifold station where the individual SUP spacer is mounted.

Note 3) If wiring is not required for stations equipped with spacers, enter "X" in the special wiring specifications column in the manifold specification sheet.



### Individual EXH spacer VVQ1000-R-1-C6 N7

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.) Block both sides of the individual valve EXH station. (Refer to the application example.)


Note 1) Specify the mounting position, as well as the EXH block base or EXH block plate position by means of the manifold specification sheet. The block plate is used in one or two places for one set.

Note 2) An EXH block base assembly is used in the blocking position when ordering an EXH spacer incorporated with a manifold no. However, do not order an EXH block base assembly because it is attached to the spacer.


When separately ordering an individual EXH spacer, separately order an EXH block base assembly because it is not attached to the spacer.

Note 3) As a standard, electric wiring is connected to the position of the manifold station where the individual EXH spacer is mounted.

Note 4) If wiring is not required for stations equipped with spacers, enter "X" in the special wiring specifications column in the manifold specification sheet.



Description/Model		Stations						
Valve	Single	1	2	3	4	5	6	7
Option	Individual EXH spacer VVQ1000-R-1-C6							



### SUP block plate VVQ1000-16A



When different pressures are supplied to a manifold, a SUP block plate is used to block the stations under different pressures.

Note) Specify the mounting position by means of the manifold specification sheet.



#### <Block indication label>

Indication labels to confirm the blocking position are attached (Each for SUP passage and SUP/EXH passage blocking positions).

Note) When ordering a block plate incorporated with a manifold, a block indication label is attached to the manifold.



SUP passage blocked



SUP/EXH passage blocked

### Blanking plate with connector VVQ1000-1C

JIS symbol




Connector		Connector lead wire length (mm)			
		300	20	2000	
1	Without connector	6	600	25	2500
2	With connector/2-wire	10	1000	30	3000
	With connector/4-wire	15	1500		

Blanking plate with a connector for individually outputting electricity to drive a single valve or equipment that are not on the manifold base.


Note) When "N" is suffixed to the end of the name plate, the plate will be different from a standard shape.

Note) Electric current should be 1A or less (including the mounted valves).




### Connector assembly part no. AXT661-43 A-6

Lead wire length (mm)		Lead wire length (mm)	
43	4-wire	6	600
44	2-wire	10	1000
		20	2000
		30	3000





## EXH block base assembly

VVQ1000-19A--(C3/C4/C6/M5/N1/N3/N7)

Manifold block assembly  
Electrical entry


<b>F0</b>	Without lead wire
<b>F1</b>	For F kit (2 to 12 stations)/Double wiring
<b>F2</b>	For F kit (13 to 24 stations)/Double wiring
<b>F3</b>	For F kit (2 to 24 stations)/Single wiring
<b>P1</b>	For P, G, T, S kit (2 to 12 stations)/Double wiring
<b>P2</b>	For P, G, T, S kit (13 to 24 stations)/Double wiring
<b>P3</b>	For P, G, T, S kit (2 to 24 stations)/Single wiring
<b>L0*</b>	L0 kit
<b>L1*</b>	L1 kit } * 1 to 8 stations
<b>L2*</b>	L2 kit }

The manifold block assembly is used between stations for which exhaust is desired to be divided when valve exhaust affects other stations due to the circuit configuration. The EXH passage on the D-side is blocked in the EXH block base assembly. It is also used in combination with an individual EXH spacer for individual exhaust.

### <Block indication label>


Indication labels to confirm the blocking position are attached. (Each for EXH passage and SUP/EXH passage blocking positions)

Note 1) When ordering a EXH block base incorporated with a manifold, a block indication label is attached to the manifold.




Note 2) Specify the mounting station by means of the manifold specification sheet.

Note 3) When ordering this option incorporated with a manifold, specify the EXH block base assembly part number with "\*" in front of it beneath the



EXH passage blocked




SUP/EXH passage blocked

## Back pressure check valve assembly [-B] VVQ1000-18A

It prevents cylinder malfunction caused by other valve exhaust entry. Insert it into R (EXH) port on the manifold side of a valve which is affected. It is effective when a single-acting cylinder is used or an exhaust centre type solenoid valve is used.

Note 1) When ordering it being mounted on all manifold stations, suffix "B" to the end of the manifold part number.

Note 2) When a back pressure check valve is desired, and is to be installed only in certain manifold stations, clearly indicate the part number and specify the mounting station by means of the manifold specification sheet.



### (Precautions)

1. The back pressure check valve assembly is the parts with a check valve structure. However, since the valve has slight air leakage, take precautions for the exhaust air not to be restricted at the exhaust port.
2. When a back pressure check valve is mounted, the effective area of the valve will decrease by about 20%.

## Name plate [-N]



VVQ1000-<sup>N</sup>NC-N-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.

Note 1) When the blanking plate with connector is mounted, it automatically will be "VVQ1000-NC-n"

Note 2) When ordering this option incorporated with a manifold, suffix "-N" to the end of the manifold



N: Standard  
NC: For mounting blanking plate with connector



## Blanking plug (For one-touch fittings)

KQ2P-

It is inserted into an unused cylinder port and SUP/EXH ports. Purchasing order is available in units of 10 pieces.



### Dimensions



Applicable fitting size ød	Model	A	L	D	Applicable fitting size ød	Model	A	L	D
3.2	KQ2P-23	16	31.5	3.2	1/8"	KQ2P-01	16	31.5	5
4	KQ2P-04	16	32	6	5/32"	KQ2P-03	16	32	6
6	KQ2P-06	18	35	8	1/4"	KQ2P-07	18	35	8.5
8	KQ2P-08	20.5	39	10	5/16"	KQ2P-09	20.5	39	10

## Port plug VVQ0000-58A

The plug is used to block the cylinder port.

Note 1) When ordering this option incorporated with a manifold, indicate "CM" for the port size of the manifold part number, as well as, the mounting station and cylinder port mounting positions 4(A) and 2(B) by means of the manifold specification sheet.

Note 2) Gently screw an M3 screw in the port plug hole and pull it for removal.






## Elbow fitting assembly

VVQ1000-F-L(C3/C4/C6/M5/N1/N3/N7)

It is used for piping that extends upward or downward from the manifold.

Note 1) When ordering this option incorporated with a manifold, indicate "L□" or "B□" for the manifold port size (when installed in all stations.)  
When installing it in part of the manifold stations, specify the elbow fitting assembly part number and the mounting station by means of the manifold specification sheet.

Note 2) When mounting elbow fitting assembly on the edge of manifold station and a silencer on EXH port, select a silencer, AN203-KM8. A silencer (AN200-KM8) is interfered with fittings.



# Series VQ1000

## VQ1000: Manifold Optional Parts



### DIN rail mounting bracket [-D/-D0/-D□]

#### VVQ1000-57A

It is used for mounting a manifold on a DIN rail.

Note 1) When ordering this option incorporated with a manifold, suffix "D" to the end of the manifold part number.

1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).



### Direct EXH outlet with built-in silencer [-S]


This is a type with an exhaust port at the top of the manifold end plate. The built-in silencer exhibits an excellent noise suppression effect. (Noise reduction: 30 dB)

Note 1) When ordering this option incorporated with a manifold, suffix "S" to the end of the manifold part number.

Note 2) A large quantity of drainage generated in the air source results in exhaust of air together with drainage.



● Refer to back page 5 for maintenance.





### Dual flow fitting assembly

#### VVQ1000-52A-C8

This is a fitting to multiply the flow rate by combining the outputs of 2 valve stations. It is used for driving a large bore cylinder. This is a one-touch fitting for a port size of  $\phi 8$  or  $\phi 5/16$ ".

Note 1) The port size for the manifold part number is "CM". Clearly indicate the dual flow fitting assembly part number and specify the mounting station by means of the manifold specifications.


Note 2) In dual flow fitting assembly, a special clip which is combined in one-piece of 2 stations is attached as a holding clip.



### Silencer (For EXH port)

This silencer is to be inserted into the EXH port (one-touch fittings) of the common exhaust type.

Note 1) When mounting elbow fitting assembly (VVQ1000-F-L□) on the edge of manifold station, select a silencer, AN203-KM8. A silencer (AN203-KM8) is interfered with fittings.



### Dimensions

Series	Applicable fitting size $\phi d$	Model	A	L	D	Effective area (mm <sup>2</sup> )	Noise reduction (dB)
VQ1000	8	AN200-KM8	59	78	22	20	30
		AN203-KM8	32	51	16	14	25*

### Regulator unit

#### VVQ1000-AR-1

The regulator controls the SUP pressure in a manifold. Supply air from D-side SUP port is regulated. SUP port on U-side is plugged.



When a regulator unit is mounted, the SUP port on the U-side of the manifold will be plugged. A maximum of 3 units can be mounted on a manifold.

### Specifications

Maximum operating pressure (MPa)	0.8
Set pressure range (MPa)	0.05 to 0.7
Ambient and fluid temp. (°C)	5 to 50
Fluid	Air
Cracking pressure valve (MPa)	0.02
Structure	Relieving type

Pressure gauge  
G27-10-01

Pressure control screw



### • How to Order

Indicate an option symbol "-G\*" for the manifold no. and be sure to specify the mounting position and number of stations by means of the manifold specification sheet. One unit is counted as one station and occupies a space for three stations, therefore, pay attention to the manifold size. The regulator valve unit, to which no wire is connected, valves can be mounted up to the standard max. number of stations of each kit.

### How to Order Manifold

#### VV5Q11-14C6FUO-D G 2



Number of manifold stations  
Number of mounted valves ... 12 sets

+  
Number of regulator units ... 2 sets


Number of regulator units ... 2 sets

With regulator unit


Others, option symbols: to be indicated alphabetically.



### Flow Characteristics



### Pressure Characteristics



## Caution

### • Pressure setting

Check the inlet pressure and then turn the pressure control screw to set the outlet pressure. Turning the screw clockwise will increase the outlet pressure while turning it counterclockwise decrease the pressure. (Set the pressure by turning the screw in the increase direction.)

### • Installation

Since some level of the actuator's operational frequency may lead to a sharp pressure change, pay attention to the pressure gauge durability.

## EXH block base assembly VVQ1000-19A--(C3/C4/C6/M5/N1/N3/N7)

Manifold block assembly  
Electrical entry



F0	Without lead wire
F1	For F kit (2 to 12 stations)/Double wiring
F2	For F kit (13 to 24 stations)/Double wiring
F3	For F kit (2 to 24 stations)/Single wiring
P1	For P, G, T, S kit (2 to 12 stations)/Double wiring
P2	For P, G, T, S kit (13 to 24 stations)/Double wiring
P3	For P, G, T, S kit (2 to 24 stations)/Single wiring
L0*	L0 kit
L1*	L1 kit
L2*	L2 kit

The manifold block assembly is used between stations for which exhaust is desired to be divided when valve exhaust affects other stations due to the circuit configuration. The EXH passage on the D-side is blocked in the EXH block base assembly. It is also used in combination with an individual EXH spacer for individual exhaust.

### <Block indication label>


Indication labels to confirm the blocking position are attached. (Each for EXH passage and SUP/EXH passage blocking positions)

Note 1) When ordering a EXH block base incorporated with a manifold, a block indication label is attached to the manifold.




Note 2) Specify the mounting station by means of the manifold specification sheet.

Note 3) When ordering this option incorporated with a manifold, specify the EXH block base assembly part number with "\*" in front of it beneath the



EXH passage blocked





SUP/EXH passage blocked

## Back pressure check valve assembly [-B] VVQ1000-18A

It prevents cylinder malfunction caused by other valve exhaust entry. Insert it into R (EXH) port on the manifold side of a valve which is affected. It is effective when a single-acting cylinder is used or an exhaust centre type solenoid valve is used.

Note 1) When ordering it being mounted on all manifold stations, suffix "-B" to the end of the manifold part number.

Note 2) When a back pressure check valve is desired, and is to be installed only in certain manifold stations, clearly



### (Precautions)

1. The manifold installed type back pressure check valve assembly is assembly parts with a check valve structure. However, since slight air leakage against the back pressure is allowed due to its structure, adverse effects of the back pressure due to increase in exhaust resistance cannot be prevented if the manifold exhaust port and other exhaust ports are put together for piping or if the piping diameter is narrowed. As a result, this may cause the actuator and air operated equipment to malfunction. So, be careful not to restrict the exhaust air.
2. When a back pressure check valve is mounted, the effective area of the valve will decrease by about 20%.



## Name plate [-N] VVQ1000--N-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.

Note 1) When the blanking plate with connector is mounted, it automatically will be "VVQ1000-NC-n"

Note 2) When ordering this option incorporated with a

N: Standard  
NC: For mounting blanking plate with connector





Note 1) : VVQ1000-NC-n

## Blanking plug (For one-touch fittings)

KQ2P-

It is inserted into an unused cylinder port and SUP/EXH ports.  
Purchasing order is available in units of 10



### Dimensions



Applicable fitting size ød	Model	A	L	D	Applicable fitting size ød	Model	A	L	D
3.2	KQ2P-23	16	31.5	3.2	1/8"	KQ2P-01	16	31.5	5
4	KQ2P-04	16	32	6	5/32"	KQ2P-03	16	32	6
6	KQ2P-06	18	35	8	1/4"	KQ2P-07	18	35	8.5
8	KQ2P-08	20.5	39	10	5/16"	KQ2P-09	20.5	39	10

## Port plug VVQ0000-58A

The plug is used to block the cylinder port.

Note 1) When ordering this option incorporated with a manifold, indicate "CM" for the port size of the manifold part number, as well as, the mounting station and cylinder port mounting positions 4(A) and 2(B) by means of the manifold specification sheet.

Note 2) Gently screw an M3 screw in the port plug hole and pull it for removal.





## Elbow fitting assembly VVQ1000-F-L(C3/C4/C6/M5/N1/N3/N7)

It is used for piping that extends upward or downward from the manifold.

Note 1) When ordering this option incorporated with a manifold, indicate "L□" or "B□" for the manifold port size (when installed in all stations.)  
When installing it in part of the manifold stations, specify the elbow fitting assembly part number and the mounting station by means of the manifold specification sheet.

Note 2) When mounting elbow fitting assembly on the edge of manifold station and a silencer on EXH port, select a silencer, AN203-KM8. A silencer (AN200-KM8) is interfered with fittings.



Downward



Upward





# Series VQ2000

## VQ2000: Manifold Optional Parts

### Blanking plate assembly JIS symbol VVQ2000-10A-1

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.





### Individual SUP spacer VVQ2000-P-1-C8-N9

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.)

Block both sides of the station, for which the supply pressure from the individual SUP spacer is used, with SUP block plates. (Refer to the application example.)  
Note 1) Specify the spacer mounting position and SUP block plate position by means of the manifold specification sheet. The block plate is used in one or two places for one set. (Two SUP block plates for blocking SUP station are attached to the individual SUP spacer.)

Note 2) As a standard, electric wiring is connected to the position of the manifold station where the individual SUP spacer is mounted.

Note 3) If wiring is not required for stations equipped with spacers, enter "X" in the special wiring specifications column in the manifold specification sheet.



### Individual EXH spacer VVQ2000-R-1-C8-N9



When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.)

Block both sides of the individual valve EXH station. (Refer to the application example.)

Note 1) Specify the mounting position, as well as the EXH block base or EXH block plate position by means of the manifold specification sheet. The block plate is used in one or two places for one set. (Two EXH block plates for blocking EXH station are attached to the individual EXH spacer.)

Note 2) As a standard, electric wiring is connected to the position of the manifold station where the individual EXH spacer is mounted.



Note 3) If wiring is not required for stations equipped with spacers, enter "X" in the special wiring specifications column in the manifold specification sheet.



### SUP block plate VVQ2000-16A


When different pressures are supplied to a manifold, a SUP block plate is used to block the stations under different pressures.

Note) Specify the mounting position by means of the manifold specification sheet.




#### <Block indication label>

Indication labels to confirm the blocking position are attached. (Each for SUP passage and SUP/EXH passage blocking positions)



SUP passage blocked



SUP/EXH passage blocked





Note) When ordering a block plate incorporated with a manifold, a block indication label is attached to the manifold.

### EXH block plate VVQ2000-19A


The EXH block plate is used between stations for which exhaust is desired to be divided when valve exhaust affects other stations configuration. It is also used in combination with an individual EXH spacer for individual exhaust.

Note) Specify the mounting position by means of the manifold specification sheet.




#### <Block indication label>

Indication labels to confirm the blocking position are attached. (Each for EXH passage and SUP/EXH passage blocking positions)



EXH passage blocked



SUP/EXH passage blocked





Note) When ordering a block plate incorporated with a manifold, a block indication label is attached to the manifold.

## SUP stop valve spacer VVQ2000-24A-1

A SUP stop valve spacer is mounted on a manifold block, making it possible to individually shut off supply air to each valve.

Enclosure: Dust-tight, Water-jet-proof (IP65) compliant



<Circuit diagram>



(Example of a spacer with a built-in single valve)

## Back pressure check valve assembly [-B] VVQ2000-18A

It prevents cylinder malfunction caused by other valve exhaust entry. Insert it into R (EXH) port on the manifold side of a valve which is affected. It is effective when a single-acting cylinder is used or an exhaust centre type solenoid valve is used.

Note 1) When ordering assemblies incorporated with a manifold, add suffix "-B" to the end of the manifold part number.

Note 2) When a check valve for back pressure prevention is desired and is to be installed only in certain manifold stations, clearly indicate the part number and specify the mounting position by means of the manifold specification sheet.



(Precautions)

1. The manifold installed type back pressure check valve assembly is assembly parts with a check valve structure. However, since slight air leakage against the back pressure is allowed due to its structure, adverse effects of the back pressure due to increase in exhaust resistance cannot be prevented if the manifold exhaust port and other exhaust ports are put together for piping or if the piping diameter is narrowed. As a result, this may cause the actuator and air operated equipment to malfunction. So, be careful not to restrict the exhaust air.
2. When a back pressure check valve is mounted, the effective area of the valve will decrease by about 20%.

## Name plate [-N]

### VVQ2000-N-Station (1 to Max. stations) (-X4□)



-X4A: For mounting slide locking type, manual, all single valves

-X4B: For mixed mounting of slide locking type, manual, single, double, and 3-position valves

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.

\* When the slide locking type manual valve is mounted, it automatically will be "VVQ2000-N-n-X4A/X4B"



\* When ordering this option incorporated with a manifold, suffix "-N" to the end of the manifold part number.



## Blanking plug (For one-touch fittings)

### KQ2P-□

It is inserted into an unused cylinder port and SUP/EXH ports. Purchasing order is available in units of 10 pieces.





## Dimensions

Applicable fitting size ød	Model	A	L	D	Applicable fitting size ød	Model	A	L	D
4	KQ2P-04	16	32	6	5/32"	KQ2P-03	16	32	6
6	KQ2P-06	18	35	8	1/4"	KQ2P-07	18	35	8.5
8	KQ2P-08	20.5	39	10	5/16"	KQ2P-09	20.5	39	10
10	KQ2P-10	22	43	12	3/8"	KQ2P-11	22	43	11.5

## Port plug VVQ1000-58A

The plug is used to block the cylinder port.

Note) When ordering a plug incorporated with a manifold, indicate "CM" for the port size of the manifold part number, as well as, the mounting position and number of stations and cylinder port mounting positions, A and B by means of the manifold specification sheet.



# Series VQ2000



## VQ2000: Manifold Optional Parts

### DIN rail mounting bracket [-D/-D0/-D□] VVQ2000-57A

It is used for mounting a manifold on a DIN rail.

Note) When ordering this option incorporated with a manifold, suffix "-D" to the end of the manifold part number.

1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).



### Direct EXH outlet with built-in silencer [-S]


This is a type with an exhaust port atop the manifold end plate. The built-in silencer exhibits an excellent noise suppression effect. (Noise reduction: 30 dB)

Note 1) When ordering this option incorporated with a manifold, suffix "-S" to the end of the manifold part number.

Note 2) A large quantity of drainage generated in the air source results in exhaust of air together with drainage.




● Refer to back page 5 for maintenance.



### Silencer (For EXH port)

This silencer is to be inserted into the EXH port (One-touch fittings).




### Dimensions

Series	Applicable fitting size ød	Model	A	L	D	Effective area (mm <sup>2</sup> ) (Cv factor)	Noise reduction (dB)
VQ2000	10	AN200-KM10	59.6	80.8	22	26 (1.4)	30

### Elbow fitting assembly VVQ2000-F-L(C4/C6/C8/N3/N7/N9)

It is used for piping that extends upward or downward from the manifold.

When not installed in the manifold stations, specify the assembly part number and the mounting position by means of the manifold specification sheet.




### Dual flow fitting assembly VVQ2000-52A-C10-N11

This is a fitting to multiply the flow rate by combining the outputs of 2-valve stations. It is used for driving a large bore cylinder. This is a one-touch fitting for a port size of ø10 or ø3/8".



Note) The port size for the manifold part number is "CM".

Clearly indicate the dual flow fitting assembly part number and specify the mounting position by means of the manifold specifications.





## Manifold Option

### Double check block (Separated) for VQ2000

VQ2000-FPG-□□-□

It is mounted on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the double check block with a 3-position exhaust centre solenoid valve will enable the cylinder to stop in the middle or maintain its position for long periods of time.


The combination with a 2-position single/double solenoid valve will prevent the dropping at the cylinder stroke end when the SUP residual pressure is released.

### Specifications


Max. operating pressure	0.8 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temp.	-5 to 50C
Flow characteristics: C	3.0 dm <sup>3</sup> /(s·bar)
Max. operating frequency	180 c.p.m



Note) Based on JIS B 8375-1981  
(Supply pressure: 0.5 MPa)




### <Circuit diagram>




## Dimensions

### Single unit



### Manifold



### Dimensions

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	46	68	90	112	134	156	178	200	222	244	266	288	310	332	354	376
L2	75	87.5	112.5	137.5	162.5	175	200	225	250	262.5	287.5	312.5	337.5	362.5	375	400
L3	85.5	98	123	148	173	185.5	210.5	235.5	260.5	273	298	323	348	373	385.5	410.5

Formula L1 = 22n + 24 n: Station

## How to Order

### Double check block

VQ2000-FPG-01 01 - F

#### IN side port size

01	Rc 1/8
02	Rc 1/4
C4	ø4 One-touch fitting
C6	ø6 One-touch fitting
C8	ø8 One-touch fitting
N7	ø1/4" One-touch fitting
N9	ø5/16" One-touch fitting

#### OUT side port size


01	Rc 1/8
02	Rc 1/4
C4	ø4 One-touch fitting
C6	ø6 One-touch fitting
C8	ø8 One-touch fitting
N7	ø1/4" One-touch fitting
N9	ø5/16" One-touch fitting

### Option

-	None
D	DIN rail mounting (For manifold)
F	With bracket
N	Name plate

Note) When two or more symbols are specified, indicate them alphabetically.  
Example) -DN

### <Example>



### Manifold (DIN rail mounting)

VVQ2000-FPG-06

#### Stations

01	1 station
...	...
16	16 stations

When ordering a double check block, order the DIN rail mounting [-D].

#### <Ordering Example>

VVQ2000-FPG-06...6-station manifold

\*VQ2000-FPG-C6C6-D, 3 sets  
\*VQ2000-FPG-C8C8-D, 3 sets

Double check block

#### Bracket Assembly

Part no.	Tightening torque
VQ2000-FPG-FB	0.8 to 1.0 N·m

## Caution

- Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for long periods of time. Check the leakage using neutral household detergent, such as dish washing soap. Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.
- Since one-touch fittings allow slight air leakage, screw piping is recommended when stopping the cylinder in the middle for long periods of time.
- Combining double check block with 3-position closed centre or pressure centre solenoid valve will not work.
- When fittings, etc. are being screwed to the double check block, tighten them with the torque below.

Connection threads	Proper tightening torque (N·m)
Rc 1/8	7 to 9
Rc 1/4	12 to 14

- If the exhaust of the double check block is restricted too much, the cylinder may not operate properly and may not stop intermediately.
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.

# Series VQ2000

## Manifold Option

### Double check block (Direct mounting)

VVQ2000-23A- $\frac{B}{C}$



It is mounted directly on the manifold to keep the cylinder in the intermediate position for a long time. Combining the double check block with a built-in pilot type double check valve and a 3-position exhaust centre solenoid valve will enable the cylinder to stop in the middle or maintain its position for long periods of time.

The combination with a 2-position single/double solenoid valve will permit this block to be used for preventing the dropping at the cylinder stroke end when the SUP residual pressure is released.

### Specifications




Max. operating pressure	0.7 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temperature	-5 to 50°C
Flow characteristics: C	1.8 dm <sup>3</sup> /(s·bar)
Max. operating frequency	180 c.p.m

### <Check valve operation principle>





## Dimensions

### Single unit



### When the manifold is mounted.




Top ported (VVQ2000-23A-C□)

Bottom ported (VVQ2000-23A-B□)

### ⚠ Caution

- Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for long periods of time. Check the leakage using neutral household detergent, such as dish washing soap. Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.
- Since zero air leakage is not guaranteed, it is sometimes not possible to hold a stop position for long periods of time.
- Combining double check block with 3-position closed centre or pressure centre solenoid valve will not work.
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.
- If the exhaust of the double check block is restricted too much, the cylinder may not operate properly and may not stop intermediately.

### <Example>





# Series VQ1000/2000

## Specific Product Precautions 1


Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions and Handling Precautions for SMC Products (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.

### Light/Surge Voltage Suppressor


#### ⚠ Caution

The lighting positions are concentrated on one side for both single solenoid type and double solenoid type. In the double solenoid type, A side and B side energization are indicated by two colours which match the colours of the manual overrides.




#### DC circuit diagram

##### Single solenoid



Note) A-side energization:  
A light (Orange) illuminates.  
B-side energization:  
B light (Green) illuminates.

##### Double solenoid



With wrong wiring prevention (stop diode) mechanism  
With a surge absorption (surge absorption diode) mechanism

### Continuous Duty


#### ⚠ Caution

If a valve is energized continuously for long periods of time, the rise in temperature due to heat-up of the coil assembly may cause a decline in solenoid valve performance, reduce service life, or have adverse effects on peripheral equipment. In particular, if three or more adjacent stations on the manifold are energized simultaneously for extended periods of time or if the valves on A side and B side are energized simultaneously for long periods of time, take special care as the temperature rise will be greater. In such cases, if it is possible to select a valve with a power-saving circuit, be sure to do so.

### UL Approved Product

#### ⚠ Caution

When conformity to UL is required, the product should be used with a UL1310 Class 2 power supply.


The product is a UL approved product only if it has a  mark on the body.

### Manual Override

#### ⚠ Warning


Without an electric signal for the solenoid valve the manual override is used for switching the main valve. Push type is standard. (Tool required) Locking type is semi-standard. (Tool required/Manual)

##### ■ Push type (Tool required)




Push down on the manual override with a small screwdriver, etc. until it stops. Release the screwdriver and the manual override will return.

##### ■ Locking type (Tool required) <Semi-standard>



Push down on the manual override with a flat head screwdriver until it stops. Turn it clockwise by 90 to lock it. Turn it counterclockwise to release it.

##### ■ Locking type (Manual) <Semi-standard>



Push down on the manual override with a small flat head screwdriver or with your fingers until it stops. Turn it clockwise by 90 to lock it. Turn it counterclockwise to release it.

#### ⚠ Caution

Do not apply excessive torque when turning the locking type manual override. (0.1 N·m or less)



# Series VQ1000/2000

## Specific Product Precautions 2


Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions and Handling Precautions for SMC Products (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.

### Manual Override

#### Warning


■ Slide locking type (Manual) <Semi-standard>



The manual override is locked by sliding it all the way to the pilot valve side (ON side) with a small flat head screwdriver or finger. Slide it to the fitting side (OFF side) to release it. In addition, it can also be used as a push type by using a screwdriver, etc., of  $\phi 1.7$  or less. ( $\phi 2$  or less for VQ2000).

### How to Mount/Remove Solenoid Valves

#### Caution



#### Removing

1. Loosen the clamp screw until it turns freely. (The screw is captive.)
2. Lift the coil side of the valve body while pressing down slightly on the screw head and remove it from the clamp bracket B. When the screw head cannot be pressed easily, gently press the area near the manual override of the valve.

### How to Mount/Remove Solenoid Valves

#### Caution

##### Mounting

1. Press down on the clamp screw. Clamp bracket A opens. Diagonally insert the hook on the valve end plate side into clamp B.
2. Press the valve body downward. (When the screw is released, it will be locked by clamp bracket A.)
3. Tighten the clamp screw. (Proper tightening torque: VQ1000, 0.25 to 0.35 N·m; VQ2000, 0.5 to 0.7 N·m.)

##### Caution


Dust on the sealing surface of the gasket or solenoid valve can cause air leakage.

### Replacement of Cylinder Port Fittings

#### Caution

The cylinder port fittings are a cassette for easy replacement. The fittings are blocked by a clip. Take out the clip with a flat head screwdriver, etc., then replace the fittings.

For mounting, insert the fitting assembly until it strikes against the inside wall and then insert the clip to the specified position.



Applicable tubing O.D.	Fitting assembly part no.	
	VQ1000	VQ2000
Applicable tubing $\phi 3.2$	VVQ1000-50A-C3	—
Applicable tubing $\phi 4$	VVQ1000-50A-C4	VVQ1000-51A-C4
Applicable tubing $\phi 6$	VVQ1000-50A-C6	VVQ1000-51A-C6
Applicable tubing $\phi 8$	—	VVQ1000-51A-C8
M5	VVQ1000-50A-M5	—
Applicable tubing $\phi 1/8$ "	VVQ1000-50A-N1	—
Applicable tubing $\phi 5/32$ "	VVQ1000-50A-N3	VVQ1000-51A-N3
Applicable tubing $\phi 1/4$ "	VVQ1000-50A-N7	VVQ1000-51A-N7
Applicable tubing $\phi 5/16$ "	—	VVQ1000-51A-N9

Note) Refer to "Manifold Optional Parts" on pages 66, 67, 71 for other types of fittings.

##### Caution

1. Use caution that O-rings must be free from scratches and dust. Otherwise, air leakage may result.
2. After screwing in the fittings, mount the M5 fitting assembly on the manifold base. (Tightening torque: 0.8 to 1.2 N·m)
3. Purchasing order is available in units of 10 pieces.



# Series VQ1000/2000

## Specific Product Precautions 3

Be sure to read before handling.


Refer to back pages 1 and 2 for Safety Instructions and Handling Precautions for SMC Products (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.

### How to Mount/Remove DIN Rail

#### ⚠ Caution


##### Removing

1. Loosen the clamp screw on side (a) of the end plate on both sides.
2. Lift side (a) of the manifold base and slide the end plate in the direction of (2) shown in the figure to remove.



##### Mounting

1. Hook side (b) of the manifold base on the DIN rail.
2. Press down side (a) and mount the end plate on the DIN rail. Tighten the clamp screw on side (a) of the end plate. (Proper tightening torque: VQ1000, 1.1 to 1.3 N·m; VQ2000, 1.4 to 1.6 N·m.)



### IP65 Enclosure

#### ⚠ Caution

Wiring connection for models conforming to IP65 should also have enclosures equivalent to or of stricter than IP65.

### Built-in Silencer Element

#### ⚠ Caution


A filter element is incorporated in the end plate on both sides of the manifold base. A dirty and choked element may reduce cylinder speed or cause malfunction. Clean or replace the dirty element.

##### Element Part No.

Type	Element part no.	
	VQ1000	VQ2000
Built-in silencer, direct exhaust	VVQ1000-82A-1	VVQ2000-82A-1

The minimum order quantity is 10 pcs.

Remove the cover from the top of the end plate and remove the old element with a flat head screwdriver, etc.



### How to Calculate Flow Rate

Refer to Best Pneumatics No. ① for obtaining the flow rate.

#### ■ Trademark




DeviceNet™ is a trademark of ODVA.

CompoNet™ is a trademark of ODVA.



## Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of “Caution,” “Warning” or “Danger.” They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC) <sup>1)</sup>, and other safety regulations.

-  **Danger:** **Danger** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.
-  **Warning:** **Warning** indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.
-  **Caution:** **Caution** indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

- 1) ISO 4414: Pneumatic fluid power – General rules and safety requirements for systems and their components.  
ISO 4413: Hydraulic fluid power – General rules and safety requirements for systems and their components.  
IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)  
ISO 10218-1: Robots and robotic devices - Safety requirements for industrial robots - Part 1: Robots.  
etc.

### Warning

#### 1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

#### 2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

#### 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

#### 4. Our products cannot be used beyond their specifications.

**Our products are not developed, designed, and manufactured to be used under the following conditions or environments.**

**Use under such conditions or environments is not covered.**

1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
2. Use for nuclear power, railways, aviation, space equipment, ships, vehicles, military application, equipment affecting human life, body, and property, fuel equipment, entertainment equipment, emergency shut-off circuits, press clutches, brake circuits, safety equipment, etc., and use for applications that do not conform to standard specifications such as catalogues and operation manuals.
3. Use for interlock circuits, except for use with double interlock such as installing a mechanical protection function in case of failure. Please periodically inspect the product to confirm that the product is operating properly.

### Caution

**We develop, design, and manufacture our products to be used for automatic control equipment, and provide them for peaceful use in manufacturing industries.**

**Use in non-manufacturing industries is not covered.**

Products we manufacture and sell cannot be used for the purpose of transactions or certification specified in the Measurement Act.

The new Measurement Act prohibits use of any unit other than SI units in Japan.

## Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following “Limited warranty and Disclaimer” and “Compliance Requirements”. Read and accept them before using the product.

### Limited warranty and Disclaimer

1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first. <sup>2)</sup> Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
- 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

### Compliance Requirements

1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

## Safety Instructions

Be sure to read “Handling Precautions for SMC Products” (M-E03-3) before using.



SMC Corporation (Europe)

Austria	+43 (0)2262622800	www.smc.at	office.at@smc.com
Belgium	+32 (0)33551464	www.smc.be	info@smc.be
Bulgaria	+359 (0)2807670	www.smc.bg	sales.bg@smc.com
Croatia	+385 (0)13707288	www.smc.hr	sales.hr@smc.com
Czech Republic	+420 541424611	www.smc.cz	office.at@smc.com
Denmark	+45 70252900	www.smc.dk.com	smc.dk@smc.com
Estonia	+372 651 0370	www.smcee.ee	info.ee@smc.com
Finland	+358 207513513	www.smc.fi	smc.fi@smc.com
France	+33 (0)164761000	www.smc-france.fr	supportclient.fr@smc.com
Germany	+49 (0)61034020	www.smc.de	info.de@smc.com
Greece	+30 210 2717265	www.smchellas.gr	sales@smchellas.gr
Hungary	+36 23513000	www.smc.hu	office.hu@smc.com
Ireland	+353 (0)14039000	www.smcautomation.ie	technical.ie@smc.com
Italy	+39 03990691	www.smcitalia.it	mailbox.it@smc.com
Latvia	+371 67817700	www.smc.lv	info.lv@smc.com

Lithuania	+370 5 2308118	www.smclt.lt	info.lt@smc.com
Netherlands	+31 (0)205318888	www.smc.nl	info@smc.nl
Norway	+47 67129020	www.smc-norge.no	post.no@smc.com
Poland	+48 22 344 40 00	www.smc.pl	office.pl@smc.com
Portugal	+351 214724500	www.smc.eu	apoiocliente.pt@smc.com
Romania	+40 213205111	www.smcromania.ro	office.ro@smc.com
Russia	+7 (812)3036600	www.smc.eu	sales@smcru.com
Slovakia	+421 (0)413213212	www.smc.sk	sales.sk@smc.com
Slovenia	+386 (0)73885412	www.smc.si	office.si@smc.com
Spain	+34 945184100	www.smc.eu	post.es@smc.com
Sweden	+46 (0)86031240	www.smc.nu	order.se@smc.com
Switzerland	+41 (0)523963131	www.smc.ch	helpcenter.ch@smc.com
Turkey	+90 212 489 0 440	www.smcturkey.com.tr	satis.tr@smc.com
UK	+44 (0)845 121 5122	www.smc.uk	sales.gb@smc.com
South Africa	+27 10 900 1233	www.smcza.co.za	Sales.za@smc.com