


Nº	CODE	DESCRIPTION	Nº	CODE	DESCRIPTION
1	P82501	AIR INLET	24	P82523	PIN (6)
2	P82502	EXHAUST SLEEVE	25	P82524	GEAR PLATE (2)
3	P82503	PIN	26	P82525	GEAR SHAFT
4	P82504	HOUSING	27	P82526	SHAFT
5	P82505	SPRING	28	P82527	BEARING (2)
6	P82506	O-RING	29	P82528	CLAMP NUT
7	P82507	VALVE STEM	30	P82529	WASHER
8	P82508	O-RING	31	BP82530	KEYLESS CHUCK 1/2"
9	BP82509	REVERSE LEVER	32	P82531	CHUCK SCREW
10	BP82510	TRIGGER	33	P82532	BUSHING
11	P51104	O-RING	34	P82533	O-RING
12	P82511	BEARING	35	P82534	HANDLE LINK
15	P82514A	CYLINDER ASSY	36	P82535	HANDLE
16	P82515	ROTOR	37	P82536	PACKING
17	P82516	ROTOR BLADE (4)	38	P82537	MUFFLER
18	P82517	GEAR LINK	39	P82538	NEEDLE BEARING (6)
20	P82519	BEARING	40	P82539	VALVE STEM
21	P82520	WASHER	41	BP82540	VALVE STEM BUSHING
22	P82521	GEAR LINK	42	P82541	O-RING
23	P82522	GEAR (6)			



BP825

Revision: 00



SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

14072022