


Instructions

Magnetic ballast: Remove the starter and any power factor capacitor. Plug in the LED 2D lamp directly into the socket.

Electronic ballast: Bypass the electronic ballast and plug in the LED 2D lamp directly to the socket.

* Average life of 30,000 hrs ** Average saving on electricity cost over the life time of the lamp based on £0.10 per unit (kWh)



Non Dimmable

