# Series HRS **Optional Accessories**

## **Applicable Model List/Air-Cooled Refrigeration**

No.	Description		Part no.	HRS012-A HRS018-A		HRS024-A-20	HRS030-A-20	HRS050-A-20 HRS060-A-20	Option		Page
				-10	-20			TIN-3000-A-20	(for -J)	(for -T)	
1	Anti-quake bracket		HRS-TK001	•	•	•	•	_		_	29
	Anti-quake bracket		HRS-TK002	_	_	_	_	•		_	29
2		G thread conversion fitting set	HRS-EP001	•	•	•	•	_		_	29
	Piping conversion fitting	NPT thread conversion fitting set	HRS-EP002	•	•	•	•	_	_		
	(for air-cooled refrigeration)	G thread conversion fitting set	HRS-EP009	_	_	_	_	•	_	_	
		NPT thread conversion fitting set	HRS-EP010	_	_	_	_	•	_	_	
3	Piping conversion fitting Note 1) (for automatic water fill port)	G thread conversion fitting set	HRS-EP005	_	_	_	_	_	•	_	- 30
		NPT thread conversion fitting set	HRS-EP006	_	_	_	_	_	•	_	
(J)	Piping conversion fitting Note 2)	G thread conversion fitting set	HRS-EP007	_	_	_	_	_	_	•	
	(for drain outlet)	NPT thread conversion fitting set	HRS-EP008	_	_	_	_	_	_	•	
4	Concentration meter		HRZ-BR002	•	•	•	•	•	•	•	31
(E)	Dungag nining get		HRS-BP001	•	•	•	•	_	_		- 31
(5)	Bypass piping set		HRS-BP004	_	_	_	_	•	_	_	
		For single-phase 100/115 VAC type	HRS-CA001	•	_	_	_	_	_		
	Dawan awantu aatu	For single-phase 200 VAC type	HRS-CA002	_	•	•	•	Note 3)	_	_	
6	Power supply cable	For single-phase 100/115 VAC type	HRS-CA003	•	_	_	_	_	_	_	32
		For single-phase 200 VAC type	HRS-CA004	_	_	_	_	Note 4)	_	_	
	Retaining clip		HRS-S0074	•	•	•	•	_	_	_	
	DI CII		HRS-DP001	•	•	•	•	•	_	_	- 33
7	DI filter set		HRS-DP002	•	•	•	•	•	_	_	
			HRS-DI001	•	•	•	•	•	_		34
	Electrical resistance	With control function/bypass	HRS-DI003	•	•	•	•	•	_	_	
8	sensor set	With bypass	HRS-DI004	•	•	•	•	•	_	_	
		With control function	HRS-DI005	•	•	•	•	•	_	_	
		(#5) OUT side	HRS-PF001	•	•	•	•	•	_	_	35
	Particle filter set	(#10) OUT side	HRS-PF002	_	_	_	_	•			
9		(#5) IN side	HRS-PF003	•	•	•	•	•	_	_	
		(#10) IN side	HRS-PF004	l —	_	_	_	•	_	_	
			HRS-WL001	•	•	•	•	_	_		
(10)	Drain pan set	With water leakage sensor	HRS-WL002	l —	_	_	_	•	_	_	36
	Connector cover		HRS-BK001	•	•	•	•	_	_		
(1)			HRS-BK002	_	_	_	_	•	_		37
12	Analog gateway unit		HRS-CV001	•	•	•	•	•	_		37
_	Replacement type dustproof filter set		HRS-FL001	•	•	•	_	_	_	_	
13	Replacement type dustproof filter		HRS-FL002	•	•	•	_	_	_		37
			IDF-TR1000-1	•	_	_	_		_	_	
			IDF-TR1000-2	•	_	_	_		_		
			IDF-TR1000-3	•	_	_	_		_	_	
14)	Separately installed		IDF-TR1000-4	•	_	_	_	Note 3)	_		38
	power transformer		IDF-TR2000-9	<u> </u>	•	•	•		_		
			IDF-TR2000-10	<u> </u>	•	•	•		_		
			IDF-TR2000-11	_	•	•	•		<u> </u>		

Note 1) When option J is selected.

Note 2) When option T or the HRS050/060 is selected.

Note 3) For the HRS050/060 models: To be prepared by user.

Note 4) Not applicable for the HRS060-A

-20. To be prepared by user.




# Series HRS

#### 11 Connector Cover

Protects the connector on the rear side.

Applicable model		
HRS012-□□-□		
HRS018-□□-□		
HRS024-□□-□		
HRS030-□□-□		



Part no.	Applicable model	
HRS-BK002	HRS050-□□-□	
IING-DR002	HRS060-□□-□	
	80	
	, and the second	

## 12 Analog Gateway Unit

This is an expansion unit for adding analog communication functions.

"Analog communication, contact input/output" functions can be used.

#### ● Analog communication

The set circulating fluid temperature can be changed by entering the analog voltage.

Converts the current circulating fluid temperature and current electrical resistance value (\*1) to an analog voltage for output.

\*1: Displayed when optional "Electrical resistance sensor set/HRS-DI001, DI003, DI004 and DI005" are used.

#### Contact input/output

The Run/Stop of the thermo-chiller HRS series can be operated by a contact signal.


The contact signal of the operation status, alarm occurrence status and the TEMP READY status can also be output.

Part no.	Applicable model		
HRS-CV001	HRS012-□□-□		
	HRS018-□□-□		
	HRS024-□□-□		
	HRS030-□□-□		
	HRS050-□□-□		
	HRS060-□□-□		

#### **Parts List**

No.	Description		
1	Analog gateway box		
2	Connection cable		
3	Mounting bracket		
4	Mounting screw (M3, 2 pcs.)		

When this product is used, the "contact input/output" and "serial communication" functions standardly equipped in the thermo-chiller HRS series cannot be used.



### (13) Replacement Type Dustproof Filter Set

A disposable dustproof filter is mounted instead of the dustproof net on the front panel.

Part no.	Applicable model			
HRS-FL001	HRS012-A□-□ HRS018-A□-□			
1110 1 2001	HRS024-A□-□			

#### **Parts List**

No.	Description	Part no.	Note
1	Replacement type dustproof filter set	HRS-FL001	Front panel with hook-and-loop fastener for holding filter 5 filters are included.  (No dustproof net is included.)
2	Replacement type dustproof filter	HRS-FL002	5 filters per set Size: 300 x 370

