# Standard/Replacement Parts/Seal Kit

When ordering the replacement parts (seal kits) for standard style Series CS1 air cylinders, indicate the order number listed in the table on the right.

Each set of replacement parts contains the following: Wiper ring, rod seal, piston seal, valve seal, tube gasket, and push plate gasket (for 1 cylinder).

#### Standard (Lube)

Bore size(mm)	Kit no.	Description
125	CS1-125A-PS	
140	CS1-140A-PS	
160	CS1-160A-PS	
180	CS1-180A-PS	Component part numbers: 23, 25, 26, 27, 28, 30
200	CS1-200A-PS	
250	CS1-250A-PS	
300	CS1-300A-PS	

 $<sup>\</sup>ast$  Seal kit includes a grease pack (ø125 to 160: 40 g, ø180 and 200: 50 g, ø250 and 300: 60 g). Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g), GR-S-020 (20 g)

## Standard (Non-lube)

Bore size(mm)	Kit no.	Description
125	CS1N125A-PS	
140	CS1N140A-PS	
160	CS1N160A-PS	
180	CS1N180A-PS	Component part numbers: ②, ②, ②, ②, ②, ③
200	CS1N200A-PS	
250	CS1N250A-PS	
300	CS1N300A-PS	

<sup>\*</sup> Seal kit includes a grease pack (ø125 to 160: 40 g, ø180 and 200: 50 g, ø250 and 300: 60 g). Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g), GR-S-020 (20 g)

#### Air-hydro

Bore size(mm)	Kit no.	Description
125	CS1H125A-PS	
140	CS1H140A-PS	Component part numbers: ②, ②, ②, ②, ②, ③
160	CS1H160A-PS	

## **Low Friction**

Bore size(mm)	Kit no.	Description
125	CS1Q125A-PS	
140	CS1Q140A-PS	Component part numbers: 3, 2, 26, 26, 27, 39, 30
160	CS1Q160A-PS	

<sup>\*</sup> Since the seal kit does not include a grease pack, order it separately. Grease pack part no.: GR-L-020 (20 g)

