
## Series **SY3000/5000**

## **Valve Replacement Parts 1**

## **How to Order Port Block Assembly**



One-touch fitting (Metric)

one todon name (means)					
Symbol	Port size	Applicable series			
		SY3000	SY5000		
C2	C2 ø2 One-touch fitting		_		
C3	ø3.2 One-touch fitting	•	_		
C4	ø4 One-touch fitting	•	•		
C6	ø6 One-touch fitting	•	•		
C8 ø8 One-touch fitting		_	•		

One-touch fitting (Inch)

0	Symbol	Port size	Applicable series	
3			SY3000	SY5000
	N1 ø1/8" One-touch fitting		•	_
	N3	ø5/32" One-touch fitting	•	•
	N7	ø1/4" One-touch fitting	•	•
	N9 ø5/16" One-touch fitting		_	•


Possible to replace only the one-touch fitting.

Port size		SY3000	SY5000
	ø2 One-touch fitting	VVQ1000-50A-C2	_
	ø3.2 One-touch fitting	VVQ1000-50A-C3	_
Metric size	ø4 One-touch fitting	VVQ1000-50A-C4	VVQ1000-51A-C4
	ø6 One-touch fitting	VVQ1000-50A-C6	VVQ1000-51A-C6
	ø8 One-touch fitting	_	VVQ1000-51A-C8
	ø1/8" One-touch fitting	VVQ1000-50A-N1	_
Inch size	ø5/32" One-touch fitting	VVQ1000-50A-N3	VVQ1000-51A-N3
	ø1/4" One-touch fitting	VVQ1000-50A-N7	VVQ1000-51A-N7
	ø5/16" One-touch fitting	_	VVQ1000-51A-N9

Refer to pages 156 and 157 for how to replace the port block assembly, one-touch fitting and body cover assembly.

## **Body Cover Assembly**

\* Used when the top ported is changed to the side or bottom ported.



	Corios	Part no.		
Series		Standard (Valve mounting screw "not" falling-out-prevention type)	Valve mounting screw falling-out-prevention type	
SY3000	Internal pilot	SY30V-16A	SY30V-16A-1	
513000	External pilot	SY30V-16AR	SY30V-16AR-1	
CVEOO	Internal pilot	SY50V-16A	SY50V-16A-1	
SY5000	External pilot	SY50V-16AR	SY50V-16AR-1	

