


How to Order Valves



A Type of actuation

1	2 position single  (A) (B) 4 2 5 1 3 (R1) (P) (R2)	4	3 position exhaust center  (A) (B) 4 2 5 1 3 (R1) (P) (R2)
2	2 position double (metal)  (A) (B) 4 2 5 1 3 (R1) (P) (R2)	5	3 position pressure center  (A) (B) 4 2 5 1 3 (R1) (P) (R2)
	2 position double (rubber)  (A) (B) 4 2 5 1 3 (R1) (P) (R2)	6	3 position perfect  (A) (B) 4 2 5 1 3 (R1) (P) (R2)
3	3 position closed center  (A) (B) 4 2 5 1 3 (R1) (P) (R2)		

B Seal type

0	Metal seal
1	Rubber seal

C Function

Nil	Standard type (1 W)
R	External pilot
Y	Low wattage type (0.5 W)

Note 1) When specifying more than one option, enter symbols in alphabetical order.

Note 2) Please select when you expect to energize the unit for extended periods of time. Refer to page 3 for details.

D Coil voltage

5	24 VDC Note)
6	12 VDC


Note) S kit is only available for 24 VDC.

E Light/Surge voltage suppressor

Nil	With
E	Without light, with surge voltage supressor

F Manual override

Nil: Non-locking push type (Tool required)



B: Locking type (Tool required)

