


Component Parts for Manifold



(1)

Stations	Manifold part no.	Clamp rod part no.
1	ZZM01-□□□□-□	ZZM-CR-01
2	ZZM02-□□□□-□	ZZM-CR-02
3	ZZM03-□□□□-□	ZZM-CR-03
4	ZZM04-□□□□-□	ZZM-CR-04
5	ZZM05-□□□□-□	ZZM-CR-05
6	ZZM06-□□□□-□	ZZM-CR-06
7	ZZM07-□□□□-□	ZZM-CR-07
8	ZZM08-□□□□-□	ZZM-CR-08
9	ZZM09-□□□□-□	ZZM-CR-09
10	ZZM10-□□□□-□	ZZM-CR-10

(2)

Manifold part no.	Adapter A		Adapter B		Silencer		Blanking plate	
	Left	Right	Left	Right	Left	Right	Left	Right
ZZM□□-□04R-□		○					○	
ZZM□□-□04L-□	○							○
ZZM□□-□04B-□	○	○						
ZZM□□-□06R-□				○			○	
ZZM□□-□06L-□			○					○
ZZM□□-□06B-□			○	○				
ZZM□□-□SR-□						○	○	
ZZM□□-□SL-□					○			○
ZZM□□-□SB-□					○	○		
ZZM□□-□00							○	○

(3)

No.	Model	Description	Quantity	Note
1	ZZM-SA	Silencer assembly	*	
2	ZZM-BP	Blanking plate assembly	*	
3	ZZM-ADA-□	Adapter A assembly	*	Note 1)
4	ZZM-ADB-□	Adapter B assembly	*	Note 1)
5	ZZM-GE	Gasket E	2	
6	ZZM-EPL-□	End plate L	1	Note 1)
7	ZZM-GBL	Gasket BL	1	
8	ZZM-GBB	Gasket BB	Station: 1	
9	ZZM-GBR	Gasket BR	1	
10	ZZM-EPR-□	End plate R	1	
11	ZZM-CR-□□	Clamp rod	1	Refer to Table (1), Note 2)

* The used quantity varies depending on the part number.

Note 1) □: Symbol corresponding to the port thread type.

Note 2) 2pcs. are included in one set.

ZA

ZX

ZR

ZM

ZMA

ZQ

ZH

ZU

ZL

ZY□

ZF□

ZP□

SP

ZCUK

AMJ

AMV

AEP

HEP

Related
Equipment