


CHAIN AND STRAP WRENCHES

■ 138A - Nylon strap wrenches



- Capacity: 0 to 165 mm.
- Body in aluminum alloy.
- High strength nylon strap.



	A [mm]	A ["]	E [mm]	E1 [mm]	L [mm]	L1 [mm]	ΔΔ [g]
138A.17	60	2	42	27,5	300	450	280
138A.30	125	4	42	27,5	300	760	290
138A.48	165	6	42	27,5	300	1200	310

■ 138.S - Spare strap




- To be used with the nylon strap wrench.
- 138.S17: spare strap L.430 mm for 138A.17.
- 138.S30: spare strap L.760 mm for 138A.30.
- 138.S48: spare strap L.1200 mm for 138A.48.



	ΔΔ [g]
138.S17	26
138.S48	44
138.S30	74

PIPE BENDERS

■ 344B - Bending pliers



- Capacity: 8 to 18 mm.
- To shape pipes in cold drawn or annealed copper.
- Easy use on the work place without particular installation.
- Bending angle measurement (0° - 180°).
- Can be carried on a tool box.
- Made in forged and machined steel.



	A ["]	A [mm]	L [mm]	L1 [mm]	ΔΔ [kg]
344B.8	5/16	8	208	14	0.340
344B.10	-	10	245	23	0.700
344B.12	-	12	270	30	0.900
344B.14	-	14	352	42	1.800
344B.16	5/8	16	380	54	2.640
344B.18	-	18	380	55	2.900