

1/2" Socket Drivers for TORX® Head Screws



7809TORX_L

T40	82	5	7809TORX-T40-120
T45	80	1	7809TORX-T45-120
T50	62	1	7809TORX-T50-100
T55	102	5	7809TORX-T55-140
T70	102	5	7809TORX-T70-140

1/2" Square Drive Socket Driver Set for TORX® Head Screw



7809TO

9		1	7809TO

7809TORX-T20, 7809TORX-T25,
7809TORX-T27, 7809TORX-T30,
7809TORX-T40, 7809TORX-T45,
7809TORX-T50, 7809TORX-T55,
7809TORX-T60

1/2" Square Drive Socket Drive Set for Torx® Head Screws - 9 pcs



7800TORX/9

800		1	7800TORX/9

7800TORX-E8, 7800TORX-E10,
7800TORX-E11, 7800TORX-E12,
7800TORX-E14, 7800TORX-E16,
7800TORX-E18, 7800TORX-E20,
7800TORX-E24

1/2" Square Drive Socket Drivers for Hex Head Screw



7809M

4 mm		1	7809M-4
5 mm		1	7809M-5
6 mm		1	7809M-6
7 mm		1	7809M-7
8 mm		1	7809M-8
9 mm		1	7809M-9
10 mm		1	7809M-10
12 mm		1	7809M-12
14 mm		1	7809M-14
17 mm		1	7809M-17
19 mm		1	7809M-19
4 mm		1	SB7809M-4
5 mm		1	SB7809M-5
6 mm		1	SB7809M-6
7 mm		1	SB7809M-7
8 mm		1	SB7809M-8
9 mm		1	SB7809M-9
10 mm		1	SB7809M-10
12 mm		1	SB7809M-12
14 mm		1	SB7809M-14
17 mm		1	SB7809M-17
19 mm		1	SB7809M-19

SB: Retail pack on a plastic info card

1/2" Socket Drivers for Hex Head Screws



7809M_L

5 mm	61	1	7809M-5-100
5 mm	143	1	7809M-5-180
6 mm	59	1	7809M-6-100

6 mm	103	1	7809M-6-140
7 mm	63	1	7809M-7-100
8 mm	83	1	7809M-8-120
10 mm	103	1	7809M-10-140
5 mm	63	1	SB7809M-5-100
5 mm	140	1	SB7809M-5-180
6 mm	62	1	SB7809M-6-100
6 mm	103	1	SB7809M-6-140
7 mm	63	1	SB7809M-7-100
8 mm	81	1	SB7809M-8-120
10 mm	101	1	SB7809M-10-140

1/2" Square Drive Socket Driver Set for Hex Head Screw



7808HM

8		1	7808HM

7809M-4, 7809M-6, 7809M-8,
7809M-7, 7809M-5, 7809M-10,
7809M-12, 7809M-14

1/2" Square Drive Socket Drivers for Imperial Hex Head Screw



7809Z

3/16 mm		1	7809Z-3/16
1/4 mm		1	7809Z-1/4
5/16 mm		1	7809Z-5/16
3/8 mm		1	7809Z-3/8
7/16 mm		1	7809Z-7/16
1/2 mm		1	7809Z-1/2
17/32 mm		1	7809Z-17/32
9/16 mm		1	7809Z-9/16
19/32 mm		1	7809Z-19/32
5/8 mm		1	7809Z-5/8

