
# Series VF3000/5000

#### How to Order Pilot Valve Assembly (With a gasket and two mounting screws)



When only the pilot valve assembly is replaced, it is not possible to change from V211 (Grommet or L/M-type) to V212 (DIN or Conduit type), or vice versa.



## **!** Caution

For V212 (DIN or Conduit type), the coil specifications and voltage (including light/surge voltage suppressor) cannot be changed by replacing the pilot valve assembly.



Tightening torque of the pilot valve assembly mounting screw M2.5: 0.24 lbf·ft (0.32 N·m)




#### **Dimensions: Series VF3000/Base Mounted**


(mm)

#### 2-position single

Grommet (G) (H): VF3140-□<sup>G</sup><sub>H</sub>□□1-<sup>02</sup><sub>03</sub>□



## L-type plug connector (L): VF3140-\(\subseteq\)L\(\subseteq\)1-\(\frac{02}{03}\)




Unless otherwise indicated, dimensions are the same as Grommet (G).

# 


Unless otherwise indicated, dimensions are the same as Grommet (G).

## M-type plug connector (M): VF3140- $\square$ M $\square$ 1- $^{02}_{03}$ $\square$



Unless otherwise indicated, dimensions are the same as Grommet (G).

## Conduit terminal (T): VF3140-□ T □□1-02 □



[ ]: Without indicator light Unless otherwise indicated, dimensions are the same as Grommet (G).

