Voltage Monitor for PFMV5 Series PFMV3

()



How to Order

Instruction manual

| Nil | With instruction manual (Leaflet: Japanese and English) |
|-----|---|
| N | None |

Calibration certificate

| Nil | None |
|-----|------------------------------|
| Α | With calibration certificate |

The certificate is written in both English and Japanese. Please consult with us for other languages.

PFMV300-ML

Type

3 Remote display unit

Input specification •

| Symbol | | Content | Applicable remote type sensor unit | |
|--------|---|---------------|---------------------------------------|--|
| | 0 | Voltage input | PFMV5□(F)-1-□□ | |

Output specification

| 0 | 2 NPN outputs + 1 to 5 V output |
|---|-----------------------------------|
| 1 | 2 NPN outputs + 4 to 20 mA output |
| 2 | 2 NPN outputs + Auto-shift input |
| 3 | 2 PNP outputs + 1 to 5 V output |
| 4 | 2 PNP outputs + 4 to 20 mA output |
| 5 | 2 PNP outputs + Auto-shift input |

Option 1

| Nil | None |
|-----|---|
| L | Power supply / Output connector Power supply / Output connector ZS-28-A |


Note) Cable is shipped together, but not connected.

The PFMV3 series is a monitor that displays the output voltage of the PFMV5 series.

Option/Part No.

| Description | Part no. | Note |
|--|----------|------------------------|
| Power supply / Output connector (2 m) | ZS-28-A | |
| Bracket | ZS-28-B | With M3 x 5 ℓ (2 pcs.) |
| Sensor connector | ZS-28-C | 1 pc. |
| Panel mount adapter | ZS-27-C | With M3 x 8 ℓ (2 pcs.) |
| Panel mount adapter + Front protective cover | ZS-27-D | With M3 x 8 ℓ (2 pcs.) |

Option 3



Note) Connector is shipped together, but not connected.

Option 2

| Option 2 | | |
|----------|---|--|
| Nil | None | |
| E | Bracket M3 x 5 t Bracket | |
| В | Panel mount adapter Panel Mounting screw (M3 x 8 t) | |
| D | Panel mount adapter + Front protective cover Panel Front protective cover Mounting screw (M3 x 8 t) | |

Note) Options are shipped together, but not assembled.

