Peltier-Type Chiller Thermo-con Air-cooled Water-cooled

Can precisely control the temperature of a heat source or process fluid.

Precisely control the temperature of the circulating fluid by using the Peltier device. Generates little vibration, and is refrigerant-free and environmentally friendly. Can control the temperature of the heat source by using the external temperature sensor (sold separately). (Automatically adjusts to the effects of ambient temperature.)



Water-cooled Series HEC-W

- Water-cooled: Can be used in the environments with facility water equipment.
- Cooling capacity: 140 W, 320 W, 600 W, 1200 W Circulating



CAT.EUS40-49Aa-UK

Series HEC

1

- Compliant with safety standard for medical equipment IEC 60601-1 (Air-cooled/HEC002-A series)
- Power supply: Applicable to 100 V to 240 V (Air-cooled/HEC-A series, Water-cooled/HEC001-W, HEC003-W)
- Suitable to fluorinated fluids (Fluorinert[™] FC-3283, GALDEN[®] HT135) (Water-cooled/HEC006-W, HEC012-W)
- Compatible with ethylene glycol 20% (Water-cooled/HEC001-W, HEC003-W)

Learning Control Function (Temp. control by external temperature sensor)

This function adjusts the fluid temperature to the set value with an automatic offset setting. Set the external temperature sensor at the circulating fluid inlet located just in front of the heat source, which allows the Thermo-con to sample the fluid temperature. This function is effective when automatically adjusting for heat exhaust from piping, etc. If the external temperature sensor is installed directly on the heat source, the learning control function may not work property due to large heat volume or large temperature difference. Be sure to install the sensor at the circulating fluid inlet.

Principle of Peltier Device (Thermo-module)

A Peltier device (thermo-module) is a plate type element, inside which P-type semiconductors and N-type semiconductors are located alternately. If direct current is supplied to the Peltier device (thermo-module), heat is transferred inside the device, and one face generates heat and increases temperature while the other face absorbs heat and decreases temperature. Therefore, changing the direction of the current supplied to the Peltier device (thermo-module) can achieve heating and cooling operation. This method has a fast response and can shift quickly between heating and cooling, so temperature can be controlled very precisely.



SMC



Target of

control

Thermo-con

temperature

SMC



The circulating fluid returns to the tank, and is transferred by the pump which is built in the Thermo-con, and goes through the heat exchangers and internal sensors and out from the circulating fluid outlet.

Figure 2 shows an example of circulating fluid piping. The circulating fluid is transferred at a constant temperature by the pump.

2

Series HEC

When to Use Air-Cooled and Water-Cooled Thermo-con

Both air-cooled and water-cooled Thermo-cons are available. Select a proper Thermo-con by referring to the following.

Air-cooled

- No facility water equipment
- Frequent piping changes
- Can install the unit easily without facility water equipment. Can reduce the piping installation labour since facility

Water-cooled

- · Need to avoid effects of ambient temperature.
- Since the unit is water-cooled, the ambient temperature will have little effect.
- Want to reduce the installation space.
- Can reduce the space since the unit is compact.

water piping is not required.



CONTENTS

• Features ······Page 1 to	3
Model Selection Page 5, 6	



Air-cooled *Series HEC-A*

- How to Order/Specifications-----Page 7
- Cooling Capacity/Heating Capacity/ Pump Capacity (Thermo-con Outlet)······Page 8
 Parts Description·····Page 9
- Dimensions ······Page 10, 11
- Connectors ------ Page 12
- Alarm/Maintenance·····Page 13
- Options ·····Page 14
- Specific Product Precautions ----- Page 15 to 17



Water-cooled Series HEC-W

- How to Order/Specifications-----Page 19, 20
- Cooling Capacity/Heating Capacity/ Pump Capacity (Thermo-con Outlet)/ Pressure Loss in Facility Water Circuit ···· Page 21 to 23
 Parts Description ···· Page 24
 Dimensions ···· Page 25 to 27
 Connectors ··· Page 28
 Alarm/Maintenance ··· Page 29
- Options ·····Page 30
- Specific Product Precautions ----- Page 31, 32



Series HEC Model Selection

Guide to Model Selection

1. What radiation method will be used?

Without a cooling tower Air-cooled HEC-A series With a cooling tower Water-cooled HEC-W series

When to Use Air-cooled and Water-cooled Thermo-con

<Air-cooled>

- No facility water equipment → Can install the unit easily without facility water equipment.
- Frequent piping changes \rightarrow Can reduce the piping installation labor since facility water piping is not required.
- <Water-cooled>
 - Need to avoid effects of ambient temperature. → Since the unit is water-cooled, the ambient temperature will have little effect.
 - \bullet Want to reduce installation space. \rightarrow Can reduce the space since the unit is compact.

2. How much is the temperature in degrees centigrade for the circulating fluid?

Temperature range which can be set with the Thermo-con: 10 to 60°C

If a lower temperature (down to -20° C) or higher temperature (up to 90° C) than this range is necessary, select the Thermo-chiller HRZ series.

3. What kind of the circulating fluids will be used?

Circulating fluids that can be used in the Thermo-con

Model	Clear water	Fluorinert [™] FC-3238 GALDEN [®] HT135	20% ethylene glycol
HEC001-W, HEC003-W	0	×	0
HEC006-W, HEC012-W	0	0	×
HEC002-A, HEC006-A	0	×	×

 \bigcirc : Usable \times : Unusable

4. How much cooling capacity required?

Allows a safety factor of 20% over the capacity that is actually required, taking into account the changes in the operating conditions. If a larger capacity than this Thermo-con is necessary, select the Thermo-cooler HRG series or Thermo-chiller HRZ series.

Example 1 When the heat generation amount in the customer's machine is known.

Heat generation amount: 400 W

Cooling capacity = Considering a safety factor of 20%, 400 x 1.2 = 480 W

After 15 min, cool 30°C down to 20°C.

Guide to Model Selection





 Cooling time h
 : 15 min

 Cooling temperature difference ΔT
 : Temperature difference: 10°C (10 K). Cool from 30°C (303 K) to 20°C (293 K).

 Circulating fluid
 : Clear water

 Density γ: 1 x 10³ kg/m³
 Specific heat C: 4.2 x 10³ J/(kg-K)

 * Refer to the information shown below for the typical physical property values by circulating fluid.
 Water bath

 ΔT x V x γ x C
 20°C

 $Q = \frac{\Delta T \times V \times \gamma \times C}{h \times 60 \times 1000}$ $= \frac{10 \times 20 \times 1 \times 10^{3} \times 4.2 \times 10^{3}}{15 \times 60 \times 1000}$

= 933 W

Cooling capacity = Considering a safety factor of 20%, 933 W x 1.2 = 1120 W

Precautions on Model Selection

The flow rate of the circulating fluid depends on the pressure loss of the customer's machine and the length, diameter and resistance created by bends in the circulating fluid piping, etc. Check if the required flow rate of circulating fluid can be obtained before selecting.

Circulating Fluid Typical Physical Property Values

Fluorinated Fluids

Physical property	Density γ	Specific heat C	
Temperature value	[kg/m³]	[J/(kg · K)]	
-10°C	1.87 x 10 ³	0.87 x 10 ³	
20°C	1.80 x 10 ³	0.96 x 10 ³	
50°C	1.74 x 10 ³	1.05 x 10 ³	
80°C	1.67 x 10 ³	1.14 x 10 ³	

Water

Density γ : 1 x 10³ [kg/m³]

Peltier-Type Chiller Thermo-con (Air-cooled) Series HEC-A





Specifications (For details, please consult our "Product Specifications" information.)

Model		el	HEC002-A5A	HEC002-A5B	HEC006-A5A	HEC006-A5B
С	ooling method	oling method Thermoelectric device (Thermo-module)				
Ra	adiating metho	d	Forced air cooling			
С	ontrol method			Cooling/Heating auton	natic shift PID control	
A	mbient tempera	ature/humidity	10 to 35°C, 35 to 80%RH (no condensation)			
	Circulating flu	Jid		Clear	water	
_	Operating tem	perature range		10.0 to 60.0°C (n	o condensation)	
system	Cooling capa	city	230 W	Note 1)	600 W	/ Note 2)
sys	Heating capa	city	600 W	Note 1)	900 W	/ Note 2)
DINI	Temperature	stability Note 3)		±0.01 to :	±0.03°C	
	Pump capacit	y	Refer to performance chart.			
Pump capacity Tank capacity Port size IN/OUT		1	Approx. 1.2 L			
כ	Port size	IN/OUT	Rc	1/4	Rc	3/8
		Drain		Rc1/4 (w	ith plug)	
Wetted parts material		material	Stainless steel 303, Stainless steel 304, EPDM, Ceramics, PPS glass 30%, Carbon, PE, Polyurethane			
E Power supply		,	Single-phase 100 to 240 VAC ±10%, 50/60 Hz			
Power supply Overcurrent protector		protector		15	A	
		umption	8 A (100 VAC) to 3 A (240 VAC) 10 A (100 VAC) to 4 A (to 4 A (240 VAC)	
Current consumption				Refer to alar	m function.	
Communications		ons	RS-485	RS-232C	RS-485	RS-232C
w	eight		Approx. 17.5 kg (including foot for fixing) Approx. 27.5 kg (including foot for fixing)		luding foot for fixing)	
A	ccessories		Power cable, Foot for fixing			
Safety standards			CE marking, UL (N Safety standard for medica		CE marking, UL (NRTL) standards

Note 1) Conditions: Set temperature 25°C, Ambient temperature 25°C, Circulating flow rate 3 L/min Note 2) Conditions: Set temperature 25°C, Ambient temperature 20°C, Circulating flow rate 8 L/min

Note 3) The indicated values are with a stable load without turbulence in the operating conditions. It may be out of this range in some other operating conditions.



Peltier-Type Chiller Thermo-con (Air-cooled) Series HEC-A





Cooling Capacity

Heating Capacity



Pump Capacity (Thermo-con Outlet)





70

Series HEC-A

Parts Description







Peltier-Type Chiller Thermo-con (Air-cooled) Series HEC-A

Dimensions **HEC002** 358 2 4 x Plastic foot 1 29 152 External temperature Alarm output connector sensor connector Communication connector 298 Tank lid 145 with gasket Power cable Power Model no. label connector 101 (Accessory) Handle 145 Handle 51 60 Air ⊄> Air ⊳ 49 • 000000 (13) . •**`** -Circulating ŎŀŔŔŔŔŔŔŔŔ fluid outlet 393 385 347 Rc1/4 270 300 347 Air ⊄> Air ⇔ 281 97 157 270 8 ¢ ŝ L 321 12 Circulating Circulating fluid 364 fluid level gauge drain port (with plug) Rc1/4 Foot (Accessory) Filter cover Circulating fluid inlet Filter Rc1/4 436 414 46 300 R400 240 270 210 42 5 A + 02 390 Power switch Warning/Caution label /Display/Operation panel **Option (Fitting part)** Power cable (Accessory) NPT fitting specification (-N, -FN) Connector: IEC60320 C13 or equivalent Cable: 14AWG, O.D. ø8.4 Circulating fluid outlet NPT1/4



Wire colour	Contents
Black	100 to 240 VAC
Black	100 to 240 VAC
Green/Yellow	PE



Series HEC-A

Dimensions

HEC006





Connector: IEC 60320 C13 or equivalent Cable: 14AWG, O.D. ø8.4

Wire colour	Contents
Black	100 to 240 VAC
Black	100 to 240 VAC
Green/Yellow	PE



Peltier-Type Chiller Thermo-con (Air-cooled) Series HEC-A

Connectors

1. Power connector (AC) IEC 60320 C14 or equivalent

Pin No.	Contents
1	100 to 240 VAC
2	100 to 240 VAC
3	PE

2. Communication connector (RS-232C or RS-485) D-sub 9 pin (socket) Holding screw: M2.6

Pin No.	Signal contents		
FIII NU.	RS-232C	RS-485	
1	Unused	BUS+	
2	RD	BUS-	
3	SD	Unused	
4	Unused	Unused	
5	SG	SG	
6-9	Unused	Unused	

3. External sensor connector (EXT.SENSOR) D-sub 15 pin (socket) Holding screw: M2.6

Pin No.	Signal contents
1-2	Unused
3	Terminal A of resistance temperature detector
4	Terminal B of resistance temperature detector
5	Terminal B of resistance temperature detector
6-14	Unused
15	FG

4. Alarm output connector (ALARM) D-sub 9 pin (pin) Holding screw: M2.6

Pin No.	Signal contents	
1	Contact a for output cut-off alarm (open when alarm occurs)	
2	Common for output cut-off alarm	
3	Contact b for output cut-off alarm (closed when alarm occurs)	
4-5	Unused	
6	Contact a for upper/lower temp. limit alarm (open when alarm occurs)	
7	Common for upper/lower temp. limit alarm	
8	Contact b for upper/lower temp. limit alarm (closed when alarm occurs)	
9	Unused	









Series HEC-A

Alarm

This unit is equipped as standard with a function allowing 15 kinds of alarms to display on the LCD and can be read out by serial communication. Also, it can generate relay output for upper/lower temperature limit alarm and output cut-off alarm.

Alarm

Alarm code	Alarm description	Operation status	Main reason
WRN	Upper/Lower temp. limit alarm	Continue	The temperature has exceeded the upper or lower limit of the target temperature.
ERR00	CPU hung-up	Stop	The CPU has crashed due to noise, etc.
ERR01	CPU check error	Stop	The contents of the CPU cannot be read out correctly when the power supply is turned on.
ERR03	Back-up data error	Stop	The contents of the back-up data cannot be read out correctly when the power supply is turned on.
ERR04	EEPROM writing error	Stop	The data cannot be written to EEPROM.
ERR11	DC power supply failure	Stop	The DC power supply has failed (due to fan stop or abnormal high temperature) or the thermo-module has been short-circuited.
ERR12	Internal temp. sensor high temp. error	Stop	The internal temperature sensor has exceeded the upper limit of cut-off temperature.
ERR13	Internal temp. sensor low temp. error	Stop	The internal temperature sensor has exceeded the lower limit of cut-off temperature.
ERR14	Thermostat alarm	Stop	The thermostat has been activated due to filter clog or fan/pump failure, etc.
ERR15	Abnormal output alarm	Continue	The temperature cannot be changed even at 100% output due to overload or disconnection of the thermo-module.
ERR16	Low flow rate alarm (option)	Stop	The flow rate of the circulating fluid has dropped.
ERR17	Internal temp. sensor disconnection alarm	Stop	The internal temperature sensor has been disconnected or short-circuited.
ERR18	External temp. sensor disconnection alarm	Continue	The external temperature sensor has been disconnected or short-circuited. (Only detected when in learning control or external tune control)
ERR19	Abnormal auto tuning alarm	Stop	Auto tuning has not been completed within 20 minutes.
ERR20	Low fluid level alarm	Stop	The amount of circulating fluid in the tank has dropped.

Maintenance

Maintenance of this unit is performed only in the form of return to and repair at SMC's site. As a rule, SMC will not conduct on-site maintenance. Separately, the following parts have a limited life and need to be replaced before the life ends.

Parts Life Expectation

Description	Expected life	Possible failure
Pump	3 to 5 years	The bearing is worn so the pump fails to transfer the circulating fluid, which results in temperature control failure.
Fan	5 to 10 years	The bearing uses up lubrication and makes the fan unable to supply enough air, which deteriorates the cooling and heating capacity.
DC power supply	5 to 10 years	The capacity of the electrolytic condenser decreases, and causes abnormal voltage which results in DC power supply failure and stops the Thermo-con.
Display panel	50,000 hours (approx. 5 years)	The display turns off when the backlight of the LCD reaches the end of its life.



Note) Options have to be selected when ordering the Thermo-con. It is not possible to add them after purchasing the unit.

F Option symbol With Flow Switch	
HEC - F • With flow switch	
This is an ON/OFF switch detecting low levels of the circulating fluid. When the fluid volume is 1 L/min. or less, "ERR16" is displayed and the Thermo-con stops. This switch is installed between the circulating fluid inlet and the tank, and built into the Thermo-con. Refer to page 2.	TypeApplicable modelAir-HEC002-A5□-FcooledHEC006-A5□-F
NPT Thread	
HEC	

The connection parts of circulating fluid piping, facility water piping and circulating fluid drain port are NPT thread type.

Туре	Applicable model
Air-	HEC002-A5 -N
cooled	HEC006-A5 -N



Series HEC-A Specific Product Precautions 1

Be sure to read this before handling. Refer to back cover for Saftey Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual " for Temperature Control Equipment Precautions. The Operation Manual can be downloaded from the SMC website: http://www.smc.eu

System Design

Marning

- 1. This catalogue shows the specifications of the Thermo-con.
 - 1. Check detailed specifications in the separate "Product Specifications", and evaluate the compatibility of the Thermo-con with customer's system.
 - Although the protection circuit as a single unit is installed, the customer is requested to carry out the safety design for the whole system.

Handling

Warning

- **1. Thoroughly read the Operation Manual.** Read the Operation Manual completely before operation, and keep this manual available whenever necessary.
- 2. If the set temperature is repeatedly changed by 10°C or more, the Thermo-con may fail in short periods of time.

Operating Environment/Storage Environment

Warning

1. Keep within the specified ambient temperature and humidity range.

Also, if the set temperature is too low, condensation may form on the inside of the Thermo-con or the surface of piping even within the specified ambient temperature range. Dew condensation can cause failure, and so must be avoided by considering operating conditions.

2. The Thermo-con is not designed for clean room usage.

It generates dust from the pump inside the unit and the cooling fan.

3. Low molecular siloxane can damage the contact of the relay.

Use the Thermo-con in a place free from low molecular siloxane.

Radiation Air

Caution

- 1. The inlet for radiation air must not be exposed to particles and dust as far as possible.
- 2. Do not let the inlet and outlet for radiation air get closed.

<HEC002>

If radiation is prevented, the set temperature may not be achieved depending on the value of the set temperature and the load. Keep a space of 100 mm for opened rear side or 200 mm for closed rear side respectively.



Note) The space must be 500 mm or more. Be sure that the ambient temperature is within the specification range.





Series HEC-A Specific Product Precautions 2

Be sure to read this before handling. Refer to back cover for Saftey Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual " for Temperature Control Equipment Precautions. The Operation Manual can be downloaded from the SMC website: http://www.smc.eu

Radiation Air

ACaution

3. If more than one Thermo-con is used, consider their arrangement so that the downstream sides of the Thermo-cons suck radiation air from the upstream sides.

Otherwise, the performance at the downstream sides may deteriorate. Also, the set temperature may not be achieved depending on the value of the set temperature and the load. In such a case, take countermeasures such as changing the direction of the Thermo-cons to prevent the deterioration of performance.

- 4. If dust adheres to the filter, remove dust with a vacuum cleaner or a dry cloth.
- 5. Do not operate without the filter.

Otherwise, dust may accumulate on the heat sink and electrical components, causing abnormal heating.

Circulating Fluid

1. Use tap water or fluid which will not damage the wetted material.

(Stainless steel 303, Stainless steel 304, EPDM, Polypropylene, PE, PPE, Ceramics, Polyurethane)

2. Deionized water (with an electrical conductivity of approx. 1 μ S/cm) can be used, but may lose its electrical conductivity.

Also, if a facility supplying deionized water is used, the Thermocon may be damaged by static electricity.

3. If deionized water is used, bacteria and algae may grow in short periods of time.

If the Thermo-con is operated with bacteria and algae, its cooling capacity or the capacity of the pump may deteriorate. Exchange all deionized water regularly depending on the conditions (once a month as a guide).

- 4. If using a fluid other than water, please contact SMC beforehand.
- 5. The maximum operating pressure of circulating fluid circuit is 0.1 MPa.

If this pressure is exceeded, leakage from the tank in the Thermo-con can result.

6. Select a pipe with a length and diameter which allow a flow rate of 1 L/min or more (HEC002) or 3 L/min or more (HEC006) for the circulating fluid.

If the flow rate is less than these values, the Thermo-con cannot provide precise control, but also can fail because of the repeated cooling and heating operation.

7. A magnet driven pump is used as a circulating pump.

A fluid which contains metal powders such as iron powder cannot be used.

8. The Thermo-con must not be operated without circulating fluid.

The pump can break due to idling.

Circulating Fluid

▲Caution

- 9. If the tank lid is opened after the supply of circulating fluid, the circulating fluid may spill out depending on the condition of external piping.
- 10. If an external tank is used, the circulating fluid may spill out from the internal tank lid depending on where the external tank is installed.

Check that the internal tank has no leakage if using an external tank.

11. If there is a point where fluid is released to atmosphere externally (tank or piping), minimize the piping resistance at the circulating fluid return side.

If the piping resistance is too large, the piping may be crushed, or the built-in circulator tank may be deformed or cracked because the pressure in the piping for return will become negative. The built-in circulator tank is made of resin (PE). Therefore, the tank may be crushed if the pressure is negative. Special attention must be paid if the flow rate of the circulating fluid is high. To avoid getting negative pressure less than -0.02 MPa, the piping for return should be as thick and short as possible to minimize the piping resistance. It is also effective to restrict the flow rate of circulating fluid or remove the gasket of internal tank for the release to atmosphere.

- 12. Fluorinated fluid is outside of the specifications.
- If it is used in the Thermo-con, static electricity will be generated by the flow of fluid. This static electricity may be discharged to the board of the Thermo-con, causing damage or operation failure and loss of data of such as set temperature. Also, as the specific gravity of the fluorinated fluid is 1.5 to 1.8 times of water, the pump will be overloaded, which also causes fluorinated fluid to be outside the specifications. Therefore, if fluorinated fluid is used, please contact SMC and we will introduce a suitable special product (water-cooled type).
- 13. Avoid operation with cavitation or bubbles due to low fluid level in the tank. This may shorten the pump life.
- 14. If clear water is used, it should satisfy the quality standards shown below.

Clear Water (as Circulating Water) Quality Standards

The Japan Refrigeration and Air Conditioning Industry Association JRA GL-02-1994 "Cooling water system – Circulating type – Supply water"

				Influ	ence
	Item	Unit	Standard value	Corrosion	Scale generation
	pH (at 25°C)	_	6.0 to 8.0	0	0
	Electrical conductivity (25°C)	[µS/cm]	100* to 300*	0	0
	Chloride ion (Cl-)	[mg/L]	50 or less	0	
Standard	Sulfuric acid ion (SO42-)	[mg/L]	50 or less	0	
item	Acid consumption amount (at pH4.8)	[mg/L]	50 or less		0
	Total hardness	[mg/L]	70 or less		0
	Calcium hardness (CaCO ₃)	[mg/L]	50 or less		0
	Ionic state silica (SiO ₂)	[mg/L]	30 or less		0
	Iron (Fe)	[mg/L]	0.3 or less	0	0
	Copper (Cu)	[mg/L]	0.1 or less	0	
Reference	Sulfide ion (S2-)	[mg/L]	Should not be detected.	0	
item	Ammonium ion (NH4+)	[mg/L]	0.1 or less	0	
	Residual chlorine (Cl)	[mg/L]	0.3 or less	0	
	Free carbon (CO ₂)	[mg/L]	4.0 or less	0	

* In the case of [MQ+cm], it will be 0.003 to 0.01.

• O: Factors that have an effect on corrosion or scale generation.

• Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.



Series HEC-A Specific Product Precautions 3

Be sure to read this before handling. Refer to back cover for Saftey Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual " for Temperature Control Equipment Precautions. The Operation Manual can be downloaded from the SMC website: http://www.smc.eu

Communication

ACaution

1. The set value can be written to EEPROM, but only up to approx. 1 million times.

In particular, pay attention to how many of times the writing is performed using the communication function.

Maintenance

Warning

1. Prevention of electric shock and fire

Do not operate the switch with wet hands. Also, do not operate the Thermo-con with water left on it.

2. Action in the case of error

If any error such as abnormal sounds, smoke, or bad smell occurs, cut off the power at once, and stop supplying and conveying fluid. Please contact SMC or a sales distributor to repair the Thermo-con.

3. Regular inspection

Check the following items at least once a month. The inspection must be done by an operator who has sufficient knowledge and experience.

- a) Check of displayed contents.
- b) Check of temperature, vibration and abnormal sounds in the body of the Thermo-con.
- c) Check of the voltage and current of the power supply system.
- d) Check for leakage and contamination of the circulating fluid and intrusion of foreign objects to it, and subsequent replacement of the fluid.
- e) Check for flow condition, temperature and filter of radiation air.



Peltier-Type Chiller Thermo-con (Water-cooled) (E Construction of the Except HECODE, 012 RoHS



Specifications (For details, please consult our "Product Specifications" information.)

Model	HEC001-W5A	HEC001-W5B	HEC003-W5A	HEC003-W5B	
Cooling method	Thermoelectric device (Thermo-module)				
Radiating method	Water-cooled				
Control method	Cooling/Heating automatic shift PID control				
Ambient temperature/humidity		10 to 35°C, 35 to 80%	RH (no condensation)		
Circulating fluid		Clear water, 20%	6 ethylene glycol		
E Operating temp. range		10.0 to 60.0°C (no condensation)			
Cooling capacity	140 V	V Note 1)	320	W Note 1)	
Heating capacity	400 V	V Note 1)	770	W Note 1)	
Temperature stability Note 2)		±0.01 to	0.03°C		
Pump capacity		Refer to perfo	rmance chart.		
Tank capacity	Approx. 1.2 L				
Temperature stability Note 2) Pump capacity Tank capacity Port size	IN/OUT: Rc3/8 Drain: Rc1/4 (with plug)				
Wetted parts material	PPE, PP glass 10%, Alumina ceramics, Carbon, EPDM, Stainless steel 303, Stainless steel 304, PE, PP, NBR				
Temperature range		condensation)			
Pressure range	Within 1 MPa 3 to 7 L/min IN/OUT: Rc3/8				
Required flow rate Note 3)					
Port size Wetted parts material					
Wetted parts material		Stainless	steel 304		
Power supply		Single-phase 100 to 24	0 VAC ±10%, 50/60 Hz		
Power supply Overcurrent protector		10	A		
	3.5 A (100 VAC) t	o 1.5 A (240 VAC)	5.5 A (100 VAC)	to 2.5 A (240 VAC)	
Current consumption		Refer to ala	rm function.		
Communications	RS-485	RS-232C	RS-485	RS-232C	
Weight	Approx	<. 12 kg	Appro	ox. 13 kg	
Accessories		Power cable, Foot for fix	xing, Splashproof cover		
Safety standards		CE marking, UL (NR	TL) standards, SEMI		

Note 1) Circulating fluid/Clear water conditions: Circulating fluid set temperature 20°C, Flow rate 5 L/min., Facility water temperature 20°C, Flow rate 5 L/min., Ambient temperature 25°C Note 2) The indicated values are with a stable load without turbulence in the operating conditions. It may be out of this range in some other operating conditions. Note 3) The flow rate over or below the set range may deteriorate performance or generate noise.



Peltier-Type Chiller Thermo-con (Water-cooled) Series HEC-W



Specifications (For details, please consult our "Product Specifications" information.)

	Model	HEC006-W2A	HEC006-W2B	HEC012-W2A	HEC012-W2B	
Cooling method Thermoelectric device (Thermo-module)						
R	adiating method	Water-cooled				
C	ontrol method		Cooling/Heating auto	matic shift PID control		
Α	nbient temperature/humidity		10 to 35°C, 35 to 80%	RH (no condensation)		
	Circulating fluid Note 1)	Clear	rinert [™] FC-3283, GALDEN [®] H	T135)		
	Operating temperature range		10.0 to 60.0°C (I	no condensation)		
en	Cooling capacity	600 W (Clear water), 400 W	(Fluorinert [™] FC-3283) Note 2)	1200 W (Clear water), 800 W	/ (Fluorinert [™] FC-3283) Note 3)	
system	Heating capacity	900 W (Clear water), 600 W	(Fluorinert [™] FC-3283) Note 2)	2200 W (Clear water), 1500 V	N (Fluorinert [™] FC-3283) Note 3)	
	Temperature stability Note 4)		±0.01 to	o 0.03°C		
g flu	Pump capacity		Refer to perfo	ormance chart.		
ating	Tank capacity	Appro	эх. 3 L	Appr	ox. 5 L	
Circulating fluid	Port size	IN/OUT: Rc3/8 Drain: Rc1/4 (with plug)		IN/OUT: Rc3/4 Drain: Rc1/4 (with plug)		
	Wetted parts material	Stainless steel 303, Stainless steel 304, EPDM, Ceramics, PPS glass 30%, Carbon, PE, Polyurethane		Stainless steel 303, Stainless steel 304, EPDM, Ceramics, PP, PE, Polyurethane, SiC, PPS		
em	Temperature range	10 to 35°C (no condensation)				
system	Pressure range	Within 1 MPa				
Facility water	Required flow rate Note 5)	8 to 10) L/min	10 to 15 L/min		
liif∧	Port size	IN/OUT	T: Rc3/8	IN/OU	IN/OUT: Rc1/2	
Fac	Wetted parts material		Stainless steel 303	, Stainless steel 304		
em	Power supply		Single-phase 200 to 22	20 VAC ±10%, 50/60 Hz		
system	Overcurrent protector	r 10 A			5 A	
	Current consumption	5	5 A	10	0 A	
Electrical	Alarm	Refer to alarm function.				
Ele	Communications	RS-485	RS-232C	RS-485	RS-232C	
W	eight	Approx. 25 kg (inclu	uding foot for fixing)	Approx. 40 kg (inc	luding foot for fixing)	
Α	ccessories		Power cable,	Foot for fixing		
S	afety standards		CEm	arking		

Note 1) Fluorinert[™] is a trademark of 3M and GALDEN[®] is a registered trademark of Solvay Solexis, Inc. Regarding the fluid other than the above, please consult with SMC. Note 2) Conditions: Set temperature 25°C, Facility water temperature 20°C, Facility water flow rate 8 L/min, Ambient temperature 25°C. Note 3) Conditions: Set temperature 25°C, Facility water temperature 20°C, Facility water flow rate 10 L/min, Ambient temperature 25°C.

Note 4) The indicated values are with a stable load without turbulence in the operating conditions. It may be out of this range in some other operating conditions.

Note 5) The flow rate over or below the set range may deteriorate performance or generate noise.

Series HEC-W

Cooling Capacity





Circulating fluid: Clear water





Circulating fluid: Clear water





The values shown on the performance chart are not guaranteed, but typical. Allow margins for safety when selecting the model.













Circulating fluid: FC-3283

Peltier-Type Chiller Thermo-con (Water-cooled) Series HEC-W

The values shown on the performance chart are not guaranteed, but typical. Allow margins for safety when selecting the model.



HEC003

Heating Capacity

Circulating fluid: Clear water





Circulating fluid: Clear water





Circulating fluid: 20% ethylene glycol 600 Facility water flow rate: 5 L/min 500 Heating capacity [W] 400 300 Facility water: 20°C 200 100 0 0 10 20 30 50 60 70 40 Circulating fluid temperature [°C]















Series **HEC-W**

Pump Capacity (Thermo-con Outlet)

HEC001/003 Since a DC pump is used, the unit is not affected by power requirements.







Pressure Loss in Facility Water Circuit



SMC

HEC012



15

20

Parts Description



HEC006/012



Series HEC-W

Dimensions

HEC001-W5□ HEC003-W5□





For NPT thread specification (-N), all fittings (including those at the circulating fluid drain port) are made of NPT.

Power Cable (Accessory)

Connector: IEC 60320 C13 or equivalent Cable: 14AWG, O.D. ø8.4

	, 0.0. 00.4	
	Contents	Wire colour
2000	100 to 240 VAC	Black
	100 to 240 VAC	Black
Power cable (Accessory	PE	Green/Yellow

Dimensions

HEC006-W2



For NPT thread specification (-N), all fittings (including those at the circulating fluid drain port) are made of NPT.

Power Cable

Connector: IEC 60320 C13 or equivalent Cable: 14AWG, O.D. ø8.4

	,
Wire colour	Contents
Black	200 to 220 VAC
Black	200 to 220 VAC
Green/Yellow	PE

\geq		
•	2000	

Power cable (Accessory)

Series **HEC-W**

Dimensions

HEC012-W2□



For NPT fitting specification (-N), all fittings (including those at the circulating fluid drain port) are made of NPT.

Power Cable

Connector: DDK CE05-6A18-10SD-D-BSS or equivalent Cable: 14AWG, O.D. ø8.4

Wire colour	Contents
Black	200 to 220 VAC
Black	200 to 220 VAC
Green/Yellow	PE



Power cable (Accessory)

Connectors

Pin No. 1 2 3

HEC006-W2□/001-W5□/003-W5□

1. Power connector (AC) IEC 60320 C14 or equivalent HEC006-W2 HEC003-W5

006-W2⊔	HEC003-W5		
Contents	Р	Pin No.	Contents
200 to 220 VAC		1	100 to 240 VAC
200 to 220 VAC		2	100 to 240 VAC
PE		3	PE

2. Communication connector (RS-232C or RS-485) D-sub 9 pin (socket) Holding screw: M2.6

Pin No.	Signal contents		
FIII NU.	RS-232C	RS-485	
1	Unused	BUS+	
2	RD	BUS-	
3	SD	Unused	
4	Unused	Unused	
5	SG	SG	
6-9	Unused	Unused	

3. External sensor connector (EXT.SENSOR) D-sub 15 pin (socket) Holding screw: M2.6

Pin No.	Signal contents
1-2	Unused
3	Terminal A of resistance temperature detector
4	Terminal B of resistance temperature detector
5	Terminal B of resistance temperature detector
6-14	Unused
15	FG

4. Alarm output connector (ALARM) D-sub 9 pin (pin) Holding screw: M2.6

Holding screw: M2.6

Pin No.	Signal contents					
1	Contact a for output cut-off alarm (open when alarm occurs)					
2	Common for output cut-off alarm					
3	Contact b for output cut-off alarm (closed when alarm occurs) Unused					
4-5						
6	Contact a for upper/lower temp. limit alarm (open when alarm occurs)					
7	Common for upper/lower temp. limit alarm					
8	Contact b for upper/lower temp. limit alarm (closed when alarm occurs) Unused					
9						

HEC012-W2□

Power connector (AC) DDK CE05-2A18-10PD-D or equivalent

Pin No.	Contents
Α	200 to 220 VAC
В	200 to 220 VAC
С	Unused
D	PE

Other connectors are the same as those for the HEC006-W2











Series **HEC-W**

Alarm

This unit is equipped as standard with a function allowing 15 kinds of alarms to display on the LCD and can be read out by serial communication. Also, it can generate relay output for upper/lower temperature limit alarm and output cut-off alarm.

Alarm code	Alarm description	Operation status	Main reason		
WRN	Upper/Lower temp. limit alarm	Continue	The temperature has exceeded the upper or lower limit of the target temperature.		
ERR00	CPU hung-up	Stop	The CPU has crashed due to noise, etc.		
ERR01	CPU check error	Stop	The contents of the CPU cannot be read out correctly when the power supply is turned on.		
ERR03	Back-up data error	Stop	The contents of the back-up data cannot be read out correctly when the power supply is turned on.		
ERR04	EEPROM writing error	Stop	The data cannot be written to EEPROM.		
ERR11	ERR11 DC power supply failure		ERR11 DC power supply failure Stop The DC power supply has failed (due to abnormal high temperature) or an has occurred or the thermo-module has been short-circuited.		The DC power supply has failed (due to abnormal high temperature) or an irregular voltage has occurred or the thermo-module has been short-circuited.
ERR12	Internal temp. sensor high temp. error	Stop	The internal temperature sensor has exceeded the upper limit of cut-off temperature.		
ERR13	Internal temp. sensor low temp. error	Stop	The internal temperature sensor has exceeded the lower limit of cut-off temperature.		
ERR14	Thermostat alarm	Stop	The thermostat has been activated due to insufficient of the facility water or high temperature.		
ERR15	Abnormal output alarm	Continue	The temperature cannot be changed even at 100% output due to overload or disconnection of the thermo-module.		
ERR16	Pump failure *1 or low circulating fluid level alarm *2		The pump has been overloaded *1 or the flow switch is activated *2.		
ERR17	RR17 Internal temp. sensor disconnection alarm		The internal temperature sensor has been disconnected or short-circuited.		
ERR18	External temp. sensor disconnection alarm		The external temperature sensor has been disconnected or short-circuited. (Only detected when in learning control or external tune control.)		
ERR19	Abnormal auto tuning alarm	Stop	Auto tuning has not been completed within 20 minutes.		
ERR20	Low fluid level alarm *3	Stop	The amount of circulating fluid in the tank has dropped and the level switch is activated.		

*1 The HEC012 only *2 Optional for the HEC001 and HEC003 only (Not available for the HEC006)

*3 Optional for the HEC001 and HEC003

Maintenance

Maintenance of this unit is performed only in the form of return to and repair at SMC's site. As a rule, SMC will not conduct on-site maintenance. Separately, the following parts have a limited life and need to be replaced before the life ends.

Parts Life Expectation				
Description	Expected life	Possible failure		
Pump	3 to 5 years	The bearing is worn so the pump fails to transfer the circulating fluid, which results in temperature control failure.		
Fan	5 to 10 years	The bearing uses up lubrication and makes the fan unable to supply enough air, which increases the internal tempera- ture of the Thermo-con, and activates the overheat protection of the power supply and generates the alarm.		
DC power supply	5 to 10 years	The capacity of the electrolytic condenser decreases, and causes abnormal voltage which results in DC power supply failure and stops the Thermo-con.		
Display panel	50,000 hours (approx. 5 years)	The display turns off when the backlight of the LCD reaches the end of its life.		



• With level switch

This switch is used to detect a LOW level of tank fluid. When the fluid level becomes below the LOW level, "ERR20" is displayed and the Thermo-con stops. This switch is installed in the circulating fluid tank and built into the Thermo-con. Refer to page 2.

Туре	Applicable model
Water-	HEC001-W5□-L
cooled	HEC003-W5□-L

Other models include a level switch as standard equipment.



Series HEC-W Specific Product Precautions 1

Be sure to read this before handling. Refer to back cover for Saftey Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual " for Temperature Control Equipment Precautions. The Operation Manual can be downloaded from the SMC website: http://www.smc.eu

System Design

Marning

- 1. This catalogue shows the specifications of the Thermo-con.
 - 1. Check detailed specifications in the separate "Product Specifications", and evaluate the compatibility of the Thermo-con with customer's system.
 - Although the protection circuit as a single unit is installed, the customer is requested to carry out the safety design for the whole system.

Handling

Warning

1. Thoroughly read the Operation Manual.

Read the Operation Manual completely before operation, and keep this manual available whenever necessary.

2. If the set temperature is repeatedly changed by 10°C or more, the Thermo-con may fail in short periods of time.

Operating Environment/Storage Environment

Warning

1. Keep within the specified ambient temperature and humidity range.

Also, if the set temperature is too low, condensation may form on the inside of the Thermo-con or the surface of piping even within the specified ambient temperature range. Dew condensation can cause failure, and so must be avoided by considering operating conditions.

2. The Thermo-con is not designed for clean room usage.

The pump and fan generate dust.

3. Low molecular siloxane can damage the contact of the relay.

Use the Thermo-con in a place free from low molecular siloxane.

Operating Environment/Storage Environment

Warning

4. Installation conditions

If the space for the intake and discharge of air is insufficient, the amount of transferred air will decrease, which can impair the performance and life of the product. Therefore, keep the conditions illustrated below for installation. Also, if ambient temperature is expected to be over 35° C, vent or exhaust air to prevent the increase of ambient temperature over 35° C.

<HEC006/012>



<HEC001/003>

It is not necessary to leave space for ventilation. Install the product while taking working space for installation and maintenance into account. However, ventilation must be also considered so that ambient temperature does not excessively rise.

Facility Water

▲Caution

1. If the temperature of the facility water is too low, it can cause formation of dew condensation inside the heat exchanger.

Supply facility water with a temperature over the atmospheric dew point to avoid the formation of dew condensation.

2. If the facility water piping is connected to multiple machines, the facility water exchanges heat at the upstream side and its temperature will become higher as it goes downstream.

Limit the number of connected Thermo-cons to two per facility water system, and if more than two Thermo-cons are to be connected, increase the number of systems.

Circulating Fluid

ACaution

1. Use tap water or fluid which will not damage the wetted parts material as described in this catalogue's specifications.

(PPE, PP glass 10%, Alumina ceramics, Carbon, EPDM, Stainless steel 303, Stainless steel 304, PE, PP, NBR)

2. Deionised water (with an electrical conductivity of approx. 1 μ S/cm) can be used, but may lose its electrical conductivity.

@ SMC



Series HEC-W Specific Product Precautions 2

Be sure to read this before handling. Refer to back cover for Saftey Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual " for Temperature Control Equipment Precautions. The Operation Manual can be downloaded from the SMC website: http://www.smc.eu

Circulating Fluid

ACaution

3. If deionized water is used, bacteria and algae may grow in a short period.

If the Thermo-con is operated with bacteria and algae, its heat exchanging capacity or the capacity of the pump may deteriorate. Exchange all deionized water regularly depending on the conditions (once a month as a guide).

- 4. If using a fluid other than this catalogue, please contact SMC beforehand.
- 5. The maximum operating pressure of circulating fluid circuit is 0.1 MPa.

If this pressure is exceeded, leakage from the tank in the Thermo-con can result.

6. Select a pipe with a length and diameter which allow a flow rate of 3 L/min or more for the circulating fluid.

If the flow rate is less than 3 L/min, the Thermo-con cannot provide precise control, but also can fail because of the repeated cooling and heating operation.

7. A magnet driven pump is used as a circulating pump.

A fluid which contains metal powders such as iron powder cannot be used.

8. The Thermo-con must not be operated without circulating fluid.

The pump can break due to idling.

- 9. If the tank lid is opened after the supply of circulating fluid, the circulating fluid may spill out depending on the condition of external piping.
- 10. If an external tank is used, the circulating fluid may spill out from the internal tank lid depending on where the external tank is installed.

Check that the internal tank has no leakage if using an external tank.

11. If there is a point where fluid is released to atmosphere externally (tank or piping), minimize the piping resistance at the circulating fluid return side.

If the piping resistance is too large, the piping may be crushed, or the built-in circulator tank may be deformed or cracked because the pressure in the piping for return will become negative. The built-in circulator tank is made of resin (PE). Therefore, the tank may be crushed if the pressure is negative. Special attention must be paid if the flow rate of the circulating fluid is high. To avoid getting negative pressure less than -0.02 MPa, the piping for return should be as thick and short as possible to minimize the piping resistance. It is also effective to restrict the flow rate of circulating fluid or remove the gasket of internal tank for the release to atmosphere.

12. If fluorinated fluid is used in the Thermo-con (HEC006/012), static electricity will be generated by the flow of fluid. This static electricity may be discharged to the board of the Thermo-con, causing damage or operation failure and loss of data of such as set temperature.

Ground pipe in order to remove static electricity.

13. Avoid operation with cavitation or bubbles due to low fluid level in the tank. This may shorten the pump life. **Circulating Fluid**

▲Caution

14. If clear water is used, it should satisfy the quality standards shown below.

Clear Water (as Circulating Water) Quality Standards

The Japan Refrigeration and Air Conditioning Industry Association JRA GL-02-1994 "Cooling water system – Circulating type – Supply water"

				Influence	
	Item	Unit	Standard value	Corrosion	Scale generation
	pH (at 25°C)	_	6.0 to 8.0	0	0
	Electrical conductivity (25°C)	[µS/cm]	100* to 300*	0	0
	Chloride ion (Cl-)	[mg/L]	50 or less	0	
Standard	Sulfuric acid ion (SO ₄ ^{2–})	[mg/L]	50 or less	0	
item	Acid consumption amount (at pH4.8)	[mg/L]	50 or less		0
	Total hardness	[mg/L]	70 or less		0
	Calcium hardness (CaCO ₃)	[mg/L]	50 or less		0
	Ionic state silica (SiO ₂)	[mg/L]	30 or less		0
	Iron (Fe)	[mg/L]	0.3 or less	0	0
	Copper (Cu)	[mg/L]	0.1 or less	0	
Reference	Sulfide ion (S2 ⁻)	[mg/L]	Should not be detected.	0	
item	Ammonium ion (NH ₄ ⁺)	[mg/L]	0.1 or less	0	
	Residual chlorine (Cl)	[mg/L]	0.3 or less	0	
	Free carbon (CO ₂)	[mg/L]	4.0 or less	0	

* In the case of [M Ω •cm], it will be 0.003 to 0.01.

 \bullet \bigcirc : Factors that have an effect on corrosion or scale generation.

 Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.

Communication

Caution

1. The set value can be written to EEPROM, but only up to approx. 1 million times.

In particular, pay attention to how many of times the writing is performed using the communication function.

Maintenance

Warning

1. Prevention of electric shock and fire

Do not operate the switch with wet hands. Also, do not operate the Thermo-con with water left on it.

2. Action in the case of error

If any error such as abnormal sounds, smoke, or bad smell occurs, cut off the power at once, and stop supplying and conveying fluid. Please contact SMC or a sales distributor to repair the Thermo-con.

3. Regular inspection

Check the following items at least once a month. The inspection must be done by an operator who has sufficient knowledge and experience.

- a) Check of displayed contents.
- b) Check of temperature, vibration and abnormal sounds in the body of the Thermo-con.
- c) Check of the voltage and current of the power supply system.
 d) Check for leakage and contamination of the circulating fluid and intrusion of foreign objects to it, and subsequent replacement of water.
- e) Check for leakage, quality change, flow rate and temperature of facility water.

▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "**Caution**," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

- 1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.
- Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3.Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
 - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
 - An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

 The product is provided for use in manufacturing industries. The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch

 *1) ISO 4414: Pneumatic fluid power – General rules relating to systems. ISO 4413: Hydraulic fluid power – General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)
 ISO 10218-1: Manipulating industrial report – Safety.

ISO 10218-1: Manipulating industrial robots - Safety. etc.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements". Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, wichever is first.*2)
- Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
 - *2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

A Safety Instructions Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation (Europe)

-							
Austria	2 +43 (0)2262622800	www.smc.at	office@smc.at	Lithuania	🕿 +370 5 2308118	www.smclt.lt	info@smclt.lt
Belgium	2 +32 (0)33551464	www.smcpneumatics.be	info@smcpneumatics.be	Netherlands	🕿 +31 (0)205318888	www.smcpneumatics.nl	info@smcpneumatics.nl
Bulgaria	2 +359 (0)2807670	www.smc.bg	office@smc.bg	Norway	2 +47 67129020	www.smc-norge.no	post@smc-norge.no
Croatia	2 +385 (0)13707288	www.smc.hr	office@smc.hr	Poland	2 +48 (0)222119616	www.smc.pl	office@smc.pl
Czech Republic	2 +420 541424611	www.smc.cz	office@smc.cz	Portugal	2 +351 226166570	www.smc.eu	postpt@smc.smces.es
Denmark	2 +45 70252900	www.smcdk.com	smc@smcdk.com	Romania	2 +40 213205111	www.smcromania.ro	smcromania@smcromania.ro
Estonia	🕿 +372 6510370	www.smcpneumatics.ee	smc@smcpneumatics.ee	Russia	🕿 +7 8127185445	www.smc-pneumatik.ru	info@smc-pneumatik.ru
Finland	🕿 +358 207513513	www.smc.fi	smcfi@smc.fi	Slovakia	2 +421 (0)413213212	www.smc.sk	office@smc.sk
France	2 +33 (0)164761000	www.smc-france.fr	promotion@smc-france.fr	Slovenia	2 +386 (0)73885412	www.smc.si	office@smc.si
Germany	2 +49 (0)61034020	www.smc.de	info@smc.de	Spain	2 +34 902184100	www.smc.eu	post@smc.smces.es
Greece	2 +30 210 2717265	www.smchellas.gr	sales@smchellas.gr	Sweden	2 +46 (0)86031200	www.smc.nu	post@smc.nu
Hungary	🕿 +36 23511390	www.smc.hu	office@smc.hu	Switzerland	2 +41 (0)523963131	www.smc.ch	info@smc.ch
Ireland	2 +353 (0)14039000	www.smcpneumatics.ie	sales@smcpneumatics.ie	Turkey	🕿 +90 212 489 0 440	www.smcpnomatik.com.tr	info@smcpnomatik.com.tr
Italy	2 +39 0292711	www.smcitalia.it	mailbox@smcitalia.it	UK	2 +44 (0)845 121 5122	www.smcpneumatics.co.uk	sales@smcpneumatics.co.uk
Latvia	🖀 +371 67817700	www.smclv.lv	info@smclv.lv			•	

 SMC CORPORATION
 Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249
 FAX: 03-5298-5362

 1st printing TO printing TO 00 Printed in Spain
 Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.