### Vacuum Pad **ZP3P-PT** Series

#### **How to Order** Vertical vacuum inlet ZP3P-T20PTSFJ10-B5 With buffer Pad diameter Symbol Pad diameter 20 ø20 25 ø25 35 ø35 50 ø50 Vacuum inlet Pad material Type Symbol Size ø20, ø25 | ø35, ø50 Symbol Material **B**5 M5 x 0.8 Female SF Silicone rubber\*1, \*2 thread Rc1/8 \*1 Compliant with the FDA (USA Food and Drug Administration) regulation 21CFR§177.2600 for "Rubber articles intended for repeated use" \*2 Compliant with the standards for "Rubber apparatus (excluding baby drinking appara-Stroke (■) tus) and containers/packaging" (D3) (Partial revision: Ministry of Health, Labour, and Welfare Notification No. 595, 2012) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food Buffer specification Symbol Stroke ø**20**, ø**25** | ø**35**, ø**50**

**Specifications** 

Pad diameter	Buffer specification	Stroke [mm]	Tightening torque [N⋅m]	Connection thread	Spring reactive force [N]	
					At 0 stroke	At full stroke
ø <b>20,</b> ø <b>25</b>	J/K	10, 20	2.5 to 3.5	M10 x 1	1.0	3.0
ø <b>35,</b> ø <b>50</b>	J/K	10, 20	6.5 to 7.5	M14 x 1	2.0	5.0

Rotating

Non-rotating

10

20

10 mm

20 mm

# **⚠ Specific Product Precautions**

Be sure to read this before handling the products. Refer to page 375 for safety instructions. For vacuum equipment I and vacuum pad precautions, refer to pages 376 to 379.

#### **Operating Precautions**

and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959).

#### **⚠** Caution

#### 1. When selecting a buffer

Buffers come with general industrial grease applied to them and are therefore not compliant with FDA regulations. Metal wear particles will be generated due to the sliding motion of the buffer. Please take this into consideration when deciding whether this pad is suitable for your application.

#### **Dimensions: With Buffer**

## ZP3P-T20PTSFJ■-B5 M5 x 0.8 Width across flats 8 Width across flats 14 m M10 x 1 Gasket M5 x 0.8 Width across 7 ø2.5 ø20 **Dimensions**

32.5


42.5

68.5

106.5

23

#### ZP3P-T20PTSFK■-B5



#### **Dimensions**

Part no.	Α	В	D	Weight [g]
ZP3P-T20PTSFK10-B5	32.5	68.5	23	28.5
ZP3P-T20PTSFK20-B5	42.5	106.5	51	41.8

Part no.

ZP3P-T20PTSFJ10-B5

ZP3P-T20PTSFJ20-B5

Weight [g]


26.7

<sup>\*</sup> The pad and mounting nut are shipped together but do not come assembled.

# Vacuum Pad **ZP3P-PT** Series

### **Dimensions: With Buffer**

#### ZP3P-T50PTSFJ■-B01



#### **Dimensions**

Part no.	Α	В	Weight [g]
ZP3P-T50PTSFJ10-B01	40.5	107	101.3
ZP3P-T50PTSFJ20-B01	50.5	112.5	102.3

#### ZP3P-T50PTSFK■-B01

### **ZP3P-T50PTSFK10-B01 ZP3P-T50PTSFK20-B01** Width across Width across flats 13 Rc1/8 flats 13 K: Non-rotating D-D Width across flats 19 20 Ш M14 x 1 Gasket M8 x 1.25 ⋖ Width across flats 21 28 22 4.5 ø4 ø50

#### **Dimensions**

Part no.	Α	В	Weight [g]
ZP3P-T50PTSFK10-B01	40.5	107	100.7
ZP3P-T50PTSFK20-B01	50.5	112.5	101.8