


Series VQ7-6

Manifold Option Parts

Blanking plate assembly AXT502-9A


It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



Block disk (For SUP/EXH passages) AXT502-14

When two or more different high pressures are supplied to one manifold, block disks are installed between stations having different pressures.

Also, in cases such as when valve exhaust effects other stations in a circuit, block disks are used for exhaust at stations where the exhaust is to be separated.



Individual SUP spacer VV71-P-⁰²₀₃ C10


Thread type

Nil	Rc
F	G
T	NPTF




Note) It is not applicable to One-touch fittings.

By mounting individual SUP spacers on a manifold block, it is possible to provide individual supply ports for each valve.



Block disk (For pilot EXH passage) AZ503-53A

When a valve's pilot valve exhaust effects other valves in a circuit, block disks are used between stations where the pilot exhaust passages are to be separated.



Individual EXH spacer VV71-R-⁰²₀₃ C12


Thread type

Nil	Rc
F	G
T	NPTF




Note) It is not applicable to One-touch fittings.

By mounting individual EXH spacers on a manifold block, exhaust ports can be provided individually for each valve. (3, 5 common EXH type)



Throttle valve spacer AXT503-23A


A throttle valve spacer is mounted on a manifold block to control cylinder speed by throttling exhaust air flow.



ISO Standard Solenoid Valve: Size 1 Metal Seal/Rubber Seal Series VQ7-6

Individual SUP spacer
Individual EXH spacer
R1, R2 individual EXH spacer
Reverse pressure spacer


VV71-P-□
VV71-R-□
VV71-R2-03
AXT502-21A-1



Double check spacer


VV71-FPG

Double check spacer with
residual pressure release valve VV71-FPGR



Dimensions inside () are for sub-plate.


Main EXH back pressure check plate
AXT503-37A



Residual pressure
release valve spacer

VV71-R-AB

Individual SUP spacer with
residual pressure release valve VV71-PR-□



Dimensions inside () are for sub-plate.

VK

VZ

VF

VFR

VP4

VZS

VFS

VS4

VQ7

EVS

VFN