





Maximum stations are 16.







## **Manifold Specifications**


	Porting specifications			
Series	Port	Port size		Applicable
	location	1(P), 3(R)	4(A), 2(B)	stations
VQ0000	Side	C6	C3, C4, M5	Max. 16
VQ1000	Side	C8	C3, C4, C6, M5	Max.16 stations

## Wiring specifications: Positive COM ●




Note) 100/110 VAC for single: AXT661-31A-□; for double: AXT661-32A-□ 200/220 VAC for single: AXT661-34A-□; for double: AXT661-35A-□





## **How to Order Manifold**



Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BNS

VQ0000

•

VQ1000

• (3)

Note 2) Models with a suffix "-B" have the back pressure check valve at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) VQ1000 are all equipped with a DIN rail, so indicate suffix "-D".

2-4-216.