Speed Controller with Indicator

In-line Type











Numerical indication of knob rotation for flow rate reduces flow setting time and setting errors!


Flow rate can be controlled numerically with the indicator window.



Body	size 1
Indicator window	Number of needle rotations
1	1
2	2
:	:
8	8

Body	size 1	Body size	2 or larger
icator ndow	Number of needle rotations	Indicator window	Number of needle rotations
1	1	1	1
2	2	2	2
:	:	<u>:</u>	:
8	8	10	10

4 Indicator Window Directions Available



Larger **Push-Lock Type** Knob

Easy to lock



Easy to operate with the larger knob and marking every 90° mark




Body size	Ø D [mm]
1	9.4
2	12 (Port size 1/8) 13 (Port size 1/4)
3	16.6
4	18.8

AS-FS Series







Easy Identification of Product Type

■ By index plate

It is possible to **identify the product when multiple controllers are mounted** and **identify the flow direction** by attaching an identification label.




■ By colour

Model	Release bu	tton colour
Wodei	Metric	Inch
Page 3	Light grey	Orange
AS-FS	0916	OSIG OF
Page 8	White	White
AS-FSG	19 OSUE 19	0505



○ Electroless nickel plating type is standardised. ○ Stainless steel type is standardised.

Series Variations





Speed Controller with Indicator

In-line Type

AS-FS Series





In-line



Model

		Applicable tubing O.D.										
Model		1	Metri	c size)				Inch	size		
	3.2	4	6	8	10	12	1/8"	5/32"	1/4"	5/16"	3/8"	1/2"
AS1002FS□	•	•	•				•	•	•			
AS2002FS□		•	•					•	•			
AS2052FS□			•	•					•	•		
AS3002FS□			•	•	•	•			•	•	•	
AS4002FS□					•	•					•	•

Specifications

Fluid	Air
Proof pressure	1.5 MPa
Max. operating pressure	1 MPa
Min. operating pressure	0.1 MPa
Ambient and fluid temperature	-5 to 60 °C (No freezing)
Applicable tubing material	Nylon, Soft nylon, Polyurethane*1, FEP, PFA

^{*1:} Use caution at the max. operating pressure when using soft nylon or polyurethane tubing. (Refer to the catalogue on www.smc.eu for details.)


Flow Rate and Sonic Conductance

Mod	el	AS	1002F	S□	AS200	2FS□	AS205	52FS□		AS300	2FS□		AS400)2FS□
Tubing	Metric size	Ø 3.2	Ø 4	Ø6	Ø 4	Ø6	Ø6	Ø 8	Ø 6	Ø 8	Ø 10	Ø 12	Ø 10	Ø 12
Tubing O.D.	Inch size	Ø 1/8"	Ø 5/32"	Ø 1/4"	Ø 5/32"	Ø 1/4"	Ø 1/4"	Ø 5/16"	Ø 1/4"	Ø 5/16"	Ø 3/8"	-	Ø 3/8"	Ø 1/2"
C values: Sonic	Free flow	0.3	0.4	0.6	0.4	0.6	1.0	1.2	1.1	1.6	2.2	2.6	2.4	3.5
conductance dm ³ /(s·bar)	Controlled flow		0.3		0.4	0.6	1.0	1.2	1.3	1.9	2.7	3.3	2.8	4.1
b values: Critical	Free flow	0.3	0	.2	0.3	0.1	0.	.2		0.	.2		0.3	0.2
pressure ratio	Controlled flow	0.2	0.3	0.4	0.	.2	0.2	0.3	0	.1	0.	.2	0.1	0.2



- *: C and b values are for controlled flow with the needle fully open and free flow with the needle fully closed.
- *: The same specifications also apply to the AS-FSG series (stainless steel type).

How to Order



Indicator window direction •						
ı	0°	Index plate				
1	180°	Indicator window Index plate				
2	90°	Index plate				
3	270°	Indicator window Index plate				

Applicable tubing O.D.*1

wetri	c size	inch s	size
23	Ø 3.2*2	01	Ø 1/8"
04	Ø 4	03	Ø 5/32"
06	Ø6	07	Ø 1/4"
80	Ø 8	09	Ø 5/16"
10	Ø 10	11	Ø 3/8"
12	Ø 12	13	Ø 1/2"

- *1: For selecting applicable tubing O.D., refer to the "Model" shown above.
- *2: Use Ø 1/8" tubing.

⚠ Caution

I Be sure to read this before handling the products. I Refer to the back cover for Safety Instructions. For Flow Control Equipment Precautions, refer to the "Operation Manual" on the SMC website, http://www.smc.eu

Options

1) Adapter for Direct Mounting

*: For use when the mounting surface interferes with the bonnet.


Part no.	Applicable model		
AS-10A1	AS1002FS□		
AS-20A1	AS2002FS□		
AS-25A1	AS2052FS□		
AS-30A1	AS3002FS□		

*: The AS4002FS can be mounted without the adapter.




2 DIN Rail Mounting Bracket

Part no.	Applicable model	Quantity
AS-10D	AS1002FS□	
AS-20D	AS2002FS□	
AS-25D	AS2052FS□	2
AS-30D	AS3002FS□	
AS-40D	AS4002FS□	



3 L-Bracket

Part no.	Applicable model	Quantity
AS-10L	AS1002FS□	
AS-20L	AS2002FS□	
AS-25L	AS2052FS□	2
AS-30L	AS3002FS□	
AS-40L	AS4002FS□	



*1: Prepare DIN rail by user.

*2: It is included in the threaded stud kit for manifold (excluding the AS4002FS□). Refer to the following details of the kit.

(4) Threaded Stud Kit for Manifold

<u> </u>	a Otaa itii	ioi maillioi	<u> </u>							
	Part n	umber		Applicab	le model					
4 stations	6 stations	8 stations	10 stations	Metric size	Inch size					
	AS-3AB	AS-5AB	AS-7AB	AS1002FS□-23	AS1002FS□-01					
AS-1AB	AS-SAD	AS-SAD	AS-TAB	AS1002FS□-04	AS1002FS□-03					
	AS-4AB	AS-6AB	AS-8AB	AS1002FS□-06	_					
AS-2AB	AS-4AD	AS-OAD	AS-OAD	_	AS1002FS□-07					
				AS2002FS□-04	AS2002FS□-03					
AS-9AB	AS-10AB	AS-11AB	AS-12AB	AS2002FS□-06	_					
				_	AS2002FS□-07					
				AS2052FS□-06	_					
AS-13AB	AS-14AB	AS-15AB	AS-16AB	_	AS2052FS□-07					
				AS2052FS□-08	AS2052FS□-09					
				AS3002FS□-06	_					
				_	AS3002FS□-07					
AS-17AB	AS-18AB	AS-20AB	AS-21AB	AS3002FS□-08	AS3002FS□-09					
A3-17AD		A3-20AD		AS3002FS□-10	_					
				_	AS3002FS□-11					
	AS-19AB		AS-22AB	AS3002FS□-12	_					
				AS4002FS□-10	<u> </u>					
AS-43B	AS-45B	AS-47B	AS-48B	_	AS4002FS□-11					
A3-43D	AS-43B AS-45B AS-47	A3-47B	A3-40D	AS4002FS□-12	<u> </u>					
				_	AS4002FS□-13					

Details of Threaded Stud Kit for Manifold

Part no.	Adapter for manife	old mounting	Thread	ed stud		Acces	sories	
Fait iio.	Part no.	Quantity	Length	Quantity	Hexagon nut	Quantity	Flat washer	Quantity
AS-1AB		3	72	2				
AS-2AB		3	90	2				
AS-3AB		5	104	2				
AS-4AB	AS-10A		114	2				
AS-5AB	, AO TOA	7	135	2				
AS-6AB		,	143	2		4	M3	4
AS-7AB		9	167	2	IVIO	-	IVIO	-
AS-8AB			170	2				
AS-9AB		3	90	2				
AS-10AB	AS-20A	5	135	2				
AS-11AB	/10 20/1	7	167	2				
AS-12AB		9	208	2				
AS-13AB		3	111	2				
AS-14AB	AS-25A	5	147	2				
AS-15AB	/10 20/1	7	191	2				
AS-16AB		9	236	2				
AS-17AB		3	111	2				
AS-18AB		5	158	2				
AS-19AB	AS-30A	5	179	2	M4	4	M4	4
AS-20AB	NO OON	7	236	2	101-7	-	IVI	-
AS-21AB		9	258	2				
AS-22AB		9	277	2				
AS-43B			119	2				
AS-45B	_		179	2				
AS-46B			191	2				
AS-47B			236	2				

^{*:} AS4002FS□ type can be mounted with the threaded stud kit only (Adapter for manifold mounting is not required).

Ordering Example

Threaded studs for manifold are not included when L-bracket and DIN rail mounting bracket are ordered. Please order them according to the number of stations.


Ex.) AS2002FS-06

When connecting 4 pcs. and mounting L-brackets on both sides

• Speed controller AS2002FS-06 ··· 4 pcs.

• L-bracket AS-20L2 pcs.

• Threaded stud kit for manifold AS-9AB ············ 1 set (Adapter for manifold mounting is included.)



^{*:} It is included in the threaded stud kit for manifold (excluding the AS4002FS□). Refer to the details of the kit shown on the left.




AS-FS Series


Needle Valve/Flow Rate Characteristics

*: The flow rate characteristics are representative values.


AS1002FS□




AS2002FS□




AS2052FS□



AS3002FS□





AS4002FS□




^{*:} The numbers above the flow rate characteristic curves in the charts show the applicable tubing outside diameter as defined by the product number.

Construction






L-Bracket



Component Parts

No.	Description	Material
1	Bracket	Steel strip

DIN Rail Mounting Bracket



Component Parts

		pononii and	
ĺ	No.	Description	Material
	1	Bracket	Steel strip
	2	Cross recessed round head screw	Steel wire
	3	Clasp	Steel strip

Component Parts

No.	Description	Material	Note
1	Body A	PBT	
2	Knob	POM	
3	Body B	PBT	
4	Needle	PBT	
5	Needle guide	Brass	Electroless nickel plating
6	U-seal	HNBR	
7	Spacer	PBT*1	
8	Cassette	_	
9	Seal	NBR	
10	O-ring	NBR	
11	O-ring	NBR	
12	Bonnet A	POM	
13	Bonnet B	POM	
14	Gear	PPS	
15	Indicator gear	POM	
16	Clip	Stainless steel	

^{*1:} The AS3002FS□-11, AS4002FS□-11, AS4002FS□-13 are made of electroless nickel plated brass.

Dimensions

Indicator window direction: 0° Indicator window direction: 180° L6 W_1 W₂ Ø D4 **X**2 Release button dimensions Ø D2 through 7 Ø D AS1002F AS1002F **M**1 Applicable tubing O.D.: Ø 3.2, Ø 4, Ø 6, Ø 1/8", 2 x Applicable tubing O.D. Ø d Ø 5/32"

Right side view

Front view

Metric Size

Model	Applicable tubing	D ₁	Release		D 2	D 3	D4	D 5	L ₁	L2	Lз	L4	! *1	L ₅	L ₆	L ₇	L8	M ₁	W1	W ₂	X 1	X 2	Weight
	0.D. Ø d		Ø X(X)	Υ								Max.	Min.	1									[g]
AS1002FS□-23	3.2	8.4	6.7	9.5					36.6	5.1	11.8	36.4	22.0				10.1						5.2
AS1002FS□-04	4	9.3	7.7	10.0	3.3	5.5	9.4	10.0	37.6	5.1	11.0	30.4	33.9	11.0	15.4	8.8	10.1	13.5	13.6	15.1	5.5	9.6	5.5
AS1002FS□-06	6	11.6	9.7	12.0					40.1	6.1	12.8	37.4	34.9				12.3						6.6
AS2002FS□-04	4	9.3	7.7	10.0	3.3	5.5	12.0	12.0	41.3	6.3	12./	44.5	43 O	12.6	17.0	10.5	12.3	13.5	20.0	21.5	6.5	15.0	9.5
AS2002FS□-06	6	11.6	9.7	12.0	5.5	3.3	12.0	12.0	43.1	0.5	13.4	44.5	45.0	12.0	17.0	10.5	12.5	13.3	20.0	21.5	0.5	13.0	10.4
AS2052FS□-06	6	12.8	11.5	_	4.3	7.8	13.0	16.0	54.2	7.6	17.2	49.0	47.6	17.0	22.5	12.0	16 1	17.0	21.5	24.0	7.8	16.2	16.0
AS2052FS□-08	8	15.2	13.5	_	4.5	7.0	13.0	10.0	57.2	8.5	18.1	49.9	48.5	17.0	22.5	12.0	10.1	19.0	21.5	24.0	7.0	10.2	18.4
AS3002FS□-06	6	13.2	11.5						60.0									17.0					23.8
AS3002FS□-08	8	15.2	13.5	_	4.3	8.0	166	20.0	65.0	9.8	21.7	55.7	54.3	22.0	25.0	120	20.5	19.0	24.5	28.5	9.3	19.2	26.0
AS3002FS□-10	10	18.5	16.5	_	4.3	0.0	10.0	20.0	70.4					22.0	25.0	12.0		21.0	24.5	20.5	9.3	19.2	30.6
AS3002FS□-12	12	20.9	18.5	_					76.0	10.9	22.8	56.8	55.4	1			22.1	22.0					34.2
AS4002FS□-10	10	18.5	16.5	_	4.3	8.0	100	26.0	76.9	11.3	23.7	64.3	60.7	20 0	33.0	140	26.2	21.0	26.0	29.0	10.0	10.0	42.5
AS4002FS□-12	12	21.7	18.5	_	4.3	0.0	10.0	20.0	81.3	11.3	23.7	04.3	02.7	20.0	33.0	14.0	20.2	22.0	20.0	29.0	10.0	19.0	47.9

^{*1:} Reference dimensions

Inch Size

Model	Applicable tubing	D ₁	Release		D ₂	D 3	D4	D 5	L ₁	L2	L3	L	1 *1	L ₅	L ₆	L ₇	L8	M ₁	W 1	W ₂	X 1	X 2	Weight [g]
	0.D. Ø d		Ø X (X)	Υ								Max.	Min.										[9]
AS1002FS□-01	1/8"	8.4	6.7	9.5					36.6	5.1	11.8	36.4	22.0				10.1						5.2
AS1002FS□-03	5/32"	9.3	7.7	10.0	3.3	5.5	9.4	10.0	37.6	3.1	11.0	30.4	33.9	11.0	15.4	8.8	10.1	13.5	13.6	15.1	5.5	9.6	5.5
AS1002FS□-07	1/4"	12	10.9	_					40.1	6.2	12.9	37.5	35.0				12.8						6.7
AS2002FS□-03	5/32"	9.3	7.7	10.0	3.3	5.5	12.0	12.0	41.3	6.3	13.4	44.5	43.0	12.6	17.0	10.5	12.3	13.5	20.0	21.5	6.5	15.0	9.5
AS2002FS□-07	1/4"	12	10.9		5.5	5.5	12.0	12.0	43.2	6.5	13.6	44.7	43.2	12.0	17.0	10.5	12.8	13.3	20.0	21.5	0.5	13.0	10.6
AS2052FS□-07	1/4"	13.2	12.0	_	4.3	7.8	13.0	16.0	53.4	7.6	17.2	49.0	47.6	17.0	22.5	12.0	16.1	17.0	21.5	24.0	7.8	16.2	16.4
AS2052FS□-09	5/16"	15.2	13.5		4.3	7.0	13.0	10.0	57.2	8.5	18.1	49.9	48.5	17.0	22.5	12.0	10.1	19.0	21.5	24.0	7.0	10.2	18.4
AS3002FS□-07	1/4"	13.2	12.0						59.0									17.0					23.6
AS3002FS□-09	5/16"	15.2	13.5		4.3	8.0	16.6	20.0	65.0	9.8	21.7	55.7	54.3	22.0	25.0	12.0	20.5	19.0	24.5	28.5	9.3	19.2	26.0
AS3002FS□-11	3/8"	18.5	16.0						69.8									21.0					38.1
AS4002FS□-11	3/8"	18.5	16.0	_	4.3	8.0	18.8	26.0	76.9	11 2	23.7	64.3	62.7	28 U	33.0	1/10	26.2	21.0	26.0	29.0	10.0	19.0	50.2
AS4002FS□-13	1/2"	21.7	20.0		4.3	0.0	10.0	20.0	81.3	11.3	23.7	04.3	02.7	20.0	33.0	14.0	20.2	22.0	20.0	29.0	10.0	19.0	57.4


^{*1:} Reference dimensions





AS-FS Series

Dimensions

L-Bracket Bracket on a single side








	<u>2</u>	x Ø D6	L18	L23	Fi	L21			L25
AS2052 AS3002 AS4002	FS□ FS□	D D6	L24		23 -				
		O SMC	L18	AS30)002F	F ₂₀	L21		
Part no.	Applicable model	D6 L18	L 19	L20 L	21 L 22	L23	L24	L25	t2

Part no. | Applicable model | D5 | L9 | L10 | L11 | L12 | L13 | L14 | L15 | L16 | L17 AS-10L AS1002FS 14.8 18.3 11 27.5 19.5 3.4 12 AS-20L AS2002FS□ 15.6 19.6 12.6 29 21 1.2 AS-25L AS2052FS□ 19.6 24.6 17 38 28 **AS-30L AS3002FS** 4.5 24.8 29.8 22 43 33 4.5 6.5 9.5 15.5 AS-40L AS4002FS 25.7 30.7 28 49 39

Adapter for Manifold Mounting

Part no.: AS-□□A



Part no.	Applicable model	D 7	L26	L28
AS-10A	AS1002FS□	9.2	4	18.7
AS-20A	AS2002FS□	9.4	8.8	20.4
	AS2052FS□	11.4	6.3	27
AS-30A	AS3002FS□	11.8	5.9	32.1

*: The AS4002FS□ can be mounted without the adapter.

Adapter for Direct Mounting

DIN Rail Mounting Bracket

Bracket on a single side

AS1002FS□ AS2002FS□

Part no.: AS-□□A1


AS-10D AS1002FS

AS-20D AS2002FS

AS-25D AS2052FS

AS-30D AS3002FS

AS-40D AS4002FS



Part no.	Applicable model	D ₇	L27	L28
AS-10A1	AS1002FS□	9.2	4.5	18.7
AS-20A1	AS2002FS□	9.4	9.3	20.4
AS-25A1	AS2052FS□	11.4	7.1	27
AS-30A1	AS3002FS□	11.8	6.4	32.1
TI 4040				

18.2 23.2 11

22 27

27.2 32.2 22

28.1 33.1 28

18.6 23.6 12.6

17

18

19.6

36.8


25.8 11.3 1.6

3.5

4.4 30.8


*: The AS4002FS□ can be mounted without the adapter.

L-Bracket Brackets on both sides



- *: Refer to page 6 for L8.
- *: The above figure shows the manifold with controllers connected using two L-brackets, adapters and a threaded stud kit for manifold. Refer to page 4 for threaded stud kits for manifold.
- *: Cannot connect the controller when the indicator window direction is 90° or 270°.

DIN Rail Mounting Bracket Brackets on both sides



- *: Refer to page 6 for L8.
- *: The above figure shows the manifold with controllers connected using two DIN rail mounting brackets, adapters and a threaded stud kit for manifold. Refer to page 4 for threaded stud kits for manifold.
- *: Cannot connect the controller when the indicator window direction is 90° or 270°.


Adapter

45

4.5

Direct mounting

 \ast : For use when the mounting surface interferes with the bonnet.



- *: Refer to page 6 for L8.
- *: The AS4002FS can be mounted directly without the adapter.

Speed Controller with Indicator Stainless Steel Series

In-line Type

AS-FSG Series



In-line



Model

		Applicable tubing O.D.											
Model		1	Metric size			Inch size							
	3.2	4	6	8	10	12	1/8"	5/32"	1/4"	5/16"	3/8"	1/2"	
AS1002FSG	•	•	•				•	•	•				
AS2002FSG		•	•					•	•				
AS2052FSG			•	•					•	•			
AS3002FSG			•	•	•	•			•	•	•		
AS4002FSG					•	•					•	•	

Specifications

Fluid	Air
Proof pressure	1.5 MPa
Max. operating pressure	1 MPa
Min. operating pressure	0.1 MPa
Ambient and fluid temperature	-5 to 60 °C (No freezing)
Applicable tubing material	Nylon, Soft nylon, Polyurethane*1, FEP, PFA

^{*1:} Use caution at the max. operating pressure when using soft nylon or polyurethane tubing. (Refer to the catalogue on www.smc.eu for details.)

Flow Rate and Sonic Conductance

Mode	el	AS ²	1002FS	G□	AS2002	2FSG□	AS205	2FSG□		AS3002	2FSG		AS400	2FSG□
Tubing	Metric size	Ø 3.2	Ø 4	Ø6	Ø 4	Ø6	Ø6	Ø 8	Ø6	Ø 8	Ø 10	Ø 12	Ø 10	Ø 12
Tubing O.D.	Inch size	Ø 1/8"	Ø 5/32"	Ø 1/4"	Ø 5/32"	Ø 1/4"	Ø 1/4"	Ø 5/16"	Ø 1/4"	Ø 5/16"	Ø 3/8"	-	Ø 3/8"	Ø 1/2"
C values: Sonic	Free flow	0.3	0.4	0.6	0.4	0.6	1.0	1.2	1.1	1.6	2.2	2.6	2.4	3.5
conductance dm³(s·bar)	Controlled flow		0.3		0.4	0.6	1.0	1.2	1.3	1.9	2.7	3.3	2.8	4.1
b values: Critical	Free flow	0.3	0.	.2	0.3	0.1	0	.2		0.	2		0.3	0.2
pressure ratio	Controlled flow	0.2	0.3	0.4	0.	.2	0.2	0.3	0	.1	0.	.2	0.1	0.2

<sup>3.5
4.1
0.2
0.2</sup>

Flow Direction

How to Order



100	M5 standard
200	1/8 standard
205	1/4 standard
300	3/8 standard
400	1/2 standard

With indicator

Stainless steel type (Stainless steel 303)

- *: The material can be visually identified by colour of the release button. Stainless steel type: White
- *: White is also used for inch size.

♦ Applicable tubing O.D.*1 Metric size Inch size

Metri	IIIC	
23	Ø 3.2*2	01
04	Ø 4	03
06	Ø6	07
08	Ø8	08
10	Ø 10	11
12	Ø 12	13

01	Ø 1/8"
03	Ø 5/32"
07	Ø 1/4"
09	Ø 5/16"
11	Ø 3/8"
13	Ø 1/2"

- *1: For selecting applicable tubing O.D., refer to the "Model" shown above.
- *2: Use Ø 1/8" tubing.

Indicator direction

_	0°	Indicator window Index plate	2	90°	Index plate
1	180°	Indicator window Index plate	3	270°	Index plate


Dimensions, flow rate characteristics and options are the same as standard product (brass needle guide). Refer to page 4 for the manifolds (DIN rail bracket mounting/L-bracket mounting).




^{*:} C and b values are for controlled flow with the needle fully open and free flow with the needle fully closed.

AS-FSG Series

Construction






Component Parts

No.	Description	Material	Note
1	Body A	PBT	
2	Knob	POM	
3	Body B	PBT	
4	Needle	PBT	
5	Needle guide	Stainless steel	
6	U-seal	HNBR	
7	Spacer	PBT*1	
8	Cassette	_	
9	Seal	NBR	
10	O-ring	NBR	
11	O-ring	NBR	
12	Bonnet A	POM	
13	Bonnet B	POM	
14	Gear	PPS	
15	Indicator gear	POM	
16	Clip	Stainless steel	

^{*1:} The AS3002FS \square -11, AS4002FS \square -11, AS4002FS \square -13 are made of stainless steel.


L-Bracket



Component Parts

	P	
No.	Description	Material
1	Bracket	Steel strip

DIN Rail Mounting Bracket



Component Parts

00	ponont i arto	
No.	Description	Material
1	Bracket	Steel strip
2	Cross recessed round head screw	Steel wire
3	Clasp	Steel strip

Related Equipment

Holder for Speed Controller


TMH Series

A holder for securing a speed controller with One-touch fittings (In-line type)

Possible to hold a single controller.



Holder mounting



Specifications

Ambient temperature	-20 to 60 °C
Material	Polypropylene
Colour	White

Accessory: Cross Recessed Round Head Screw for Mounting (Zinc chromated)

Part	no.	Size	Quantity
Metric size	Inch size	(Nominal x Length)	Quartity
TMH-23J	TMH-01J	M3 x 15	
TMH-04J	TMH-03J	IVIO X IO	
TMH-06J	TMH-07J	M3 x 20	1
TMH-06	TMH-07	M4 x 25	
TMH-08	TMH-09	IVI4 X 25	
TMH-10	_	M4 x 35	
TMH-12	TMH-13	1V14 X 33	

Series

Select the applicable holder/TMH for each speed controller from the table below.

Metric Size


Tubing size	Applicable tubing					
	23	04	06	80	10	12
Applicable model	Ø 3.2	Ø 4	Ø6	Ø 8	Ø 10	Ø 12
AS1002FS□	TMH-23J	TMH-04J	TMH OF I			
AS2002FS□		110111-045	I MIH-003			
AS2052FS□			TMH-06	TMH-08		
AS3002FS□			TMH-07	I WITI-UO	TMH-10	TMH-12
AS4002FS□					1 W117-10	TMH-13

^{*:} The applicable TMH for the AS1002FS \square -02 is not available.

Inch Size

Tubing size			Applicab	le tubing		
	01	03	07	09	11	13
Applicable model	Ø 1/8"	Ø 5/32"	Ø 1/4"	Ø 5/16"	Ø 3/8"	Ø 1/2"
AS1002FS□	TMH-01J	TMH-03J	TMH 07 I			
AS2002FS□		1 MH-030	TIVITI-U/J			
AS2052FS□			TMH-07	TMH-09		
AS3002FS□			I WITI-U7	I IVITI-US	TMH-10	
AS4002FS□					1 W17-10	TMH-13

Dimensions



Part no.		α D1	α Da	H1	H2	НЗ	H4	H5	14	1.2	12	Cumbal
Metric size	Inch size	וטש	Ø D2	пі	П2	пз	П4	пэ	L1	L2	L3	Symbol
TMH-23J	TMH-01J	8.5	8.5 9.4 3.3	4.5	4.6	7.5	6	12	7.2	6.6	18	1/8J
TMH-04J	TMH-03J	9.4										4 5/32J
TMH-06J	1	11.7	33	6.3	6.4	9.3	7.7	15.4	8.5	8.3	21	6J
_	TMH-07J	12.1										1/4J
TMH-06	-	13.1	4.3	7.1	7.2	11.1	10	20	11	10.6	26.5	6
_	TMH-07	13.5										1/4
TMH-08	TMH-09	15.5										8 5/16
TMH-10	_	18.8	4.3	9.5	9.6	13.5	14	28	14.2	14.6	34	10
TMH-12	-	21.2										12
_	TMH-13	22										1/2



⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution indicates a hazard with a low level of risk which if not avoided could result in minor or mode

which, if not avoided, could result in minor or moderate injury

njury.

Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious

injury.

⚠ Danger : Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

*1) ISO 4414: Pneumatic fluid power – General rules relating to systems. ISO 4413: Hydraulic fluid power – General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

⚠ Warning

 The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3.Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
 - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
 - An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, wichever is first.*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
 - *2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

A Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

∧ Caution

 $\ensuremath{\mathsf{SMC}}$ products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation (Europe)

Austria Belgium Bulgaria Croatia Czech Republic Denmark Estonia Finland France Germany Greece Hungary Ireland	☎ +43 (0)2262622800 ☎ +32 (0)33551464 ☎ +359 (0)2807670 ☎ +385 (0)13707288 ☎ +420 541424611 ☎ +45 70252900 ☎ +372 6510370 ☎ +358 207513513 ☎ +33 (0)164761000 ☎ +49 (0)61034020 ☎ +30 210 2717265 ☎ +36 23511390 ☎ +353 (0)14039000 ☎ +39 0792711	www.smc.at www.smcpneumatics.be www.smc.bg www.smc.hr www.smc.cz www.smcdk.com www.smcpneumatics.ee www.smc.fi www.smc.france.fr www.smc.de www.smc.hellas.gr www.smc.hellas.gr	office@smc.at info@smcpneumatics.be office@smc.bg office@smc.hr office@smc.cz smc@smcdk.com smc@smcpneumatics.ee smcfi@smc.fi info@smc-france.fr info@smc.de sales@smchellas.gr office@smc.hu sales@smcpneumatics.ie mailbov@smcitalia.it	Lithuania Netherlands Norway Poland Portugal Romania Russia Slovakia Slovenia Spain Sweden Switzerland Turkey IIK	### 370 5 2308118 34 370 5 2308118 35 370 5 2308118 36 370 5 23081888 36 47 67129020 36 48 222119600 37 38 1226166570 37 38 127185445 37 38 127185445 37 38 127185445 37 38 127185445 37 38 127185445 37 38 127185445 37 38 127185445 38 421 4210 38 42 421 4210 38 42 421 4210 38 42 421 4210 38 42 421 421 421 421 421 38 42 421 421 421 421 421 38 42 421 421 421 421 421 38 42 421 421 421 421 421 38 42 421 421 421 421 421 38 42 421 421 421 421 421 38 42 421 421 421 421 421 421 421 38 42 421 421 421 421 421 421 421 421 421	www.smclt.lt www.smcpneumatics.nl www.smc-norge.no www.smc.pl www.smc.eu www.smc-pneumatik.ru www.smc.sk www.smc.si www.smc.eu www.smc.eu www.smc.nu www.smc.ch	info@smcl.lt info@smcpneumatics.nl post@smc-norge.no office@smc.pl postpt@smc.smces.es smcromania@smcromania.ro info@smc-pneumatik.ru office@smc.sk office@smc.si post@smc.smces.es post@smc.smces.es post@smc.nu info@smc.ch
Italy Latvia	☎+39 0292711 ☎+371 67817700	www.smcitalia.it www.smclv.lv	mailbox@smcitalia.it info@smclv.lv	UK	* +44 (0)845 121 5122	www.smcpneumatics.co.uk	sales@smcpneumatics.co.uk